

Product Manual



Servo Positioning Controller ARS 2100 FS

designed for Functional Safety

Metronix Meßgeräte und Elektronik GmbH

Kocherstraße 3

38120 Braunschweig

Germany

Phone: +49-(0)531-8668-0

Telefax: +49-(0)531-8668-555

E-mail: vertrieb@metronix.de

<http://www.metronix.de>

Translation of the original instructions

Copyrights

© 2015 Metronix Meßgeräte und Elektronik GmbH. All rights reserved.

The information and data in this document have been composed to the best of our knowledge. However, deviations between the document and the product cannot be excluded entirely. For the devices and the corresponding software in the version handed out to the customer, Metronix guarantees the contractual use in accordance with the user documentation. In the case of serious deviations from the user documentation, Metronix has the right and the obligation to repair, unless it would involve an unreasonable effort. A possible liability does not include deficiencies caused by deviations from the operating conditions intended for the device and described in the user documentation.

Metronix does not guarantee that the products meet the buyer's demands and purposes or that they work together with other products selected by the buyer. Metronix does not assume any liability for damages resulting from the combined use of its products with other products or resulting from improper handling of machines or systems.

Metronix Meßgeräte und Elektronik GmbH reserves the right to modify, amend, or improve the document or the product without prior notification.

This document may, neither entirely nor in part, be reproduced, translated into any other natural or machine-readable language nor transferred to electronic, mechanical, optical or any other kind of data media, without expressive authorisation by the author.

Trademarks

Any product names in this document may be registered trademarks. The sole purpose of any trademarks in this document is the identification of the corresponding products.

ServoCommander[®] is a registered trademark of Metronix Meßgeräte und Elektronik GmbH.

Revision Information	
Author:	Metronix Meßgeräte und Elektronik GmbH
Manual title:	Product Manual „Servo Positioning Controller ARS 2100 FS“
File name:	P-HB_ARS2100_FS_5p0_EN.docx
Version 5.0	August 2015

TABLE OF CONTENTS:

1	GENERAL	15
1.1	Documentation.....	15
1.2	Scope of supply	16
2	SAFETY NOTES FOR ELECTRICAL DRIVES AND CONTROLLERS	17
2.1	Used symbols	17
2.2	General notes.....	18
2.3	Danger resulting from misuse	20
2.4	Safety notes	21
2.4.1	General safety notes.....	21
2.4.2	Safety notes for assembly and maintenance	23
2.4.3	Protection against contact with electrical parts	25
2.4.4	Protection against electrical shock by means of protective extra-low voltage (PELV).....	26
2.4.5	Protection against dangerous movements.....	26
2.4.6	Protection against contact with hot parts	27
2.4.7	Protection during handling and assembly	28
3	PRODUCT DESCRIPTION.....	29
3.1	General	29
3.2	Power supply	32
3.2.1	Single-phase AC supply with active PFC.....	32
3.2.1.1	Behaviour during switch-on	32
3.2.1.2	Behaviour during normal operation and control characteristics	33
3.2.2	DC bus coupling, DC supply	34
3.2.2.1	DC bus coupling	34
3.2.2.2	DC supply	34
3.2.3	Mains fuse	34
3.3	Brake chopper.....	35
3.4	Communication interfaces.....	35
3.4.1	Serial interface [X5].....	36
3.4.2	USB interface [X19]	36
3.4.3	UDP interface [X18]	36
3.4.4	CAN interface [X4]	36
3.4.5	Technology module: PROFIBUS	37
3.4.6	Technology module: Sercos II	37

3.4.7	Technology module: EtherCAT	37
3.4.8	I/O functions and device control	37
4	TECHNICAL DATA	39
4.1	General Technical data	39
4.2	Operating and display elements	41
4.3	Supply [X9]	42
4.4	Motor connection [X6]	44
4.4.1	Current derating	44
4.5	Motor feedback connection [X2A] and [X2B]	49
4.5.1	Resolver connection [X2A]	50
4.5.2	Encoder connection [X2B]	51
4.6	Communication interfaces	53
4.6.1	RS232 [X5]	53
4.6.2	USB [X19]	53
4.6.3	Ethernet [X18]	54
4.6.4	CAN bus [X4]	54
4.6.5	SD/MMC card	54
4.6.6	I/O interface [X1]	55
4.6.7	Incremental encoder input [X10]	56
4.6.8	Incremental encoder output [X11]	57
5	FUNCTION OVERVIEW	58
5.1	Motors	58
5.1.1	Synchronous servo motors	58
5.1.2	Linear motors	58
5.2	Functions of the servo positioning controller ARS 2100 FS	59
5.2.1	Compatibility	59
5.2.2	Pulse width modulation (PWM)	60
5.2.3	Setpoint management	60
5.2.4	Torque-controlled mode	61
5.2.5	Speed-controlled mode	61
5.2.6	Torque-limited speed control	62
5.2.7	Synchronization to the external clock signal	62
5.2.8	Load torque compensation for vertical axes	62
5.2.9	Positioning and position control	62
5.2.10	Synchronisation, electronic gearing	63
5.2.11	Brake management	63

5.3	Positioning control	64
5.3.1	Overview	64
5.3.2	Relative positioning	65
5.3.3	Absolute positioning	65
5.3.4	Driving profile generator	65
5.3.5	Homing	66
5.3.6	Positioning sequences	67
5.3.7	Optional stop input	67
5.3.8	Contouring control with linear interpolation	67
5.3.9	Time-synchronized multi-axis positioning	68
6	FUNCTIONAL SAFETY TECHNOLOGY	69
6.1	General	69
6.1.1	DIP switch	70
6.1.2	Assignment of the DIP switch	71
6.2	Integrated safety technology (schematic representation)	73
6.3	Module variants	74
6.3.1	FBA module	74
6.3.2	FSM 2.0 – STO (Safe Torque Off)	75
6.3.3	FSM 2.0 – MOV	75
7	MECHANICAL INSTALLATION	76
7.1	Important notes	76
7.2	View of the device	78
7.3	Mounting	80
8	ELECTRICAL INSTALLATION	81
8.1	Connector configuration	81
8.2	ARS 2100 FS complete system	82
8.3	Connection: Power supply [X9]	84
8.3.1	Device side [X9]	84
8.3.2	Counterplug [X9]	84
8.3.3	Pin assignment [X9]	85
8.3.4	Cable type and design [X9]	85
8.3.5	Connection notes [X9]	86
8.4	Connection: Motor [X6]	87
8.4.1	Device side [X6]	87
8.4.2	Counterplug [X6]	87
8.4.3	Pin assignment [X6]	88

8.4.4	Cable type and design [X6].....	88
8.4.5	Connection notes [X6].....	89
8.5	Connection: I/O communication [X1].....	91
8.5.1	Device side [X1].....	93
8.5.2	Counterplug [X1].....	93
8.5.3	Pin assignment [X1].....	94
8.5.4	Cable type and design [X1].....	95
8.5.5	Connection notes [X1].....	95
8.6	Connection: Resolver [X2A]	96
8.6.1	Device side [X2A].....	96
8.6.2	Counterplug [X2A].....	96
8.6.3	Pin assignment [X2A].....	96
8.6.4	Cable type and design [X2A]	97
8.6.5	Connection notes [X2A]	97
8.7	Connection: Encoder [X2B]	98
8.7.1	Device side [X2B].....	98
8.7.2	Counterplug [X2B].....	98
8.7.3	Pin assignment [X2B].....	99
8.7.4	Cable type and design [X2B]	101
8.7.5	Connection notes [X2B]	102
8.8	Connection: Incremental encoder input [X10]	104
8.8.1	Device side [X10]	104
8.8.2	Counterplug [X10].....	104
8.8.3	Pin assignment [X10].....	104
8.8.4	Cable type and design [X10].....	105
8.8.5	Connection notes [X10].....	105
8.9	Connection: Incremental encoder output [X11]	106
8.9.1	Device side [X11].....	106
8.9.2	Counterplug [X11].....	106
8.9.3	Pin assignment [X11].....	106
8.9.4	Cable type and design [X11].....	107
8.9.5	Connection notes [X11].....	107
8.10	Connection: CAN-Bus [X4]	108
8.10.1	Device side [X4].....	108
8.10.2	Counterplug [X4].....	108
8.10.3	Pin assignment [X4].....	108
8.10.4	Cable type and design [X4].....	109
8.10.5	Connection notes [X4].....	109

8.11 Connection: RS232/COM [X5].....	111
8.11.1 Device side [X5].....	111
8.11.2 Counterplug [X5].....	111
8.11.3 Pin assignment [X5].....	111
8.11.4 Cable type and design [X5].....	112
8.11.5 Connection notes [X5].....	112
8.12 Connection: USB [X19]	113
8.12.1 Device side [X19].....	113
8.12.2 Counterplug [X19].....	113
8.12.3 Pin assignment [X19].....	113
8.12.4 Cable type and design [X19].....	113
8.13 SD/MMC card.....	114
8.13.1 Supported card types.....	114
8.13.2 Supported functions.....	114
8.13.3 Supported file systems.....	114
8.13.4 File names	114
8.13.5 Pin assignment SD/MMC card.....	115
8.13.6 BOOT-DIP-Switch.....	116
8.14 Notes on safe and EMC-compliant installation	117
8.14.1 Definitions and terms	117
8.14.2 General information on EMC	117
8.14.3 EMC areas: first and second environment	118
8.14.4 EMC-compliant cabling	118
8.14.5 Operation with long motor cables.....	119
8.14.6 ESD protection.....	120
9 ADDITIONAL REQUIREMENTS FOR THE SERVO DRIVES CONCERNING THE UL APPROVAL.....	121
9.1 Circuit protection.....	121
9.2 Wiring and environment regards.....	121
9.3 Motor temperature sensor	121
10 INITIAL OPERATION	122
10.1 General notes on connection	122
10.2 Tools / material	122
10.3 Connecting the motor	123
10.4 Connecting the servo positioning controller ARS 2100 FS to the power supply	123
10.5 Connecting the PC (serial interface).....	123

10.6	Connecting the PC (USB interface, alternative)	124
10.7	Checking operability	124
11	SERVICE FUNCTIONS AND ERROR MESSAGES	125
11.1	Protection and service functions	125
11.1.1	Overview	125
11.1.2	Overcurrent and short-circuit monitoring	125
11.1.3	Overvoltage monitoring for the DC bus	126
11.1.4	Temperature monitoring of the heat sink	126
11.1.5	Monitoring of the motor	126
11.1.6	I ² t monitoring	126
11.1.7	Power monitoring for the brake chopper	127
11.1.8	I ² t monitoring for the PFC stage	127
11.1.9	Initial operation status	127
11.1.10	Rapid discharge of the DC bus	127
11.1.11	Operating hours counter	127
11.2	Display of operating mode and error messages	128
11.2.1	Operating mode and error display	128
11.2.2	Error messages	129
12	TECHNOLOGY MODULES	166
12.1	EA88 interface (terminal extension)	166
12.1.1	Product description	166
12.1.2	Technical data	166
12.1.2.1	General data	166
12.1.2.2	Digital inputs	167
12.1.2.3	Digital outputs	167
12.1.3	Pin assignment and cable specifications	168
12.1.3.1	Power supply	168
12.1.3.2	Pin assignments	168
12.1.3.3	Counterplug	169
12.1.3.4	Connection notes	169
12.2	PROFIBUS-DP interface	170
12.2.1	Product description	170
12.2.2	Technical data	170
12.2.3	Pin assignments and cable specifications	172
12.2.3.1	Pin assignment	172
12.2.3.2	Counterplug	172
12.2.3.3	Cable type and configuration	172
12.2.4	Termination and bus terminating resistors	173

12.3 Sercos II module	174
12.3.1 Product description	174
12.3.2 Technical data.....	175
12.3.3 Optical waveguide specification	176
12.4 EtherCAT	177
12.4.1 Product description	177
12.4.2 Characteristics of the EtherCAT technology module.....	177
12.4.3 Technical data.....	178
12.4.4 Display elements.....	179
12.4.5 EtherCAT interface	179
12.5 MC 2000 “Drive-In” 4-Axis Motion Coordinator	180
12.5.1 Product description	180
12.5.2 Features.....	181
12.5.2.1 Compact.....	181
12.5.2.2 Fast.....	182
12.5.2.3 Easy	182
12.5.3 Technical data.....	183
12.6 General installation notes for technology modules	184

Table of Figures:

Figure 1:	Type key	29
Figure 2:	Schematic setup of PFC stage	33
Figure 3:	Performance curve of the PFC stage	43
Figure 4:	Control scheme of the ARS 2100 FS.....	59
Figure 5:	Driving profiles of servo positioning controller ARS 2100 FS	65
Figure 6:	Path program	67
Figure 7:	Linear interpolation between two data values	68
Figure 8:	Schematic representation of the integrated safety technology (MOV)	73
Figure 9:	FBA module: Front view	74
Figure 10:	Servo positioning controller ARS 2100 FS: Installation space	77
Figure 11:	Servo positioning controller ARS 2102 FS: Front view.....	78
Figure 12:	Servo positioning controller ARS 2102 FS: Top view.....	79
Figure 13:	Servo positioning controller ARS 2102 FS: Bottom view.....	79
Figure 14:	Servo positioning controller ARS 2100 FS: Mounting plate	80
Figure 15:	Connection to power supply and motor	81
Figure 16:	Complete setup of the ARS 2100 FS with motor and PC.....	83
Figure 17:	Supply [X9].....	86
Figure 18:	Motor connection [X6].....	89
Figure 19:	Connecting a holding brake with high current draw (> 1A) to the device	90
Figure 20:	Basic circuit diagram connector [X1]	92
Figure 21:	Pin assignment: Resolver connection [X2A].....	97
Figure 22:	Pin assignment: Analog incremental encoder – optional [X2B].....	102
Figure 23:	Pin assignment: Incremental encoder with serial communication interface (for example EnDat, HIPERFACE) – optional [X2B]	102
Figure 24:	Pin assignment: Digital incremental encoder – optional [X2B].....	103
Figure 25:	Pin assignment: Input of the incremental encoder [X10].....	105
Figure 26:	Pin assignment: Incremental encoder output [X11].....	107
Figure 27:	Cabling example for CAN-Bus.....	109
Figure 28:	Integrated CAN terminating resistor	110
Figure 29:	Pin assignment: RS232 null modem cable [X5]	112
Figure 30:	Pin assignment: USB interface [X19], front view	113
Figure 31:	Pin assignment: SC/MMC card.....	115

Figure 32:	E88: Position of the pin-and-socket connectors [X21] and [X22] at the front plate	169
Figure 33:	PROFIBUS-DP interface: Front view	171
Figure 34:	PROFIBUS-DP interface: Connection with external terminating resistors	173
Figure 35:	Sercos II module: Front view	175
Figure 36:	EtherCAT module: Front view	178
Figure 37:	MC 2000 4-Axis Motion Coordinator.....	181
Figure 38:	MC 2000 4-Axis Motion Coordinator maximum capacity.....	181
Figure 39:	Servo positioning controller with integrated technology module MC 2000 (example)	184

Table of Tables:

Table 1:	Scope of supply	16
Table 2:	Connector set: POWER connector	16
Table 3:	Connector set: DSUB connector.....	16
Table 4:	Connector set: Shield connector.....	16
Table 5:	Technical data: Ambient conditions and qualification.....	39
Table 6:	Technical data: Dimensions and weight	39
Table 7:	Technical data: Cable specifications	40
Table 8:	Technical data: Motor temperature monitoring	40
Table 9:	Display elements and RESET button	41
Table 10:	Technical data: Performance data [X9]	42
Table 11:	Technical data: Internal brake resistor [X9]	42
Table 12:	Technical data: External brake resistor [X9]	42
Table 13:	Performance data of PFC stage	43
Table 14:	Technical data: Motor connection [X6]	44
Table 15:	ARS 2102 FS: Rated current for an ambient temperature of $\leq 40\text{ °C}$	46
Table 16:	ARS 2105 FS: Rated current for an ambient temperature of $\leq 40\text{ °C}$	46
Table 17:	ARS 2108 FS: Rated current for blocked or slowly rotated servo motor ($f_{el} \leq 2\text{ Hz}$ and for an ambient temperature of $\leq 40\text{ °C}$	47
Table 18:	ARS 2108 FS: Rated current for rotated servo motor ($f_{el} \geq 3\text{ Hz}$ and for an ambient temperature of $\leq 40\text{ °C}$	48
Table 19:	Technical data: Resolver [X2A]	50
Table 20:	Technical data: Resolver interface [X2A]	50
Table 21:	Technical data: Encoder evaluation [X2B].....	51
Table 22:	Technical data: RS232 [X5]	53
Table 23:	Technical data: USB [X19].....	53
Table 24:	Technical data: Ethernet [X18]	54
Table 25:	Technical data: CAN bus [X4].....	54
Table 26:	Technical data: SD/MMC card.....	54
Table 27:	Technical data: Digital inputs and outputs [X1]	55
Table 28:	Technical data: Analog inputs and outputs [X1]	56
Table 29:	Technical data: Incremental encoder input [X10]	56
Table 30:	Technical data: Incremental encoder output [X11]	57
Table 31:	Output voltage at the motor terminals in the case of a DC bus circuit voltage (U_{ZK}) of 360 V	60

Table 32:	Table overview of the DIP switch functionality	70
Table 33:	Fieldbus specific assignment of the DIP switches	72
Table 34:	Pin assignment: [X9]	85
Table 35:	Pin assignment: [X6]	88
Table 36:	Pin assignment: I/O communication [X1]	94
Table 37:	Pin assignment: [X2A]	96
Table 38:	Pin assignment: Analog incremental encoder – optional [X2B]	99
Table 39:	Pin assignment: Incremental encoder with serial interface (for example EnDat, HIPERFACE) – optional [X2B]	100
Table 40:	Pin assignment: Digital incremental encoder – optional [X2B]	101
Table 41:	Pin assignment: Incremental encoder input [X10]	104
Table 42:	Pin assignment: Incremental encoder output [X11]	106
Table 43:	Pin assignment: CAN-Bus [X4]	108
Table 44:	Pin assignment: RS232 interface [X5]	111
Table 45:	Pin assignment: USB interface [X19]	113
Table 46:	Pin assignment: SD card	115
Table 47:	Pin assignment: MMC card	115
Table 48:	EMC requirements: First and second environment	118
Table 49:	Operating mode and error display	128
Table 50:	Error messages	130
Table 51:	Technical data: EA88 interface	166
Table 52:	Digital inputs: EA88 interface [X21]	167
Table 53:	Digital outputs: EA88 interface [X22]	167
Table 54:	EA88: Connector [X21] for 8 digital inputs	168
Table 55:	EA88: Connector [X22] for 8 digital outputs	168
Table 56:	Technical data: PROFIBUS-DP interface: Ambient conditions, dimensions and weight	170
Table 57:	Technical data: PROFIBUS-DP interface: Interfaces and communication	171
Table 58:	Pin assignment: PROFIBUS-DP interface	172
Table 59:	Technical data: Sercos II module: Ambient conditions, dimensions and weight	175
Table 60:	Technical data: EtherCAT module: Ambient conditions, dimensions and weight	178
Table 61:	Display elements	179
Table 62:	Signal level and differential voltage	179
Table 63:	Technical data: MC 2000 4-Axis Motion Coordinator	183

1 General

1.1 Documentation

This product manual serves the purpose of a safe use of the ARS 2100 FS series servo positioning controllers. It contains safety notes, which must be complied with.

Further information can be found in the following manuals of the ARS 2000 FS product range:

- ❖ **Product Manual "Servo Positioning Controller ARS 2300 FS"**: Description of the technical data and the device functionality plus notes concerning the installation and operation of ARS 2302 FS, ARS 2305 FS and ARS 2310 FS servo positioning controllers.
- ❖ **Product Manual "MC 2000"**: Description of the technical data and the device functionality as well as notes on the installation and the operation of the Motion Coordinator MC 2000 (German version).
- ❖ **Product Manual "FSM 2.0 - STO"**: Description of the technical data and device functionality plus notes on the installation and operation of the FSM 2.0 – STO.
- ❖ **Product Manual "FSM 2.0 - MOV"**: Description of the technical data and device functionality plus notes on the installation and operation of the FSM 2.0 – MOV (German version).
- ❖ **PROFIBUS Manual "Servo Positioning Controller ARS 2000"**: Description of the implemented PROFIBUS-DP protocol.
- ❖ **CANopen Manual "Servo Positioning Controller ARS 2000"**: Description of the implemented CANopen protocol as per DSP402.
- ❖ **ETHERNET Manual "Servo Positioning Controller ARS 2000"**: Description of the implemented Ethernet protocol (UDP).
- ❖ **EtherCAT Manual "Servo Positioning Controller ARS 2000"**: Description of the implemented EtherCAT protocol (CoE) (German version).
- ❖ **Sercos Manual "Servo Positioning Controller ARS 2000"**: Description of the implemented Sercos functionality.

You can find all these documents on our homepage at the download area (<http://www.metronix.de>).

Certificates and declarations of conformity for the products described in this manual can be found at <http://www.metronix.de>.

The entire software functionality of the new ARS 2000 FS product range will be implemented in the course of a step-by-step development process.

This version of the product manual contains the functions of the firmware version 4.1.0.1.2.

1.2 Scope of supply

The scope of supply includes:

Table 1: Scope of supply

1x	Servo positioning controller ARS 2100 FS			
	Type	ARS 2102 FS	ARS 2105 FS	ARS 2108 FS
	Metronix order number	9200-2102-20	9200-2105-20	9200-2108-21

Counterplugs for power, controller or shaft encoder connections, as well as for shield connection are not included in the standard scope of supply. They can, however, be ordered as accessories.

Table 2: Connector set: POWER connector

1x	Connector set: POWER connector			
	This plug set contains the counterplugs for the following connections:			
	<ul style="list-style-type: none"> - Supply [X9] - Motor connection [X6] 			
	Type	ARS 2102 FS	ARS 2105 FS	ARS 2108 FS
	Metronix order number	9200-0210-20		9200-0218-20

Table 3: Connector set: DSUB connector

1x	Connector set: DSUB connector			
	This connector set includes the counterplugs for the following connections:			
	<ul style="list-style-type: none">- I/O interface [X1]- Angle encoder connection [X2A]- Angle encoder connection [X2B]- CAN fieldbus interface [X4]- Incremental encoder input [X10]- Incremental encoder output [X11]			
	Type	ARS 2102 FS	ARS 2105 FS	ARS 2108 FS
	Metronix order number	9200-0200-00		

Table 4: Connector set: Shield connector

1x	Connector set: Shield connector			
	This connector set includes two shield terminals (SK14)			
	Type	ARS 2102 FS	ARS 2105 FS	ARS 2108 FS
	Metronix order number	9200-0202-00		

2 Safety notes for electrical drives and controllers

2.1 Used symbols



Information

Important information and notes.



Caution!

Nonobservance may result in severe property damages.



DANGER!

Nonobservance may result in **property damages** and in **personal injuries**.



Caution! Dangerous voltages.

The safety note indicates a possible perilous voltage.

2.2 General notes

In case of damage resulting from non-compliance with the safety notes in this manual, Metronix Meßgeräte und Elektronik GmbH will not assume any liability.



Prior to the initial use you must read the *Safety notes for electrical drives and controllers* starting on page 17 and *chapter 8.14 Notes on safe and EMC-compliant installation*, starting on page 117.

If the documentation in the language at hand is not understood accurately, please contact and inform your supplier.

Sound and safe operation of the servo positioning controller requires proper and professional transportation, storage, mechanical installation, and project planning – with a consideration of the risks as well as the protective and emergency measures – plus the proper and professional electrical installation, operation, and maintenance of the devices.

Only trained and qualified personnel is authorised to handle electrical devices and systems:

TRAINED AND QUALIFIED PERSONNEL

in the sense of this product manual or the safety notes on the product itself are persons who are sufficiently familiar with the project, the setup, assembly, commissioning and operation of the product as well as all warnings and precautions as per the instructions in this manual and who are sufficiently qualified in their field of expertise:

- ❖ Education and instruction concerning the standards and accident prevention regulations for the application, or authorisation to switch devices/systems on and off and to ground them as per the standards of safety engineering and to efficiently label them as per the job demands.
- ❖ Education and instruction as per the standards of safety engineering regarding the maintenance and use of adequate safety equipment.
- ❖ First aid training.

The following notes must be read prior to the initial operation of the system to prevent personal injuries and/or property damages:



These safety notes must be complied with at all times.



Do not try to install or commission the servo positioning controller before carefully reading all safety notes for electrical drives and controllers contained in this document. These safety instructions and all other user notes must be read prior to any work with the servo positioning controller.



In case you do not have any user notes for the servo positioning controller, please contact your sales representative. Immediately demand these documents to be sent to the person responsible for the safe operation of the servo positioning controller.



If you sell, rent and/or otherwise make this device available to others, these safety notes must also be included.



The user must not open the servo positioning controller for safety and warranty reasons.



Professional control process design is a prerequisite for sound functioning of the servo positioning controller!



DANGER!

Inappropriate handling of the servo positioning controller and non-compliance with the warnings as well as inappropriate intervention in the safety features may result in property damage, personal injuries, electric shock or in extreme cases even death.

2.3 Danger resulting from misuse

**DANGER!**

High electrical voltages and high load currents!

Danger to life or serious personal injury from electrical shock!

**DANGER!**

High electrical voltage caused by wrong connections!

Danger to life or serious personal injury from electrical shock!

**DANGER!**

Surfaces of device housing may be hot!

Risk of injury! Risk of burning!

**DANGER!****Dangerous movements!**

Danger to life, serious personal injury or property damage due to unintentional movements of the motors!

2.4 Safety notes

2.4.1 General safety notes



The servo positioning controller corresponds to IP20 degree of protection as well as pollution degree 2. Make sure that the environment corresponds to this degree of protection and pollution degree.



Only use replacement parts and accessories approved by the manufacturer.



The devices must be connected to the mains supply as per EN regulations, so that they can be cut off the mains supply by means of corresponding separation devices (for example main switch, contactor, power switch).



The servo positioning controller may be protected using an AC/DC sensitive 300 mA fault current protection switch, type B (RCD = Residual Current protective Device).



Gold contacts or contacts with a high contact pressure should be used to switch the control contacts.



Preventive interference rejection measures should be taken for control panels, such as connecting contactors and relays using RC elements or diodes.



The safety rules and regulations of the country in which the device will be operated must be complied with.



The environment conditions defined in the product documentation must be kept. Safety-critical applications are not allowed, unless specifically approved by the manufacturer.



For notes on installation corresponding to EMC, please refer to *chapter 8.14 Notes on safe and EMC-compliant installation (page 117)*. The compliance with the limits required by national regulations is the responsibility of the manufacturer of the machine or system.



The technical data and the connection and installation conditions for the servo positioning controller are to be found in this product manual and must be met.



DANGER!

The general setup and safety regulations for work on power installations (for example DIN, VDE, EN, IEC or other national and international regulations) must be complied with.

Non-compliance may result in death, personal injury or serious property damages.

**Without claiming completeness, the following regulations and others apply:**

VDE 0100	Erection of power installations with nominal voltages up to 1000 V
EN 1037	Safety of machinery - Prevention of unexpected start-up
EN 60204-1	Safety of machinery - Electrical equipment of machines Part 1: General requirements
EN 61800-3	Adjustable speed electrical power drive systems Part 3: EMC requirements and specific test methods
EN 61800-5-1	Adjustable speed electrical power drive systems Part 5-1: Safety requirements - Electrical, thermal and energy
EN 61800-5-2	Adjustable speed electrical power drive systems Part 5-2: Safety requirements - Functional
EN ISO 12100	Safety of machinery - General principles for design - Risk assessment and risk reduction
EN ISO 13849-1	Safety of machinery - Safety-related parts of control systems Part 1: General principles for design
EN ISO 13849-2	Safety of machinery - Safety-related parts of control systems Part 2: Validation

**More standards to be respected by the user:**

EN 574	Safety of machinery - Two-hand control devices
EN 1088	Safety of machinery - Interlocking devices associated with guards
EN ISO 13850	Safety of machinery - Emergency stop

2.4.2 Safety notes for assembly and maintenance

The appropriate DIN, VDE, EN and IEC regulations as well as all national and local safety regulations and rules for the prevention of accidents apply for the assembly and maintenance of the system. The plant engineer or the operator is responsible for compliance with these regulations:



The servo positioning controller must only be operated, maintained and/or repaired by personnel trained and qualified for working on or with electrical devices.

Prevention of accidents, injuries and/or damages:



Additionally secure vertical axes against falling down or lowering after the motor has been switched off, for example by means of:

- Mechanical locking of the vertical axle,
- External braking, catching or clamping devices or
- Sufficient balancing of the axle



The motor holding brake supplied by default or an external motor holding brake driven by the drive controller alone is not suitable for personal protection!



Keep the electrical equipment voltage-free using the main switch and protect it from being switched on again until the DC bus circuit is discharged, in the case of:

- Maintenance and repair work
- Cleaning
- long machine shutdowns



Prior to carrying out maintenance work make sure that the power supply has been turned off, locked and the DC bus circuit is discharged.



The external or internal brake resistor carries dangerous DC bus voltages during operation of the servo positioning controller and up to 5 minutes thereafter. Contact may result in death or serious personal injury. Wait for this time prior to performing any work on the affected connections. Measure the voltages for your own protection. Contact with these high DC bus circuit voltages may result in death or serious personal injury.



Be careful during the assembly. During the assembly and also later during operation of the drive, make sure to prevent drill chips, metal dust or assembly parts (screws, nuts, cable sections) from falling into the device.



Also make sure that the external power supply of the controller (24 V) is switched off.



The DC bus circuit or the mains supply must always be switched off prior to switching off the 24 V controller supply.



Carry out work in the machine area only, if AC and/or DC supplies are switched off. Switched off output stages or controller enablings are no suitable means of locking. In the case of a malfunction the drive may accidentally be put into action.

This does not apply to drives with the special “Safe Stop” feature in accordance with EN 954-1 CAT 3 or with the “Safe Torque Off” feature in accordance with EN 61800-5-2.

This feature can be achieved with the ARS 2100 FS by integrating the module FSM 2.0 – STO for example.



Initial operation must be carried out with idle motors, to prevent mechanical damages for example due to the wrong direction of rotation.



Electronic devices are never fail-safe. It is the user's responsibility, in the case an electrical device fails, to make sure the system is transferred into a secure state.



The servo positioning controller and in particular the brake resistor, externally or internally, can assume high temperatures, which may cause serious burns.

2.4.3 Protection against contact with electrical parts

This section only concerns devices and drive components carrying voltages exceeding 50 V. Contact with parts carrying voltages of more than 50 V can be dangerous for people and may cause electrical shock. During operation of electrical devices some parts of these devices will inevitably carry dangerous voltages.

**DANGER!**

High electrical voltage!

Danger to life, danger due to electrical shock or serious personal injury!

The appropriate DIN, VDE, EN and IEC regulations as well as all national and local safety regulations and rules for the prevention of accidents apply for the assembly and maintenance of the system. The plant engineer or the operator is responsible for compliance with these regulations:



Before switching on the device, install the appropriate covers and protections against accidental contact. Rack-mounted devices must be protected against accidental contact by means of a housing, for example a switch cabinet. The national regulations for safety/accident prevention must be complied with!



Always connect the ground conductor of the electrical equipment and devices securely to the mains supply. Due to the integrated line filter the leakage current exceeds 3.5 mA!



Comply with the minimum copper cross-section for the ground conductor over its entire length (see for example EN 60800-5-1).



Prior to the initial operation, even for short measuring or testing purposes, always connect the ground conductor of all electrical devices as per the terminal diagram or connect it to the ground wire. Otherwise the housing may carry high voltages which can cause electrical shock.



Do not touch electrical connections of the components when switched on.



Prior to accessing electrical parts carrying voltages exceeding 50 Volts, disconnect the device from the mains or power supply. Protect it from being switched on again.



For the installation the amount of DC bus voltage must be considered, particularly regarding insulation and protective measures. Ensure proper grounding, wire dimensioning and corresponding short-circuit protection.



The device comprises a rapid discharge circuit for the DC bus as per EN 60204-1. In certain device constellations, however, mostly in the case of parallel connection of several servo positioning controllers in the DC bus or in the case of an unconnected brake resistor, this rapid discharge may be rendered ineffective. The servo positioning controllers can carry voltage until up to 5 minutes after being switched off (residual capacitor charge).

2.4.4 Protection against electrical shock by means of protective extra-low voltage (PELV)

All connections and terminals with voltages of up to 50 Volts at the servo positioning controller are protective extra-low voltage, which are designed safe from contact in correspondence with the following standards:

- ❖ International: IEC 60364-4-41
- ❖ European countries within the EU: EN 61800-5-1

**DANGER!**

High electrical voltages due to wrong connections!

Danger to life, risk of injury due to electrical shock!

Only devices and electrical components and wires with a protective extra low voltage (PELV) may be connected to connectors and terminals with voltages between 0 to 50 Volts.

Only connect voltages and circuits with protection against dangerous voltages. Such protection may be achieved by means of isolation transformers, safe optocouplers or battery operation.

2.4.5 Protection against dangerous movements

Dangerous movements can be caused by faulty control of connected motors, for different reasons:

- ❖ Improper or faulty wiring or cabling
- ❖ Error in handling of components
- ❖ Error in sensor or transducer
- ❖ Defective or non-EMC-compliant components
- ❖ Software error in superordinated control system

These errors can occur directly after switching on the device or after an indeterminate time of operation.

The monitors in the drive components for the most part rule out malfunctions in the connected drives. In view of personal protection, particularly the danger of personal injury and/or property damage, this may not be relied on exclusively. Until the built-in monitors come into effect, faulty drive movements must be taken into account; their magnitude depends on the type of control and on the operating state.

**DANGER!**

Dangerous movements!

Danger to life, risk of injury, serious personal injuries or property damage!

For the reasons mentioned above, personal protection must be ensured by means of monitoring or superordinated measures on the device. These are installed in accordance with the specific data of the system and a danger and error analysis by the manufacturer. The safety regulations applying to the system are also taken into consideration. Random movements or other malfunctions may be caused by switching the safety installations off, by bypassing them or by not activating them.

2.4.6 Protection against contact with hot parts

**DANGER!**

Housing surfaces may be hot!

Risk of injury! Risk of burning!



Do not touch housing surfaces in the vicinity of heat sources! Danger of burning!



Before accessing devices let them cool down for 10 minutes after switching them off.



Touching hot parts of the equipment such as the housing, which contain heat sinks and resistors, may cause burns!

2.4.7 Protection during handling and assembly

Handling and assembly of certain parts and components in an unsuitable manner may under adverse conditions cause injuries.

**DANGER!**

Risk of injury due to improper handling!

Personal injury due to pinching, shearing, cutting, crushing!

The following general safety notes apply:



Comply with the general setup and safety regulations on handling and assembly.



Use suitable assembly and transportation devices.



Prevent incarcerations and contusions by means of suitable protective measures.



Use suitable tools only. If specified, use special tools.



Use lifting devices and tools appropriately.



If necessary, use suitable protective equipment (for example goggles, protective footwear, protective gloves).



Do not stand underneath hanging loads.



Remove leaking liquids on the floor immediately to prevent slipping.

3 Product description

3.1 General

The servo positioning controller ARS 2000 FS (ARS servo 2nd generation for **F**unctional **S**afety) series devices are intelligent AC servo inverters with substantial parameterisation possibilities and extension options. They are flexible and can be easily adapted to a number of different applications.

These servo positioning controllers are designed for receiving so-called FSM modules (**F**unctional **S**afety **M**odules). Thanks to their integrated safety features, external monitoring devices can be omitted for numerous applications.

The series includes types with single-phase and three-phase supply.

Type key:

Example using the ARS 2102 FS




Figure 1: Type key

The single-phase supply types are designed for connection to the 230 VAC mains and comprise an active PFC stage (**P**ower **F**actor **C**ontrol, with the ARS 2108 FS being an exception). The PFC stage is an active mains current converter required to fulfil the corresponding standards on the limitation of the mains harmonics (for category C2, residential areas).

The PFC stage also serves the active control of the DC bus voltage. The PFC stage works according to the boost operation principle and provides a nominal DC bus voltage of 380 VDC. This voltage is available regardless of the quality of the mains voltage and therefore also in the case of fluctuating main voltages or undervoltage. This is an important advantage regarding the selection of the servo motor, because, as compared to devices with a passive mains supply, higher rotational speeds can be achieved and/or higher torque constants can be selected.

Furthermore, due to the active PFC stage, the device is also suitable for varying voltage operation down to 100 VAC mains supply. However, the limitation of the active power input due to the allowed maximum current of the PFC stage must be taken into consideration in this case.

All servo positioning controller ARS 2000 FS series devices have the following features:

- ❖ Space-saving compact design, directly cascadable
- ❖ High quality of control due to extremely high-quality sensor technology, far superior to conventional market standards, and better than average computer resources
- ❖ Complete integration of all of the components for the controller and power module, including USB, Ethernet, and RS232 for the PC communication, plus CANopen for the integration into automation systems
- ❖ SD card: support of FW downloads (initialisation via boot switches) and uploads and downloads of parameter sets
- ❖ Integrated universal encoder evaluation for the following encoders:
 - Resolver
 - Incremental encoder with/without commutation signals
 - High-resolution Stegmann incremental encoders, absolute encoders with HIPERFACE®
 - High-resolution Heidenhain incremental encoders, absolute encoders with EnDat
- ❖ Compliance with current European regulations and associated standards without any additional external measures
- ❖ Device design as per UL standards, cULus certified
- ❖ Completely closed, EMC-optimized metal housing for mounting to conventional control cabinet plates. All devices comply with the IP20 degree of protection
- ❖ Integration of all filters to fulfil the EMC regulations (industrial) inside the device, for example line filter, motor output filter, filter for 24 V-supply as well as inputs and outputs
- ❖ Integrated brake resistor. External resistors can be connected for higher braking energies
- ❖ Automatic identification of externally connected brake resistors
- ❖ Complete galvanic separation of controller and power output stage as per EN 61800-5-1. Galvanic separation of the 24 V potential area with the digital inputs and outputs, analog electronics and the controller electronics
- ❖ Operation as speed controller, torque controller or positioning controller
- ❖ Integrated positioning control with wide range of functions as per CAN in Automation (CiA) DSP402 and numerous additional application-specific functions
- ❖ Jerk limit or time-optimal positioning relative or absolute to a point of reference
- ❖ Point-to-point positioning (with or without S-ramps)
- ❖ Speed and angle synchronisation with electronic gear system via incremental encoder input or fieldbus
- ❖ Extensive modes of operation for synchronisation
- ❖ Various methods for homing
- ❖ Jogging
- ❖ Teach-in mode

- ❖ Short cycle times, in current control circuit 50 µs (20 kHz), in speed control circuit 100 µs (10 kHz)
- ❖ Switchable clock frequency for the power output stage
- ❖ Freely programmable I/O's
- ❖ User-friendly parameterisation with the Metronix ServoCommander® software
- ❖ Menu-driven first set up
- ❖ Automatic motor identification
- ❖ Easy coupling to host controller, for example to a PLC via I/O level or fieldbus
- ❖ High-resolution 16-bit analog input
- ❖ Technology slots for extensions such as I/O extension module or PROFIBUS interface.
Note: Depending on the current consumption, only one technology module with an additional fieldbus interface may be used
- ❖ Option "STO" (Safe Torque Off, corresponds to EN 60204 Stop 0), SIL 3 in accordance with ISO EN 61800-5-2 / PL e in accordance with ISO EN 13849-1

3.2 Power supply

3.2.1 Single-phase AC supply with active PFC

The servo positioning controller ARS 2100 FS fulfils the following demands on a servo positioning controller with active PFC stage (with the ARS 2108 FS being an exception):

- ❖ Fulfilment of current standards regarding mains harmonics (EN 61000-3-2)
- ❖ $\cos\varphi^\circ > 0.97$ at nominal operation (at rated output power of the PFC stage)
- ❖ Sinusoidal mains current, harmonic distortion $< 4\%$ (at rated output power of the PFC stage)
- ❖ Controlled average value of DC bus voltage of 380 VDC
- ❖ Insensitive in the case of weak mains and short mains interruptions. In such cases the device maintains stable (within the physical possibilities) without malfunctions
- ❖ Wide input voltage range, rated voltage 230 VAC
- ❖ Frequency range nominal 50-60 Hz $\pm 10\%$
- ❖ Electrical impulse load capacity for possible combination of several servo positioning controllers. The servo positioning controller ARS 2100 FS allows dynamic conversion in both directions between motor and generator operation without dead times
- ❖ No parameterisation by user necessary

3.2.1.1 Behaviour during switch-on

- ❖ As soon as the servo positioning controller ARS 2100 FS is supplied with the input voltage, the DC bus is charged (< 1 s) using the brake resistor as a precharging resistor, the DC link relay deactivated. During this the PFC remains inactive
- ❖ After precharging of the DC bus the relay is energized and the DC bus is coupled hard to the mains power without the precharging resistor. Subsequently, the PFC stage is activated and the DC bus is boosted to the full DC bus voltage
- ❖ If the DC bus voltage after precharging is too small, because the input mains voltage is below the PFC operation input voltage range, the PFC stage remains inactive and an error message on the seven segment display is shown
- ❖ If the servo positioning controller ARS 2100 FS is supplied with less than the nominal voltage of 230 VAC, the actual DC bus voltage after the precharge is used to compute a power derating for the PFC stage (see *chapter 4.3 Supply [X9], page 42 and Figure 3*)

3.2.1.2 Behaviour during normal operation and control characteristics

- ❖ During operation the PFC stage controls the power input of the servo positioning controller ARS 2100 FS from the supply. Based on an analog closed-loop control the mains current is regulated to a sinusoidal waveform with a phase shift near to 0°. The effective amplitude is adjusted according to the demanded input power
- ❖ A superimposed digital closed-loop control adjusts the DC bus voltage to an average value close to 380 VDC. To relieve the voltage control that is relatively sluggish, during load changes (acceleration/deceleration of the drive) the output/input power delivered from the servo positioning controller ARS 2100 FS to the motor is measured and used for the pre-control of the PFC stage




Figure 2: Schematic setup of PFC stage

- ❖ The control system includes the following values:
 - digital control of the DC bus voltage to an average value of 380 VDC
 - analog control of the input mains current
 - Keeping of a sinusoidal mains current under stationary load conditions
 - $\cos\varphi > 0.97$ at nominal operation (at rated output power of the PFC stage)
- ❖ By use of the parameterisation program Metronix ServoCommander® the PFC stage (Parameters/Device parameters/PFC) can be switched on and off. With deactivated PFC the DC bus behaves like a normal DC bus with a rectifier bridge
- ❖ Under stationary load conditions the DC bus voltage is regulated to a constant average value, which is independent from the actual power transferred to the motor.

3.2.2 DC bus coupling, DC supply

3.2.2.1 DC bus coupling

- ❖ It is possible to couple multiple servo positioning controllers of the ARS 2100 FS series when they have the same DC bus voltage. For this purpose, the PFC stage has to be deactivated
- ❖ When they have the same DC bus voltage, the servo positioning controllers ARS 2100 FS can be coupled with the servo positioning controllers of the previous ARS and ARS 2000 series. For this, deactivation of the PFC stage is mandatory



Caution!

DC bus coupling is not allowed while the PFC stage is active. This can otherwise result in damages to the servo positioning controller.



Caution!

When the DC buses are connected, the power supplies must be connected to the same mains phase.

This means, if two ARS 2105 FS are coupled in the DC bus, only the connection L1/N is possible for both devices. It is not allowed to connect the DC Busses if the devices are connected to different mains phases.

It is forbidden to supply device 1 via L1/N and device 2 via L2/N, when the DC buses are coupled.



Caution!

Operation with DC bus coupling together with devices of the ARS 2300 FS series is not allowed.

3.2.2.2 DC supply

- ❖ The direct DC supply is supported for a supply with voltages ≥ 60 VDC by the DC-bus connection instead of the connection to the mains



The digital motor temperature measurement system requires a DC-link voltage of 120 VDC minimum. Below this voltage, the system will always identify the digital motor temperature sensor as open.

3.2.3 Mains fuse

A slow-blow (B16) single-phase automatic circuit breaker of 16 A has to be installed in the mains supply line.

3.3 Brake chopper

A brake chopper with a brake resistor is integrated into the power output stage. If during the generator operation the permissible charging capacity of the DC bus is exceeded, the braking energy can be converted into heat by the internal brake resistor. The brake chopper is software-driven. The internal brake resistor is overload-protected by means of software and hardware.

If in a special application the power of the internal resistors should be insufficient, they can be cut off by removing the bridge between the pin *BR-CH* and *BR-INT* of the [X9] plug. Instead, an external brake resistor is inserted between the pins *BR-CH* and *ZK+*. This brake resistor must fulfil certain minimum specifications (see *Table 12, page 42*). The output is protected against short-circuiting in the brake resistor or its cable.



Pin *BR-CH* lies on positive DC bus potential and is thus not protected against ground fault or short-circuits against mains voltage or negative DC bus voltages.

Simultaneous use of the internal and external brake resistors is not possible. The external resistors are not automatically overload-protected by the device.

3.4 Communication interfaces

The servo positioning controller ARS 2000 FS has several communication interfaces. The basic device itself is already equipped with many of these interfaces.

The following communication interfaces are included in the basic device:

- ❖ Serial interface [X5]: RS232/RS485
- ❖ USB interface [X19]: USB
- ❖ UDP interface [X18]: Ethernet
- ❖ Fieldbus system [X4]: CANopen
- ❖ I/O interface [X1]: Digital and analog In- and outputs

The serial, Ethernet, and USB interface are particularly important for the connection of a PC and for the use of the Metronix ServoCommander[®] parameterisation tool.

The fieldbus systems PROFIBUS-DP, Sercos and EtherCAT are extension options that can be implemented in the form of plug-in modules. If required, customer-specific fieldbus protocols can also be realised.

In any case, the servo positioning controller of this design always works as a slave to the fieldbus.

3.4.1 Serial interface [X5]

The RS232 protocol is mainly intended to be a parameterisation interface, but also allows the control of the servo positioning controller ARS 2000 FS.

3.4.2 USB interface [X19]

This interface, too, was mainly intended as a parameterisation interface, but it can also be used for controlling the ARS 2000 FS servo positioning controller.

3.4.3 UDP interface [X18]

The UDP communication enables the connection of the ARS 2000 FS servo positioning controller to the Ethernet fieldbus system. The communication via the UDP interface [X18] is realised with the aid of a standard cabling.

3.4.4 CAN interface [X4]

The CANopen protocol as per DS301 with application profile DSP402 is implemented.



The specific Metronix CAN protocol of the previous ARS devices is no longer supported by the ARS 2000 FS series. The servo positioning controller ARS 2000 FS supports the CANopen protocol as per DS301 with application profile DSP402.

3.4.5 Technology module: PROFIBUS

Support of PROFIBUS communication as per DP-V0. For drive technology applications the functions as per PROFIDRIVE Version 3.0 are available. The features include functions as per Application Class 1 (speed and torque control) as well as per Application Class 3 (point-to-point positioning).

It is also possible to include the device into control systems via an I/O mapping via PROFIBUS. From a control point of view, this option offers the same functionality as a conventional PLC coupling via parallel wiring with the device's digital I/Os.

Via a special Metronix telegram it is also possible to access all device-specific functions, exceeding the functionality defined by PROFIDRIVE.



The Metronix PROFIBUS-profile of the previous ARS series is no longer supported by the ARS 2000 FS series.

3.4.6 Technology module: Sercos II

The Sercos II interface is a slave fieldbus module that enables the use of the ARS 2000 FS servo positioning controllers in numerically-controlled, highly dynamic drive applications, for example in machine tools. The Sercos II interface enables the position, speed, or torque control in accordance with the functionality of the compliance classes A and B.

The connected module is automatically identified. Since the data exchange between the CNC system and the controller is realised via optical fibre cables, mutual interference can be avoided. The drive address is set, and the bus is activated, via the Metronix ServoCommander® parameterisation tool. The transmission rate can be set to a value between 2 and 16 Mbit/s.

3.4.7 Technology module: EtherCAT

The EtherCAT interface enables the connection of the ARS 2000 FS servo positioning controller to the EtherCAT fieldbus system. The communication via the EtherCAT interface (IEEE-802.3u) is realised with the aid of EtherCAT standard cabling.

3.4.8 I/O functions and device control

Ten digital inputs provide the elementary control functions (see *chapter 4.6.6 I/O interface [X1]*, page 55):

The ARS 2000 FS comprises a target table, in which the positioning targets are stored and from which they can later be retrieved. At least four digital inputs serve the purpose of target selection; one input is used as a start input.

The limit switches serve the safety limitation of the motion space. During a homing one of the two limit switches may serve as a reference point for the positioning control.

Two inputs are used for the power stage enabling on the hardware side as well as for the controller enabling on the software side.

High-speed sample inputs are available for different time-critical applications (for example homing, special applications).

The servo positioning controller ARS 2000 FS has three analog inputs for input levels in the range of $+10V$ to $-10V$. One input is designed as a differential input (16 bit), to guarantee high interference immunity. Two inputs (10 bit) are single-ended. The analog signals are quantized and digitalized by an analog-digital converter at a resolution of 16 bit or 10 bit. The analog signals provide the setpoints (speed or torque) for the control.

In common applications the existing digital inputs are already used for basic functions. For the use of further functions such as teach-in mode, separate “start homing” input or stop input, the analog inputs AIN 1, AIN 2 as well as the digital outputs DOUT 2 and DOUT 3, which are also usable as digital inputs, can optionally also be used. Alternatively the I/O extension module EA88 can be inserted.

4 Technical data

4.1 General Technical data

Table 5: Technical data: Ambient conditions and qualification

Range	Values
Admissible temperature ranges	Storage temperature: -25 °C to +70 °C
	Operating temperature: 0 °C to +40 °C
	+40 °C to +50 °C at reduced power 2,5 %/K
Admissible installation height	Mounting height maximum 2000 m above msl, above 1000 m above msl with power reduction 1% per 100 m
Humidity	Relative humidity up to 90 %, not bedewing
Protection degree	IP20
Protection class	I
Pollution degree	2
CE conformity Low-voltage directive:	2006/95/EC verified by application of the harmonised standard EN 61800-5-1
EMC directive:	2004/108/EC verified by application of the harmonised standard EN 61800-3
cULus certification	Listed according to UL 508C, C22.2 No. 274-13

Table 6: Technical data: Dimensions and weight

Type	ARS 2102 FS	ARS 2105 FS	ARS 2108 FS
Dimensions including the mounting plate (H*W*D)	261 mm*54,6 mm*205 mm		
Dimensions (H*W*D)	200 mm*54 mm*200 mm		
Weight	approx. 2,0 kg	approx. 2,1 kg	approx. 1,8 kg

Table 7: Technical data: Cable specifications

Range	ARS 2102 FS	ARS 2105 FS	ARS 2108 FS
Maximum motor cable length for interference emission as per EN 61800-3 for $f_{PWM} \leq 10$ kHz			
Category C2 Switch cabinet assembly (see <i>chapter 8.14 Notes on safe and EMC-compliant installation</i>)	$l \leq 25$ m		
Category C3 (industrial area)	$l \leq 25$ m		
Cable capacity of a phase against shield or between two lines	$C' \leq 200$ pF/m		
Derating of the cable length (see also <i>chapter 8.14.5 Operation with long motor cables</i>)			
$f_{PWM} = 12$ kHz	$l \leq 21$ m		
$f_{PWM} = 16$ kHz	$l \leq 15$ m		
$f_{PWM} = 20$ kHz	$l \leq 12$ m		

Table 8: Technical data: Motor temperature monitoring

Motor temperature monitoring	Values
Digital Sensor	Normally closed contact: $R_{cold} < 500 \Omega$ $R_{hot} > 100 k\Omega$
Analog Sensor	Silicon temperature sensor, for example KTY81, 82 or similar $R_{25} \approx 2000 \Omega$ $R_{100} \approx 3400 \Omega$

4.2 Operating and display elements

On the front the servo positioning controller ARS 2100 FS has two LEDs and one seven-segment display to indicate the operating status.

Table 9: Display elements and RESET button

Element	Function
Seven segment display	Display of operating mode and a coded error number in the case of a malfunction
LED 1 (two-color LED, green/red)	Operational state respectively fault
LED 2 (green)	Controller enable
LED 3 (yellow)	Status display CAN bus
RESET-Button	Hardware reset for processor

4.3 Supply [X9]

Table 10: Technical data: Performance data [X9]

Type	ARS 2102 FS	ARS 2105 FS	ARS 2108 FS
Supply voltage	1 x 100 ... 230 VAC [$\pm 10\%$], 50 ... 60 Hz		
In continuous operation maximum of mains current	2,4 A _{RMS}	4,7 A _{RMS}	10 A _{RMS}
Intermediate circuit voltage (at an operating voltage of 230 VAC)	310 ... 320 VDC (without PFC) 360 ... 380 VDC (with active PFC)		310 ... 320 VDC
Alternative DC supply	60 ... 380 VDC		60 ... 320 VDC
24 V supply	24 VDC [$\pm 20\%$] (0,55 A) ^{*)}	24 VDC [$\pm 20\%$] (0,65 A) ^{*)}	

^{*)} plus current consumption of a possibly connected holding brake and I/Os

Table 11: Technical data: Internal brake resistor [X9]

Type	ARS 2102 FS	ARS 2105 FS	ARS 2108 FS
Brake resistance	60 Ω	60 Ω	37 Ω
Pulse power	2,8 kW	2,8 kW	3,9 kW
Continuous power	10 W	20 W	25 W
Threshold limit (without PFC) (with active PFC)	389 V 440 V	389 V 440 V	389 V (no PFC)
Over-current detection (without PFC) (with active PFC)	400 V 460 V	400 V 460 V	400 V (no PFC)


Table 12: Technical data: External brake resistor [X9]

Type	ARS 2102 FS	ARS 2105 FS	ARS 2108 FS
Break resistance	$\geq 50\ \Omega$	$\geq 50\ \Omega$	$\geq 25\ \Omega$
Continuous power	$\leq 2500\ \text{W}$		
Operating voltage	$\geq 460\ \text{V}$	$\geq 460\ \text{V}$	$\geq 400\ \text{V}$

Table 13: Performance data of PFC stage

Type	ARS 2102 FS	ARS 2105 FS
For a nominal supply voltage of 230 VAC [$\pm 10\%$]:		
Continuous power output	500 W	1000 W
Peak power output	1000 W	2000 W

Below the nominal supply voltage, the power output of the PFC stage is reduced linearly. These performance curves are shown in the following figure (*Figure 3: Performance curve of the PFC stage*).


Figure 3: Performance curve of the PFC stage

4.4 Motor connection [X6]

Table 14: Technical data: Motor connection [X6]

Type	ARS 2102 FS	ARS 2105 FS	ARS 2108 FS
Specifications for operation with 1x 230 VAC [$\pm 10\%$], 50 Hz			
Output power	0,5 kVA	1,0 kVA	1,5 kVA
Max. output power for 5s	1,0 kVA	2,0 kVA	3,0 kVA
Output current	2,5 A _{RMS}	5 A _{RMS}	8 A _{RMS}
Max. output current for 5s	5 A _{RMS}	10 A _{RMS}	16 A _{RMS}
Max. output current 0,5s	10 A _{RMS}	20 A _{RMS}	32 A _{RMS} ($f_{el} \geq 3\text{ Hz}$ *)
Current derating from	12 kHz	12 kHz	10 kHz
Max. clock frequency	approx. 20 kHz		
Holding brake 24 V	Signal level dependent on switch status, high side / low side switch / max. 2 A		
Motor temperature sensor	N.C. and N.O. contact, PTC, KTY ... + 3,3 V / 5 mA		
Power loss/efficiency (with regard to the rated output power)**)	typical 8% / 92%		

*) with smaller electrical rotational frequencies (f_{el}) shorter permissible times are valid with ARS 2108 FS; see the following tables

**) "As a guideline".

4.4.1 Current derating

Differently from the indicated technical motor data the servo positioning controllers ARS 2100 FS have a current derating during nominal operation. The rated current and the time of the maximum allowed peak current of the servo positioning controller depend on different factors.

These factors are:

- ❖ Output current level (the higher the output current, the shorter the allowed time)
- ❖ Power stage clock frequency (the higher the clock frequency, the shorter the allowed time)
- ❖ Electrical rotational frequency of the motor (speed multiplied by pole pair number; the higher the rotational frequency, the longer the allowed time)

The last point (electrical rotational frequency) only applies to the ARS 2108 FS. For a better clarity, we only distinguish between electrical rotational frequencies less than 2 Hz and those over 3 Hz. For rotational frequencies lying in between these two values, interpolation is required.

Therefore, in the following you will find two tables for the ARS 2108 FS: the first one applies to blocked or slowly rotated motors (electrical rotational frequency ≤ 2 Hz); the second one applies to faster rotated motors (electrical rotational frequency ≥ 3 Hz).

Table 15: ARS 2102 FS: Rated current for an ambient temperature of $\leq 40\text{ }^{\circ}\text{C}$

Parameter	Values		
Power stage clock frequency (kHz)	≤ 12		
Output current (A_{RMS})	2,5		
Max. output current (A_{RMS})	5	7,5	10
Max. allowed time (s)	5	1,3	0,5
Power stage clock frequency (kHz)	16		
Output current (A_{RMS})	2,2		
Max. output current (A_{RMS})	4,4	6,6	8,8
Max. allowed time (s)	5	1,3	0,5
Power stage clock frequency (kHz)	19		
Output current (A_{RMS})	1,9		
Max. output current (A_{RMS})	3,8	5,7	7,6
Max. allowed time (s)	5	1,3	0,5

Table 16: ARS 2105 FS: Rated current for an ambient temperature of $\leq 40\text{ }^{\circ}\text{C}$

Parameter	Values		
Power stage clock frequency (kHz)	≤ 12		
Output current (A_{RMS})	5		
Max. output current (A_{RMS})	10	15	20
Max. allowed time (s)	5	1,3	0,5
Power stage clock frequency (kHz)	16		
Output current (A_{RMS})	4,4		
Max. output current (A_{RMS})	8,8	13,2	17,6
Max. allowed time (s)	5	1,3	0,5
Power stage clock frequency (kHz)	19		
Output current (A_{RMS})	3,7		
Max. output current (A_{RMS})	7,4	11,1	14,8
Max. allowed time (s)	5	1,3	0,5

Table 17: ARS 2108 FS: Rated current for blocked or slowly rotated servo motor (f_{el}) ≤ 2 Hz and for an ambient temperature of ≤ 40 °C

Parameter	Values		
Power stage clock frequency (kHz)	≤ 10		
Output current (A_{RMS})	8		
Max. output current (A_{RMS})	16	24	32
Max. allowed time (s)	5	0,7	0,2
Power stage clock frequency (kHz)	12		
Output current (A_{RMS})	7,4		
Max. output current (A_{RMS})	14,8	22,2	29,6
Max. allowed time (s)	5	0,7	0,2
Power stage clock frequency (kHz)	16		
Output current (A_{RMS})	6,3		
Max. output current (A_{RMS})	12,6	18,9	25,2
Max. allowed time (s)	5	0,7	0,2
Power stage clock frequency (kHz)	19		
Output current (A_{RMS})	5,2		
Max. output current (A_{RMS})	10,4	15,6	20,8
Max. allowed time (s)	5	0,7	0,2

Table 18: ARS 2108 FS: Rated current for rotated servo motor (f_{el}) ≥ 3 Hz and for an ambient temperature of ≤ 40 °C

Parameter	Values		
Power stage clock frequency (kHz)	≤ 10		
Output current (A_{RMS})	8		
Max. output current (A_{RMS})	16	24	32
Max. allowed time (s)	5	1,3	0,5
Power stage clock frequency (kHz)	12		
Output current (A_{RMS})	7,4		
Max. output current (A_{RMS})	14,8	22,2	29,6
Max. allowed time (s)	5	1,3	0,5
Power stage clock frequency (kHz)	16		
Output current (A_{RMS})	6,3		
Max. output current (A_{RMS})	12,6	18,9	25,2
Max. allowed time (s)	5	1,3	0,5
Power stage clock frequency (kHz)	19		
Output current (A_{RMS})	5,2		
Max. output current (A_{RMS})	10,4	15,6	20,8
Max. allowed time (s)	5	1,3	0,5

4.5 Motor feedback connection [X2A] and [X2B]

Different feedback systems can be connected to the servo positioning controller ARS 2100 FS via the universal encoder interface:

- ❖ Resolver (interface [X2A])
- ❖ Encoder (interface [X2B])
 - Incremental encoders with analog and digital track signals
 - SinCos encoder (single-turn/multi-turn) with HIPERFACE
 - Multiturn absolute encoder with EnDat

The encoder type is determined in the Metronix ServoCommander® parameterisation software.

The feedback signal is available via the incremental encoder output [X11] for master-slave applications.

It is possible to evaluate two shaft encoder systems in parallel. Typically, the resolver for the current control is connected to [X2A], and for example an absolute encoder is connected to [X2B] as a feedback system for the positioning control.

4.5.1 Resolver connection [X2A]

The 9-pin D-SUB connection [X2A] is used to evaluate standard resolvers. Single- and multi-pole resolvers are supported. The user can state the number of pairs of poles of the servo motor in the "Motor Data" menu of the Metronix ServoCommander[®] parameterization program so that the ARS 2100 FS determines the speed correctly. However, the number of pairs of poles can also be identified automatically. The number of pairs of poles of the motor (P_{0Motor}) is always an integer multiple of the number of pairs of poles of the resolver ($P_{0Resolver}$). Wrong combinations such as, for example, $P_{0Resolver} = 2$ and $P_{0Motor} = 5$ lead to an error message during motor identification.

The resolver offset angle, which is determined automatically during the identification, is readable and writeable for service purposes.

Table 19: Technical data: Resolver [X2A]

Parameter	Values
Transformation ratio	0,5
Carrier frequency	5 to 10 kHz
Excitation voltage	7 V _{RMS} , short circuit-proof
Impedance excitation (at 10kHz)	$\geq (20 + j20) \Omega$
Impedance stator	$\leq (500 + j1000) \Omega$

Table 20: Technical data: Resolver interface [X2A]

Parameter	Values
Resolution	16 Bit
Delay time signal detection	< 200 μ s
Speed resolution	approximately 4 min ⁻¹
Absolute accuracy of angle detection	< 5'
Max. rotational speed	16.000 min ⁻¹

4.5.2 Encoder connection [X2B]

At the 15-pole D-Sub connection [X2B], motors with encoder can be fed back. The possible incremental encoders for the encoder connection are divided into several groups. If you want to use other types of encoders, please contact your sales representative.

Table 21: Technical data: Encoder evaluation [X2B]

Parameter	Values
Parameterisable number of encoder lines	1 - 2 ¹⁸ lines/revolution
Angular resolution / Interpolation	10 Bit/period
Encoder signals A, B	1 V _{PP} differential; 2.5 V offset
Encoder signal N	0.2 to 1 V _{PP} differential; 2.5 V offset
Commutation track A1, B1 (optional)	1 V _{PP} differential; 2.5 V offset
Input impedance encoder signals	Differential input 120 Ω
Limit frequency	f _{Limit} > 300 kHz (high-resolution signal) f _{Limit} approximately 10 kHz (commutation track)
Additional communication interface	EnDat (Heidenhain) and HIPERFACE® (Sick-Stegmann)
Output supply	5 V or 12 V; max. 300 mA; current-limited control via sensor lines Setpoint programmable via SW

Standard incremental encoders without commutation signals:

This type of encoder is used with low-cost linear motor applications, to save the costs for the provision of the commutation signals (hall sensor). With this type of encoder the servo positioning controller ARS 2100 FS must carry out an automatic pole position determination after power-on.

Standard incremental encoders with commutation signals:

These are standard incremental encoders with three binary hall sensor signals. The number of lines of the encoder can be freely parameterized (1 – 2¹⁴ lines/rotation).

There is an additional offset angle for the hall sensor signals. It is determined during motor identification or can be set via the parameterisation software Metronix ServoCommander®. In general, the hall sensor offset angle is zero.

Sick-Stegmann encoders:

Single-turn and multi-turn shaft encoders with HIPERFACE[®] made by Sick-Stegmann are supported. The following series of encoders can be connected:

- ❖ Singleturn SinCos encoders: SCS 60/70, SKS 36, SRS 50/60/64, SEK 37/52
- ❖ Multiturn SinCos encoders: SCM 60/70, SKM 36, SRM 50/60/64, SEL 37/52
- ❖ Singleturn SinCos Hollow shaft encoders: SCS-Kit 101, SHS 170, SCK 25/35/40/45/50/53
- ❖ Multiturn SinCos Hollow shaft encoders: SCM-Kit 101, SCL 25/35/40/45/50/53

In addition, the following Sick Stegmann encoder systems can be connected and evaluated:

- ❖ Absolute, non-contact length measuring system L230 and TTK70 (HIPERFACE[®])
- ❖ Digital incremental encoder CDD 50



SinCoder[®] encoders like SNS 50 or SNS 60 are no longer supported.

Heidenhain encoders:

Incremental and absolute encoders by Heidenhain are evaluated. The following series of encoders can be connected:

- ❖ Analog incremental encoders: ROD 400, ERO 1200/1300/1400, ERN 100/400/1100/1300
- ❖ Singleturn absolute encoders (EnDat 2.1/2.2): ROC 400, ECI 1100/1300, ECN 100/400/1100/1300
- ❖ Multiturn absolute encoders (EnDat 2.1/2.2): ROQ 400, EQI 1100/1300, EQN 100/400/1100/1300
- ❖ Absolute length measuring system (EnDat 2.1/2.2): LC 100/400

Yaskawa encoders:

Digital incremental encoders with zero-pulse [Σ (sigma 1), Yaskawa-OEM-protocol] made by Yaskawa are supported.

4.6 Communication interfaces

4.6.1 RS232 [X5]

Table 22: Technical data: RS232 [X5]

Communication interface	Values
RS232	As per RS232 specification, 9600 Baud to 115.2 kBaud

4.6.2 USB [X19]

Table 23: Technical data: USB [X19]

Communication interface	Values
Function	USB 2.0, Slave–Client, 12 MBaud to 480 MBaud
Connector type	USB-B, no current consumption from the bus (integrated power supply)
Communication protocol	Metronix specific (generic device)

4.6.3 Ethernet [X18]

Table 24: Technical data: Ethernet [X18]

Communication interface	Values
Function	Ethernet, 10/100 MBaud (auto select)
Connector type	RJ45

4.6.4 CAN bus [X4]

Table 25: Technical data: CAN bus [X4]

Communication interface	Values
CANopen controller	ISO/DIS 11898, full CAN controller, max. 1 Mbaud
CANopen protocol	as per DS301 and DS402

4.6.5 SD/MMC card

Table 26: Technical data: SD/MMC card

Communication interface	Values
Card type	SD, SDHC and MMC
File system	FAT12, FAT16 and FAT32

4.6.6 I/O interface [X1]

Table 27: Technical data: Digital inputs and outputs [X1]

Digital inputs/outputs	Values	
Signal level	24 V (8 V ... 30 V) active high, conforming with DIN EN 61131-2	
Logic inputs general		
DIN 0	Bit 0 \ (lsb → least significant bit)	
DIN 1	Bit 1, \ Target selection for positioning	
DIN 2	Bit 2, / 16 targets selectable from target table	
DIN 3	Bit 3 / (msb → most significant bit)	
DIN 4	Control input power stage (enable at High)	
DIN 5	Controller enable at high signal, acknowledge error with falling edge	
DIN 6	Limit switch input 0	
DIN 7	Limit switch input 1	
DIN 8	Control signal Start positioning or Homing switch for homing or saving of positions	
DIN 9	Control signal Start positioning or Homing switch for homing or saving of positions	
Logic outputs general	Galvanically separated, 24 V (8 V ... 30 V) active high	
DOUT 0	Operational state	24 V, max. 100 mA
DOUT 1	Freely configurable	24 V, max. 100 mA
DOUT 2	Freely configurable, optional use as input DIN 10	24 V, max. 100 mA
DOUT 3	Freely configurable, optional use as input DIN 11	24 V, max. 100 mA
DOUT 4 [X6]	Holding brake	24 V, max. 1 A

Table 28: Technical data: Analog inputs and outputs [X1]

Analog inputs/outputs	Values	
High-resolution analog input, AIN 0	± 10 V input range, 16 Bit, differentially, < 250 μ s delay time	
Analog input, AIN 1	Optionally, this input can also be parameterized as digital input DIN AIN 1 with a switching threshold at 8 V	± 10 V, 10 Bit, single ended, < 250 μ s delay time
Analog input, AIN 2	Optionally, this input can also be parameterized as digital input DIN AIN 2 with a switching threshold at 8 V	± 10 V, 10 Bit, single ended, < 250 μ s delay time
Analog outputs, AOUT 0 and AOUT 1	± 10 V output range, 10 mA, 9 bit resolution, $f_{\text{Limit}} > 1$ kHz	

4.6.7 Incremental encoder input [X10]

The input supports all common incremental encoders.

For example encoders corresponding to the industry standard ROD426 by Heidenhain or encoders with single-ended TTL outputs as well as open collector outputs.

Alternatively, the A and B encoder signals are interpreted by the device as pulse-direction signals, so that the controller can also be driven by stepping motor control boards.

Table 29: Technical data: Incremental encoder input [X10]

Parameter	Values
Parameterisable line count	$1 - 2^{28}$ lines/revolution
Trace signals: A, #A, B, #B, N, #N	In accordance with RS422 specification
Max. input frequency	1000 kHz
Pulse direction interface: CLK, #CLK, DIR, #DIR, RESET, #RESET	In accordance with RS422 specification
Supply output	5 V, 100 mA max.

4.6.8 Incremental encoder output [X11]

The output provides incremental encoder signals for processing in superimposed controls.

The signals are generated from the encoder's angle of rotation with a freely programmable number of lines.

Besides the encoder signals A and B, the emulation also provides a reset pulse, which goes to high once per rotation (for the programmed number of lines), for the duration of a $\frac{1}{4}$ signal period (as long as the encoder signals A and B are high).

Table 30: Technical data: Incremental encoder output [X11]

Parameter	Values
Number of lines	Programmable $1 - 2^{13}$ and 2^{14} lines/revolution.
Connection level	Differential / RS422 specification
Encoder signals A, B, N	As per RS422 specification
speciality	N-Trace disconnectable
Output impedance	$R_{a,diff} = 66 \Omega$
Limit frequency	$f_{Limit} > 1,8 \text{ MHz (lines/s)}$
Edge sequence	Can be limited by parameters
Output supply	5 V, max. 100 mA

5 Function overview

5.1 Motors

5.1.1 Synchronous servo motors

Typically, permanently excited synchronous motors with sinusoidal EMF are used. The servo positioning controller ARS 2100 FS is a universal servo positioning controller, which can be operated with standard servo motors. The motor specifications are determined and parameterized by means of an automatic motor identification.

5.1.2 Linear motors

Besides rotary applications, the servo positioning controllers ARS 2100 FS are also suitable for linear drives. Here also, permanently excited synchronous linear motors are supported. Due to the high signal processing quality, the ARS 2000 FS series is particularly suitable for driving air-core and iron-core synchronous motors with low motor inductances (2 ... 4 mH).

5.2 Functions of the servo positioning controller ARS 2100 FS

5.2.1 Compatibility

For compatibility reasons, from the user's point of view, the control structure of the ARS 2100 FS has mostly the same characteristics, interfaces and parameters as the previous ARS family.




Figure 4: Control scheme of the ARS 2100 FS

Figure 4 shows the basic control structure of the ARS 2100 FS. Current controller, speed controller and positioning controller are arranged in a cascade. Due to the rotor-oriented control principle the current can be set separated in active current (i_q) and reactive current (i_d). Therefore there are two current controllers, both of them PI controllers. To provide a better overview, however, the i_d controller does not appear in Figure 4.

The planned basic modes of operation are torque control, speed control and positioning.

Functions such as synchronisation, “flying saw” and so on are variants of these basic modes of operation.

Furthermore, individual functions of these modes of operation can be combined with each other, for example torque control with speed limitation.

5.2.2 Pulse width modulation (PWM)

The servo positioning controller ARS 2100 FS is able to vary the clock frequency in the current controller circuit.

In most cases the settings can be made using the parameterisation software Metronix ServoCommander®. In order to minimize switching losses, the clock of the pulse width modulation can be cut in half as compared to the frequency in the current controller circuit.

The servo positioning controller ARS 2100 FS also features a sine modulation or alternatively a sine modulation with third harmonic. This increases the effective converter output voltage. The type of modulation can be selected via the Metronix ServoCommander®. The default setting is sine modulation.

Table 31: Output voltage at the motor terminals in the case of a DC bus circuit voltage (U_{ZK}) of 360 V

Output voltage converter	Output voltage at the motor terminals
$U_{out,(sin)}$	$U_{LL,motor} = \text{approx. } 210 \text{ V}_{RMS}$
$U_{out,(sin+sin3x)}$	$U_{LL,motor} = \text{approx. } 235 \text{ V}_{RMS}$

5.2.3 Setpoint management

For speed controlled and torque controlled modes of operation, the setpoint can be set via a setpoint management.

Possible setpoint sources are:

- ❖ 3 analog inputs:
 - AIN 0, AIN 1 and AIN 2
- ❖ 3 fixed values:
 - 1st value: setting depending on controller enabling logic:
 - fixed value 1 or
 - RS232 interface or
 - CANopen bus interface or
 - PROFIBUS-DP interface or
 - Sercos interface
 - 2nd and 3rd value: setting of fixed values 2 and 3
- ❖ Process controller
- ❖ SYNC input
- ❖ Additional incremental encoder input [X10]



If no setpoint source is activated, the setpoint is zero.

The setpoint management has a ramp generator with a preceding adder. Any of the above-mentioned setpoint sources can be selected via the corresponding selectors and run through the ramp generator. Additional sources can be selected as setpoints using two more selectors. These, however, cannot be run through the ramp generator. The total setpoint is then a summation of all values. The acceleration and deceleration times of the ramp are directionally parameterisable.

5.2.4 Torque-controlled mode

In torque control mode a certain setpoint torque is set, which the servo positioning controller generates in the motor. In this case only the current controller is activated, since the torque is proportional to the motor current.

5.2.5 Speed-controlled mode

This mode of operation is used, if the motor speed is to be kept constant regardless of the acting load. The motor speed exactly follows the speed set by the setpoint management.

The cycle time of the speed control loop for the servo positioning controller ARS 2100 FS is twice the PWM period duration, thus typically 208,4 μ s. However, it can also be set as an integer multiple of the current controller cycle time.

The speed controller is a PI controller with an internal resolution of 12 bits per rpm. In order to eliminate wind-up effects, the integrator function is stopped upon reaching subsidiary limitations.

In speed control mode only the current controller and the speed controller are active. In the case of setting via analog setpoint inputs it is optionally possible to define a "safe zero". If the analog setpoint is within this range, the setpoint is then set to zero ("dead zone"). This can suppress interferences or offset drifts. The function of a dead zone can be activated and deactivated and the width can be set.

The setpoints of the speed as well as the actual position are generally determined from the encoder system inside the motor, which is also used for commutation. For the actual value feedback to the speed control any encoder interface may be selected (for example reference encoder or corresponding system at external incremental encoder input). The actual speed value for the speed controller is then fed back for example via the external incremental encoder input.

The setpoint for the speed can also be set internally or can be derived from the data of an external encoder system (speed synchronisation via [X10] for speed controller).

5.2.6 Torque-limited speed control

The servo positioning controllers ARS 2100 FS support torque-limited speed-controlled operation with the following features:

- ❖ Fast updating of the limit value, for example in 200 µs cycle
- ❖ Addition of two sources of limitation (for example for servo control values)

5.2.7 Synchronization to the external clock signal

The controllers work with sinusoidal constrained current operation. The cycle time is always bound to the PWM frequency. In order to synchronise the current control to the external clock signal (for example Sercos, CANopen, EtherCAT) the device has a corresponding PLL. Accordingly the cycle time varies within certain limits, to allow synchronisation to the external clock signal. For synchronisation to an external clock signal the user must enter the rated value of the synchronous cycle time.

5.2.8 Load torque compensation for vertical axes

For vertical axis applications, the holding torque at standstill can be determined and stored.

It is then added to the torque control loop and improves the start-up behaviour of the axes after releasing the holding brake.

5.2.9 Positioning and position control

In positioning mode a superordinated positioning controller is active in addition to the speed control, which processes deviation of the actual position from the set position and converts it into the corresponding setpoints for the speed controller.

The position controller is a P-controller. By default, the cycle time of the position control circuit is twice the speed controller cycle time. However, it can also be set as an integer multiple of the speed controller cycle time.

When the positioning controller is activated, it receives its setpoints from the positioning or from the synchronisation controller. The internal resolution is up to 32 bits per motor revolution (depending on the used encoder).

5.2.10 Synchronisation, electronic gearing

The servo positioning controller ARS 2100 FS allows master-slave operation, which in the following will be called synchronisation. The controller can serve as master or slave.

If the servo positioning controller ARS 2100 FS is the master, it can provide the slave with its current rotor position at the incremental encoder output [X11].

With this information the slave can determine the current position and/or speed of the master via the incremental encoder input [X10]. Of course it is also possible to derive this information needed for the slave via an external encoder [X2B].

The synchronisation can be activated or deactivated via communication interfaces or via digital inputs.

The speed feed forward can be calculated by the servo positioning controller ARS 2100 FS itself. All inputs can be activated/deactivated. The internal encoder can optionally be shut off, if another input is selected as actual-value encoder. This also applies to speed control mode. The external inputs can be weighed with transmission factors. The different inputs can be used individually or simultaneously.

5.2.11 Brake management

The servo positioning controller ARS 2100 FS can directly actuate a holding brake. The holding brake is operated with programmable delay times. In positioning mode an additional automatic braking function can be activated, which shuts down the power stage of the ARS 2100 FS after a parameterized idle time and which lets the brake fall in. This mode of operation is compatible with the functions of the previous ARS and ARS 2000 series of devices.

5.3 Positioning control

5.3.1 Overview

In positioning mode a certain position is set, which is to be approached by the motor. The current position is derived from the information provided by the internal encoder evaluation. The position deviation is processed in the position controller and is passed on to the speed controller.

The integrated positioning control allows jerk-limited or time-optimal positioning relative or absolute to a point of reference. It provides the position controller and - to improve the dynamics - the speed controller also, with the setpoints.

In the case of absolute positioning a set target position is directly approached. In the case of relative positioning a parameterized route is run. The positioning space of 2^{32} full revolutions allows any number of relative positioning in one direction.

The positioning control is parameterized via a target table. The target table includes entries for the parameterisation of a target via a communication interface and also target positions, which can be retrieved via the digital inputs. For each entry it is possible to set the positioning method, the driving profile, the acceleration and the deceleration times as well as the maximum speed. All targets can be pre-parameterized. The only thing to do for positioning is then to select an entry and start the action. It is also possible to change the target parameters online via the communication interface.

The servo positioning controller ARS 2100 FS provides 256 configurable positioning sets.

The following settings are possible for all positioning sets:

- ❖ Target position
- ❖ Driving speed
- ❖ Final speed
- ❖ Acceleration
- ❖ Deceleration
- ❖ Torque feed forward
- ❖ Remaining distance trigger
- ❖ Additional flags:
 - Relative / relative to last target / absolute
 - Wait for end / interrupt / ignore start
 - Synchronized
 - Rotary axis
 - Option: automatic deceleration in case of missing following positioning
 - Different options on the setup of path programs

The positioning sets can be activated via all bus systems or via the parameterisation software Metronix ServoCommander®. The positioning process can be controlled via digital inputs.

5.3.2 Relative positioning

In the case of relative positioning, the target position is added to the current position. Since no fixed zero is required, referencing is not compulsory. It does, however, make sense in many cases, in order to bring the drive to a defined position.

Adding of relative positionings allows for example endless positioning in one direction for a trimming unit or a conveyor belt (incremental dimension).

5.3.3 Absolute positioning

The target position is approached independent of the current position. In order to execute an absolute positioning we recommend prior referencing of the drive. In the case of absolute positioning the target position is a fixed (absolute) position referred to the zero or reference point.

5.3.4 Driving profile generator

Driving profiles are categorized in time-optimal and jerk-limited positioning. In the case of time-optimal positioning the maximum set acceleration is used for starting and braking. The drive approaches the target in the shortest time possible, the velocity profile is trapezoidal, and the acceleration profile is block-shaped.

In the case of jerk-limited positioning the acceleration profile is trapezoidal and the velocity profile is therefore of third order. Since the acceleration changes continuously, the drive is extremely gentle on the mechanics.




Figure 5: Driving profiles of servo positioning controller ARS 2100 FS

5.3.5 Homing

Every positioning control requires a defined zero at start-up, which is determined by means of a homing. The servo positioning controller ARS 2100 FS can do this homing on its own. As reference signals it evaluates different inputs, for example the end switch inputs.

A homing can be started by means of a command via the communication interface or automatically with the controller enabling. Optionally a start via a digital input can be programmed using the parameterisation program Metronix ServoCommander®, to carry out a specific homing independent of the controller enabling. The controller enabling acknowledges (with falling edge) for example error messages and can be switched off depending on the application, without requiring another homing with a new enabling. Since the existing digital inputs are used in standard applications, the use of the analog inputs AIN 1, AIN 2 as digital inputs DIN AIN 1 and DIN AIN 2 as well as the digital outputs DOUT 2 and DOUT 3 as digital inputs DIN 10 and DIN 11 are optionally available.

Several methods as per the CANopen manual and following DSP 402 are implemented for the homing. Most methods first search for a switch at search velocity. The further movement depends on the method of communication. If a homing is activated via the fieldbus, there is generally no following positioning to zero. This is done optionally during the start via the controller enabling or RS232. A following positioning is always an option. The default setting is “no following positioning”.

Ramps and velocities are parameterisable for the homing. The homing can also be time-optimal and jerk-limited.

5.3.6 Positioning sequences

Positioning sequences consist of a series of positioning sets. These are run consecutively. A positioning set can be made part of a path program by means of its path program options, thus generating a linked list of positions:




Figure 6: Path program

Via the **start position of the path program** the user determines which position series to run. In principle, linear or cyclic series are possible.

The start position of a path program can be determined:

- ❖ via fieldbus
- ❖ via digital inputs

The number of positions in the corresponding positioning sequence is only limited by the number of totally available positions. Every user-defined positioning set (0 to 255) can be used in the path program.

For further information, please refer to the software manual “Servo Positioning Controller ARS 2000 FS”.

5.3.7 Optional stop input

The optional stop input can interrupt the ongoing positioning by setting the selected digital input. Resetting the digital input will resume positioning to the original target position.

5.3.8 Contouring control with linear interpolation

The implementation of the Interpolated Position Mode allows setting position values in a multi-axis application of the controller. For that purpose set position values are provided by a superordinated control at a fixed time pattern (synchronisation interval). If this interval exceeds a position control cycle, the controller autonomously interpolates the data values between two set position values, as shown in the following illustration. The servo positioning controller also calculated a corresponding speed feed forward.




Figure 7: Linear interpolation between two data values

5.3.9 Time-synchronized multi-axis positioning

The implementation of the clock synchronisation allows simultaneous movements for multi-axis applications in conjunction with “interpolated positioning mode”. All servo positioning controllers of the ARS 2100 FS family, that is the entire controller cascade, will be synchronized to the external clock signal. Pending positioning values in the case of multiple axes are then taken over and executed simultaneously without jitter. The sync message of a CAN bus system or the EtherCAT “DC” (Distributed Clock) can for example be used as a clock signal.

That way it is for example possible to send several axes with different path lengths and velocities to the destination at the same time.

6 Functional safety technology

6.1 General

With an increasing degree of automation, the protection of persons against dangerous movements becomes increasingly important. The so-called functional safety describes the necessary measures in the form of electrical or electronic devices in order to reduce or eliminate the hazards that are caused by malfunctions. Under normal operating conditions, protective devices prevent human access to dangerous areas. In certain operating modes, however, for example during the set-up, persons are required to be present in these dangerous areas. In these situations, the machine operator must be protected by drive- and control-internal measures.

The integrated safety technology provides the control- and drive-specific conditions for the optimal realisation of protective functions. Planning and installation become less labour-intensive. Compared to conventional safety technology, the machine functionality and availability can be increased by the use of integrated safety technology.

In their delivery status, the servo positioning controllers of the ARS 2000 FS product range are not equipped with integrated features for the safety-relevant monitoring and control of movements but they are equipped with an extension slot for a safety module.

As a standard, the ARS 2000 FS series servo positioning controllers come supplied with the module FSM 2.0 – FBA (**F**ield**b**us **A**ctivation **M**odule) integrated in the extension slot for safety modules. You can remove the FBA module and replace it with a Functional Safety Module.

If the safety modules of the FSM 2.0 series (**F**unctional **S**afety **M**odule) are used, external monitoring devices are no longer required for numerous applications. The wiring of the entire system is simplified and the number of components as well as the costs of the system solution can be reduced.

The design of the safety modules ensures that they can be simply plugged into the basic device from the outside. As a result, the servo positioning controllers can be quickly adapted to the specific safety requirements of the overall system. Retrofitting of these modules (or the later use of a different safety module), thereby, becomes possible. The module is supplied with power via the power supply of the basic device.

6.1.1 DIP switch

The FBA module (**F**ield**b**us **A**ctivation Module) and all of the integrated functional safety modules (FSM 2.0) are equipped with a DIP switch (8 poles). Under certain conditions, substantial parts of the parameters of the fieldbus communication can be configured with the aid of this DIP switch.

Depending on the fieldbus that is used, it is possible, for example, to adjust the fieldbus node number or the baud rate, and so on. This DIP switch does not have a safety-relevant function.

The following applies in order to achieve downward compatibility with the previous ARS 2000 devices:

- ❖ If all of the switches on the module are set to zero (factory setting), the fieldbus communication parameters of the parameter data set of the basic device will be used.



The position of the DIP switch is read in only once after a reset. Modifications of the switch positions during the operation, therefore, do not affect the current operation.

Table 32: Table overview of the DIP switch functionality

Technology module (type)	Functionality of the DIP switch		
	Communication On/Off	Baudrate	Settings station address
-- (CAN, in the basic device)	✓	✓	✓
PROFIBUS	✓	-- (via Master)	✓
Sercos (without DIP switch)	✓	✓	✓
Sercos (with DIP switch)	--	--	--
EtherCAT	-- ¹⁾	--	--

¹⁾ The control of EtherCAT via the DIP switches is not planned. By using the EtherCAT fieldbus technology module the bus will be switched on automatically.

6.1.2 Assignment of the DIP switch

The firmware of the ARS 2000 FS servo positioning controllers distinguishes itself by the universal support of various types of fieldbuses. Since every fieldbus requires a specific hardware, the fieldbus is selected based on the fieldbus module that is plugged into one of the technology slots. Depending on the identified technology module, the individual switches have an influence on the activation and perhaps also on the configuration of this specific fieldbus. If the system does not find any fieldbus technology module, the switch settings affect the fieldbus CAN whose interface is integrated into the basic device. This means that if, for example, a PROFIBUS-module is installed, the switch positions cannot be used to activate the CAN communication.

The assignment of the individual switch positions to a specific function depends on the fieldbus that is used. As far as this is possible, the function of a switch is the same for all of the fieldbuses such as, for example, switch 8 for activating/deactivating the communication. The functions are listed in


Table 33.

The following general rules apply to the communication parameterisation of the technology modules that are listed in

Table 33:

- ❖ Switch position = 0:
Activation of the communication. The baud rate and the fieldbus address will be taken from the parameter data set or – depending on the parameterisation – optionally also by an addition of digital inputs
- ❖ Switch position \neq 0:
The configuration of the communication parameters via the DIP switch takes precedence over the corresponding settings in the parameter data set:
 - Activation of the communication via DIP switch
 - Selection of the baud rate (if it can be adjusted) via DIP switch
 - Setting of the fieldbus address via DIP switch (addition to the basic node number taken from the parameter data set)
- ❖ If the communication is deactivated via the DIP switch, it is optionally possible to reactivate or deactivate it via the Metronix ServoCommander[®] parameterisation software
- ❖ The fieldbus address that is set via the DIP switch is checked internally for validity and, if necessary, it is limited
- ❖ Fieldbus-specific functions (for example CAN: check for double node numbers) are configured via the settings in the parameter data set
- ❖ If no fieldbus technology module is connected, the DIP switch is used for the configuration of the CAN hardware that is integrated in the basic device.
The control of operating parameters for the RS485 communication that is also supported in the basic device is not possible in favour of the parameterisation of the CAN interface

Table 33: Fieldbus specific assignment of the DIP switches

DIP switch		Functionally of the DIP switch (fieldbus specific with technology module)			
		CAN (in the basic device)	PROFIBUS	Sercos (without DIP switch)	EtherCAT
	8	Communication: 1: On 0: Off	Communication: 1: On 0: Off	Communication: 1: On 0: Off	Communication: 1: On 0: Off ¹⁾
	7	Baudrate: 11: 1 MBaud 10: 500 kBaud 01: 250 KBaud 00: 125 kBaud Node address respectively address offset ²⁾ : 1 ... 31	Slave address respectively address offset ²⁾ : 0 .. 127 valid range: 3 .. 125	Baudrate: 11: 16 MBaud 10: 8 MBaud 01: 4 MBaud 00: 2 MBaud	No function ¹⁾
	6				
	5			Drive address respectively address offset ²⁾ : 1 ... 31	
	4				
	3				
	2				
	1				

¹⁾ If all DIP switches == 0: automatic start-up of EtherCAT is activated → EtherCAT is switched on.

If at least one of the DIP switches 1 to 7 <> 0 and DIP switch 8 == 0: no automatic start-up of EtherCAT → EtherCAT is switched off.

²⁾ If necessary, the addresses will be added as an offset of a predefined base address of the corresponding bus system. The base address can be predefined in the Metronix ServoCommander® and can then be saved in the parameter set of the ARS 2000 FS.

The activation of a fieldbus via the DIP switch takes precedence over the activation of the fieldbus based on the parameter data set. In order to be nonetheless able to change settings and test different configurations during the operation, the fieldbus menu of the Metronix ServoCommander® can be used.

After a reset, however, the setting of the DIP switches will be checked and used.

Example:

- DIP switch position <> 0 and DIP8 = ON
→ fieldbus always activated, can be changed via Metronix ServoCommander®
- DIP switch position <> 0 and DIP8 = OFF
→ fieldbus always off, can be changed via Metronix ServoCommander®
- DIP switch position = 0
→ fieldbus configuration based on the parameter set. Can be changed and saved via Metronix ServoCommander® (downward-compatible)

6.2 Integrated safety technology (schematic representation)




Figure 8: Schematic representation of the integrated safety technology (MOV)

6.3 Module variants

6.3.1 FBA module

As a standard, the basic device comes supplied with a so-called “FBA module” (**F**ield**b**us **A**ctivation Module) that has a DIP switch (8 poles) on its front panel. Under certain conditions, substantial parts of the parameters of the fieldbus communication can be configured with the aid of this DIP switch. Depending on the fieldbus that is used, it is possible, for example, to adjust the fieldbus node number or the baud rate, and so on. This means that a servo positioning controller that is supplied in its original state (that is without a parameterisation or fieldbus data settings) can be installed and commissioned in a system.

In addition, the FBA module is required for enabling the driver power supply for the power stage.



Figure 9: FBA module: Front view

6.3.2 FSM 2.0 – STO (Safe Torque Off)

Please refer to the Original instructions “FSM 2.0 – STO” for further information.

6.3.3 FSM 2.0 – MOV

Module for the safety functions SLS, SOS, SBC etc.

Please refer to the Original instructions “FSM 2.0 – MOV” for further information.

7 Mechanical installation

7.1 Important notes

- ❖ Only use the servo positioning controller ARS 2100 FS as a built-in device for switch cabinets
- ❖ Mounting position vertical with supply lines [X9] on top
- ❖ Mount to control cabinet plate using a fastening strap
- ❖ Installation spaces:
Keep a minimum distance of 100 mm to other components each above and underneath the device to ensure sufficient venting.
- ❖ The servo positioning controller ARS 2100 FS may be installed adjacently in one switch cabinet without a gap, proper usage and installation on a heat-dissipating rear panel provided. Please note that excessive heat may cause premature aging and/or damaging of the device. In case the servo positioning controller ARS 2100 FS are subject to high thermal stress, a space of 59 mm is recommended!



The connections shown in the following illustrations for the servo positioning controller ARS 2102 FS also apply to the servo positioning controller ARS 2105 FS and ARS 2108 FS!




Figure 10: Servo positioning controller ARS 2100 FS: Installation space

7.2 View of the device




Figure 11: Servo positioning controller ARS 2102 FS: Front view




Figure 12: Servo positioning controller ARS 2102 FS: Top view




Figure 13: Servo positioning controller ARS 2102 FS: Bottom view

7.3 Mounting

The servo positioning controller ARS 2100 FS has attachment lugs on the top and the bottom of the device. These lugs are used to mount the servo positioning controller vertically to a control cabinet plate. The lugs are part of the cooling body profile. This is why the best possible heat transfer to the control cabinet plate has to be ensured.

Recommended tightening torque for an M5 screw of property class 5.6: 2.8 Nm.

Please use M5 screws for the mounting of the servo positioning controllers ARS 2102 FS, ARS 2105 FS und ARS 2108 FS.




Figure 14: Servo positioning controller ARS 2100 FS: Mounting plate

8 Electrical installation

8.1 Connector configuration

The servo positioning controller ARS 2100 FS is connected to the supply voltage, the motor, the brake resistor and the holding brakes as shown in *Figure 15*.




Figure 15: Connection to power supply and motor

The operation of the servo positioning controller ARS 2100 FS requires a 24V voltage supply source for the electronics supply, which is connected to the terminals +24V and GND24V.

The connection to the supply for the power output stage is either made to terminals L1 and N for AC supply or to ZK+ and ZK- for DC supply.

The motor is connected to terminals U, V and W. The motor temperature switch (analogue or digital) is connected to terminals MT+ and MT–, if it is lead into one cable together with the motor phases. If an analog temperature sensor is used in the motor (for example KTY81), the connection is realized via the encoder cable to [X2A] or [X2B].

The connection of the shaft encoder via the D-Sub connector to [X2A] / [X2B] is roughly shown in *Figure 15*.

The servo positioning controller ARS 2100 FS must be connected to ground with its PE connection.

The ARS 2100 FS must be completely wired first. Only then the operating voltages for the DC bus and the electronics may be switched on. In the case of inversed wiring of the operating voltage connections, excessive operating voltage or in the case of confusing the connections for operating voltage and motor the servo positioning controller will be damaged.

8.2 ARS 2100 FS complete system

The complete servo positioning controller ARS 2100 FS system is shown in *Figure 16*. The following components are required for using the servo positioning controller:

- ❖ Main switch mains supply
- ❖ Fault current protection switch (RCD), AC/DC sensitive 300mA (if this is required by an application)
- ❖ Automatic circuit breaker
- ❖ Servo positioning controller ARS 2100 FS
- ❖ Motor with motor cable
- ❖ Mains cable

The parameterisation requires a PC with serial or USB connection.

A slow-blow (B16) single-phase automatic circuit breaker of 16 A has to be installed in the mains supply line.




Figure 16: Complete setup of the ARS 2100 FS with motor and PC

8.3 Connection: Power supply [X9]

The servo positioning controller ARS 2100 FS receives its 24 VDC power supply for the control electronics via connector [X9].

The mains voltage supply is single-phase. As an alternative to AC feed or for the purpose of DC bus coupling a direct DC supply for the DC bus is possible.

8.3.1 Device side [X9]

- ❖ ARS 2102 FS and ARS 2105 FS PHOENIX MINI-COMBICON MC1.5/9-G-5.08 BK
- ❖ ARS 2108 FS PHOENIX COMBICON MSTBA 2,5/9-G-5.08 BK

8.3.2 Counterplug [X9]

- ❖ ARS 2102 FS and ARS 2105 FS PHOENIX MINI-COMBICON MC1.5/9-ST-5.08 BK
- ❖ ARS 2108 FS PHOENIX COMBICON MSTB 2,5/9-ST-5,08 BK

- ❖ ARS 2102 FS and ARS 2105 FS PHOENIX MINI-COMBICON connector housing 12-pole, KGG-MC1,5/12 BK
- ❖ ARS 2108 FS PHOENIX COMBICON connector housing 12-pole, KGS-MSTB 2,5/9 BK

- ❖ Coding to PIN 9 (GND24V)

8.3.3 Pin assignment [X9]

Table 34: Pin assignment: [X9]

Pin No.	Denomination	Values	Specification
1	L	100 ... 230 VAC [$\pm 10\%$], 50 ... 60 Hz	Phase conductor
2	N		Neutral conductor
3	ZK+	< 440 VDC	Pos. DC bus voltage
4	ZK-	GND_ZK	Neg. DC bus voltage
5	BR-INT	< 460 VDC	Connection of internal brake resistor (bridge to BR-CH when using the internal resistor)
6	BR-CH	< 460 VDC	Brake chopper connection for internal brake resistor against BR-INT and external brake resistor against ZK+
7	PE	PE	Connection ground conductor from mains
8	+24V	24 VDC [$\pm 20\%$], 0,55 A ^{*)} ARS 2102 FS 0,65 A ^{*)} ARS 2105 FS and ARS 2108 FS	Supply for control module
9	GND24V	GND (0 VDC)	Reference potential supply

^{*)} Plus current consumption of a possibly connected holding brake and I/Os

8.3.4 Cable type and design [X9]

The mentioned cable denominations refer to cables by Lapp. They have proven effective and are successfully used in many applications. However, similar cables from other manufacturers, for example Lütze or Helukabel, may also be used.

For the 230 VAC supply:

❖ LAPP KABEL ÖLFLEX-CLASSIC 110; 3 x 1.5 mm²

8.3.5 Connection notes [X9]




Figure 17: Supply [X9]



ARS 2102 FS and ARS 2105 FS: PHOENIX MINI-COMBICON MC 1,5/ 9-ST-5,08 BK
ARS 2108 FS: PHOENIX COMBICON MSTB 2,5/9-ST-5,08 BK

The servo positioning controller ARS 2100 FS has an internal brake chopper with brake resistor. For more brake power it is possible to connect an external brake resistor to the connector [X9].



If no external brake resistor is used, a bridge must be connected between PIN 5 and PIN 6 so that the DC bus precharge, when the mains power supply is "ON", and the DC bus rapid discharge can function properly!

8.4 Connection: Motor [X6]

8.4.1 Device side [X6]

- ❖ ARS 2102 FS and ARS 2105 FS PHOENIX MINI-COMBICON MC1.5/9-G-5.08 BK
- ❖ ARS 2108 FS PHOENIX COMBICON MSTBA 2,5/9-G-5.08 BK

8.4.2 Counterplug [X6]

- ❖ ARS 2102 FS and ARS 2105 FS PHOENIX MINI-COMBICON MC1.5/9-ST-5.08 BK
- ❖ ARS 2108 FS PHOENIX COMBICON MSTB 2,5/9-ST-5,08 BK

- ❖ ARS 2102 FS and ARS 2105 FS PHOENIX MINI-COMBICON connector housing 12-pole, KGG-MC1,5/12 BK
- ❖ ARS 2108 FS PHOENIX COMBICON connector housing 12-pole, KGS-MSTB 2,5/9 BK

- ❖ Coding to PIN 1 (BR-)

8.4.3 Pin assignment [X6]

Table 35: Pin assignment: [X6]

Pin No.	Denomination	Values	Specification
1	BR-	0 V brake	Holding brake (motor), signal level dependent on switch status, high side / low side switch
2	BR+	24 V brake	
3	PE	PE	Connection for inner shield (holding brake + temperature sensor)
4	MT-	GND	Motor temperature sensor ¹⁾ , N.C. and N.O. contact, PTC, NTC KTY
5	MT+	+ 3,3 V / 5 mA	
6	PE	PE	Motor ground conductor
7	W	0 ... 270 V _{RMS} ARS 2102 FS and ARS 2105 FS 0 ... 230 V _{RMS} ARS 2108 FS 0 ... 2,5 A _{RMS} ARS 2102 FS 0 ... 5 A _{RMS} ARS 2105 FS 0 ... 8 A _{RMS} ARS 2108 FS 0 ... 1000 Hz	Connection of the three motor phases
8	V		
9	U		

¹⁾ Please comply with *Chapter 9 Additional requirements for the servo drives concerning the UL approval on page 121.*



The cable shield of the motor cable must also be connected to the controller housing (PE screw terminal).

8.4.4 Cable type and design [X6]

The mentioned cable denominations refer to cables by Lapp. They have proven effective and are successfully used in many applications. However, similar cables from other manufacturers, for example Lütze or Helukabel, may also be used.



Caution!

Please comply with the prescribed minimum copper cross-section for cables as per EN 60204-1!

- ❖ ARS 2102 FS:
LAPP KABEL ÖLFLEX SERVO 700 CY; 4 G 1,5 + 2 x (2 x 0,75); Ø 12,7 mm, with tinned total Cu shield
- ❖ ARS 2105 FS and ARS 2108 FS:
LAPP KABEL ÖLFLEX SERVO 700 CY; 4 G 2,5 + 2 x (2 x 0,75); Ø 14,9 mm, with tinned total Cu shield

For highly flexible applications:

- ❖ ARS 2102 FS:
LAPP KABEL ÖLFLEX SERVO FD 755 P; 4 G 1,5 + 2 x (2 x 0,75) CP; Ø 14,1 mm, with tinned total Cu shield for highly flexible use in drag chains
- ❖ ARS 2105 FS und ARS 2108 FS:
LAPP KABEL ÖLFLEX SERVO FD 755 P; 4 G 2,5 + 2 x (2 x 0,75) CP; Ø 15,1 mm, with tinned total Cu shield for highly flexible use in drag chains

8.4.5 Connection notes [X6]




Figure 18: Motor connection [X6]



ARS 2102 FS and ARS 2105 FS: PHOENIX MINI-COMBICON MC 1,5/ 9-ST-5,08 BK
ARS 2108 FS: PHOENIX COMBICON MSTB 2,5/9-ST-5,08 BK

- ❖ Connect the inner shields to PIN 3; maximum length 40 mm.
- ❖ Length of unshielded cores maximum 35 mm.
- ❖ Connect total shield on controller side flat to PE terminal; maximum length 40 mm.
- ❖ Connect total shield on motor side flat to connector or motor housing; maximum length 40 mm.

Via terminals ZK+ and ZK- the DC buses of several servo positioning controllers ARS 2100 FS can be interconnected. The coupling of the DC bus is interesting for applications with high brake energies or if movements have to be carried out even in the case of power failure. For further information please refer to Application Note 67.

A holding brake can be connected to the terminals BR+ and BR- of the motor. The holding brake is fed by the servo positioning controller's power supply. Note the maximum output current provided by the servo positioning controller ARS 2100 FS. A relay may have to be placed between the device and the holding brake as shown in *Figure 19*:




Figure 19: Connecting a holding brake with high current draw (> 1A) to the device



The switching of inductive direct current via relay produces strong currents and sparking. For interference suppression we recommend integrated RC suppressor elements, for example by Evox RIFA, denomination: PMR205AC6470M022 (RC element with 22 Ω in series with 0.47 μF).

8.5 Connection: I/O communication [X1]

The following *Figure 20* shows the principle function of the digital and analog inputs and outputs. The servo positioning controller ARS 2100 FS is shown on the right hand side, the control system connection on the left. The cable design is also visible.

The servo positioning controller ARS 2100 FS features two potential ranges:

Analog inputs and outputs:

All analog inputs and outputs refer to AGND. AGND is internally connected with GND, the reference potential for the control module with μ C and AD converters in the controller. This potential range is galvanically separated from the 24 V range and from the DC bus.

24 V inputs and outputs:

These signals refer to the 24 V supply voltage of the servo positioning controller ARS 2100 FS which is fed via [X9], and separated from the reference potential of the control module by means of optocouplers.




Figure 20: Basic circuit diagram connector [X1]

The servo positioning controller ARS 2100 FS comprises one differential (AIN 0) and two single-ended analog inputs, designed for input voltages within a range of $\pm 10V$. The inputs AIN 0 and #AIN 0 are lead to the control via twisted cables (twisted pair design).

If the control comprises single-ended outputs, the output is connected to AIN 0 and #AIN 0 is put on the reference potential of the control. If the control has differential outputs, they are to be connected 1:1 to the differential inputs of the servo positioning controller ARS 2100 FS.

The reference potential AGND is connected to the reference potential of the control. This is necessary in order to prevent the differential input of the servo positioning controller ARS 2100 FS from being overridden by high "common-mode interference".

There are two analog monitor outputs with output voltages in the range of ± 10 V and an output for a reference voltage of + 10 V. These outputs can be led to the superimposed control, the reference potential AGND must be carried along. If the control has differential inputs, the "+"-input of the control is connected to the output of the servo positioning controller ARS 2100 FS and "-"-input of the control with AGND.

8.5.1 Device side [X1]

- ❖ D-SUB connector, 25-pole, female

8.5.2 Counterplug [X1]

- ❖ D-SUB connector, 25-pole, male
- ❖ Housing for 25-pole D-SUB connector with bolting screws 4/40 UNC

8.5.3 Pin assignment [X1]

Table 36: Pin assignment: I/O communication [X1]

Pin No.		Denomination	Values	Specification
1		AGND	0 V	Shield for analog signals, AGND
	14	AGND	0 V	Reference potential for analog signals
2		AIN 0	$U_{in} = \pm 10 \text{ V}$ $R_i \geq 30 \text{ k}\Omega$	Setpoint input 0, differential, max. 30 V input voltage
	15	#AIN 0		
3		AIN 1	$U_{in} = \pm 10 \text{ V}$ $R_i \geq 30 \text{ k}\Omega$	Setpoint inputs 1 and 2, single ended, max. 30 V input voltage
	16	AIN 2		
4		+VREF	+ 10 V	Reference output for setpoint potentiometer
	17	AMON 0	$\pm 10 \text{ V}$	Analog monitor output 0
5		AMON 1	$\pm 10 \text{ V}$	Analog monitor output 1
	18	+24V	24 V / 100 mA	Auxiliary voltage for IOs at X1
6		GND24	Reference GND	Reference potential for digital I/Os
	19	DIN 0	POS Bit 0	Target selection positioning Bit 0
7		DIN 1	POS Bit 1	Target selection positioning Bit 1
	20	DIN 2	POS Bit 2	Target selection positioning Bit 2
8		DIN 3	POS Bit 3	Target selection positioning Bit3
	21	DIN 4	FG_E	Power stage enable
9		DIN 5	FG_R	Input controller enable
	22	DIN 6	END 0	Input end switch 0 (locks $n < 0$)
10		DIN 7	END 1	Input end switch 1 (locks $n > 0$)
	23	DIN 8	START	Input for positioning start
11		DIN 9	SAMP	High-speed input
	24	DOUT 0 / READY	24 V / 100 mA	Output operational
12		DOUT 1	24 V / 100 mA	Output freely programmable
	25	DOUT 2	24 V / 100 mA	Output freely programmable
13		DOUT 3	24 V / 100 mA	Output freely programmable

8.5.4 Cable type and design [X1]

The mentioned cable denominations refer to cables by Lapp. They have proven effective and are successfully used in many applications. However, similar cables from other manufacturers, for example Lütze or Helukabel, may also be used.

❖ LAPP KABEL UNITRONIC LiYCY (TP); 25 x 0,25mm²; Ø 10,7 mm

Figure 20 shows the cable between the servo positioning controller ARS 2100 FS and the control. The cable shown has two cable shields.

The outer cable shield is connected on both sides to PE. Inside the servo positioning controller the connector housing of the D-Sub connector is connected to PE. When using metal D-Sub connector housings the cable shield is simply squeezed underneath the strain relief clamp.

Often, an unshielded cable is sufficient for the 24 V signals. In heavily disturbed surroundings or in the case of long cables ($l > 2$ m) between the control and the servo positioning controller ARS 2100 FS Metronix recommends the use of shielded cables.

In spite of the differential design of the analog inputs of the ARS 2100 FS the cables should not be unshielded, since interferences, for example due to switching contactors or power stage interferences of the converters can reach high amplitudes. They couple into the analog signals and cause common-mode interference, which may lead to deviation of the analog measured values.

In the case of limited cable lengths ($l < 2$ m, wiring inside control cabinet) the outer dual-sided PE shield is enough to guarantee undisturbed operation.

For optimal interference suppression on the analog signals the cores for the analog signals are to be shielded together and separate from others. This internal cable shield is connected to AGND (Pin 1 or 14) on one side of the ARS 2100 FS. It can be connected on both sides in order to establish a connection between the reference potentials of the control and the servo positioning controller ARS 2100 FS. Pins 1 and 14 are directly connected to each other inside the controller.

8.5.5 Connection notes [X1]

The digital inputs are designed for control voltages of 24 V. Due to the high signal level a higher interference immunity of these inputs is already guaranteed. The servo positioning controller ARS 2100 FS provides a 24 V auxiliary voltage, which may be loaded with a maximum of 100 mA. This way the inputs can be activated directly via switches. Activation via the 24 V outputs of a PLC is, of course, also possible.

The digital outputs are designed as so-called "high-side switches". That means that the 24 V of the servo positioning controller ARS 2100 FS are actively switched through to the output. Loads such as lamps, relays, and so on are thus switched from the output to GND24. The four outputs DOUT 0 to DOUT 3 can be loaded with a maximum of 100mA each. The outputs can also be lead directly to 24 V inputs of a PLC.

8.6 Connection: Resolver [X2A]

8.6.1 Device side [X2A]

- ❖ 1 D-SUB connector, 9-pole, female

8.6.2 Counterplug [X2A]

- ❖ D-SUB connector, 9-pole, male
- ❖ Housing for 9-pole D-SUB connector with bolting screws 4/40 UNC

8.6.3 Pin assignment [X2A]

Table 37: Pin assignment: [X2A]

Pin No.		Denomination	Values	Specification
1		S2	$3,5 V_{\text{eff}} / 5\text{-}10 \text{ kHz}$	SINE trace signal, differential
	6	S4	$R_i > 5 \text{ k}\Omega$	
2		S1	$3,5 V_{\text{eff}} / 5\text{-}10 \text{ kHz}$	COSINE trace signal, differential
	7	S3	$R_i > 5 \text{ k}\Omega$	
3		AGND	0 V	Shield for signal pairs (inner shield)
	8	MT-	GND (0 V)	Reference potential temperature sensor
4		R1	$7 V_{\text{eff}} / 5\text{-}10 \text{ kHz}$ $I_A \leq 150 \text{ mA}_{\text{eff}}$	Carrier signal for resolver
	9	R2	GND (0 V)	
5		MT+	$+3,3 \text{ V} / R_i = 2 \text{ k}\Omega$	Motor temperature sensor, normally closed contact, PTC, KTY



The outer cable shield of the angle encoder cable must additionally be applied to the mounting plate of the controller housing over a large contact area with the aid of the shield connection clamp SK14.

8.6.4 Cable type and design [X2A]

The mentioned cable denominations refer to cables by Lapp. They have proven effective and are successfully used in many applications. However, similar cables from other manufacturers, for example Lütze or Helukabel, may also be used.

- ❖ LAPP KABEL ÖLFLEX SERVO 720 CY; 3 x (2 x 0,14 DY) + 2 x (0,5 DY) CY; Ø 8.5 mm, with tinned total Cu shielding, Error during angle detection up to approx. 1.5° at 50 m cable length
 - 2 x (0,5 DY) use carriers for the resolver!

For highly flexible applications:

- ❖ LAPP KABEL ÖLFLEX SERVO FD 770 CP; 3 x (2 x 0,14 D12Y) + 2 x (0,5 D12Y) CP; Ø 8.3 mm, with tinned total Cu shielding, Error during angle detection up to approximately 1.5° at 50 m cable length
 - 2 x (0.5 D12Y) use carriers for the resolver!

8.6.5 Connection notes [X2A]




Figure 21: Pin assignment: Resolver connection [X2A]

- ❖ The outer shield is always connected to PE (connector housing) on the controller side.
- ❖ The three inner shields are connected on one side of the servo positioning controller ARS 2100 FS to PIN3 of [X2A].

8.7 Connection: Encoder [X2B]

8.7.1 Device side [X2B]

- ❖ D-SUB connector, 15-pole, female

8.7.2 Counterplug [X2B]

- ❖ D-SUB connector, 15-pole, male
- ❖ Housing for 15-pole D-SUB connector with bolting screws 4/40 UNC

8.7.3 Pin assignment [X2B]

Table 38: Pin assignment: Analog incremental encoder – optional [X2B]

Pin No.		Denomination	Values	Specification
1		MT+	+3,3 V / $R_i = 2 \text{ k}\Omega$	Motor temperature sensor ¹⁾ , normally closed contact, PTC, KTY
	9	U_SENS+	5 V ... 12 V / $R_i \approx 1 \text{ k}\Omega$	Sensor cables for encoder supply
2		U_SENS-		
	10	US	5 V / 12 V / $\pm 10 \%$ $I_{\max} = 300 \text{ mA}$	Supply voltages for high-resolution incremental encoder
3		GND	0 V	Reference potential encoder supply and motor temperature sensor
	11	R	0,2 V _{SS} ... 0,8 V _{SS} $R_i \approx 120 \Omega$	Reset pulse trace signal (differential) from high-resolution incremental encoder
4		#R		
	12	COS_Z1 ²⁾	1 V _{SS} / $\pm 10 \%$ $R_i \approx 120 \Omega$	COSINE commutation signal (differential) from high-resolution incremental encoder
5		#COS_Z1 ²⁾		
	13	SIN_Z1 ²⁾	1 V _{SS} / $\pm 10 \%$ $R_i \approx 120 \Omega$	SINE commutation signal (differential) from high-resolution incremental encoder
6		#SIN_Z1 ²⁾		
	14	COS_Z0 ²⁾	1 V _{SS} / $\pm 10 \%$ $R_i \approx 120 \Omega$	COSINE trace signal (differential) from high-resolution incremental encoder
7		#COS_Z0 ²⁾		
	15	SIN_Z0 ²⁾	1 V _{SS} / $\pm 10 \%$ $R_i \approx 120 \Omega$	SINE trace signal (differential) from high-resolution incremental encoder
8		#SIN_Z0 ²⁾		

¹⁾ Please comply with *Chapter 9 Additional requirements for the servo drives concerning the UL approval on page 121*.

²⁾ Heidenhain encoder: A=SIN_Z0; B=COS_Z0; C=SIN_Z1; D=COS_Z1



The outer cable shield of the angle encoder cable must additionally be applied to the mounting plate of the controller housing over a large contact area with the aid of the shield connection clamp SK14.

Table 39: Pin assignment: Incremental encoder with serial interface (for example EnDat, HIPERFACE) – optional [X2B]

Pin No.		Denomination	Values	Specification
1		MT+	+3,3V / $R_i = 2 \text{ k}\Omega$	Motor temperature sensor ¹⁾ , , normally closed contact, PTC, KTY
	9	U_SENS+	5 V ... 12 V $R_l \approx 1 \text{ k}\Omega$	Sensor cables for encoder supply
2		U_SENS-		
	10	US	5 V / 12 V / $\pm 10 \%$ $I_{\max} = 300 \text{ mA}$	Supply voltages for high-resolution incremental encoder
3		GND	0 V	Reference potential encoder supply and motor temperature sensor
	11			
4				
	12	DATA	5 V _{SS} $R_l \approx 120 \Omega$	Bidirectional RS485 data line (differential) (EnDat/HIPERFACE)
5		#DATA		
	13	SCLK	5 V _{SS} $R_l \approx 120 \Omega$	Clock output RS485 (differential) (EnDat)
6		#SCLK		
	14	COS_Z0 ²⁾	1 V _{SS} / $\pm 10 \%$ $R_l \approx 120 \Omega$	COSINE trace signal (differential) from high-resolution incremental encoder
7		#COS_Z0 ²⁾		
	15	SIN_Z0 ²⁾	1 V _{SS} / $\pm 10 \%$ $R_l \approx 120 \Omega$	SINE trace signal (differential) from high-resolution incremental encoder
8		#SIN_Z0 ²⁾		

¹⁾ Please comply with *Chapter 9 Additional requirements for the servo drives concerning the UL approval on page 121*.

²⁾ Heidenhain encoder: A=SIN_Z0; B=COS_Z0



The outer cable shield of the angle encoder cable must additionally be applied to the mounting plate of the controller housing over a large contact area with the aid of the shield connection clamp SK14.

Table 40: Pin assignment: Digital incremental encoder – optional [X2B]

Pin No.		Denomination	Values	Specification
1		MT+	+3,3 V / $R_i = 2 \text{ k}\Omega$	Motor temperature sensor ¹⁾ , normally closed contact, PTC, KTY
	9	U_SENS+	5 V ... 12 V $R_i \approx 1 \text{ k}\Omega$	Sensor cables for encoder supply
2		U_SENS-		
	10	US	5 V / 12 V / $\pm 10 \%$ $I_{\max} = 300 \text{ mA}$	Supply voltages for high-resolution incremental encoder
3		GND	0V	Reference potential encoder supply and motor temperature sensor
	11	N	2 V_{SS} ... 5 V_{SS} $R_i \approx 120 \Omega$	Reset pulse trace signal RS422 (differential) from digital incremental encoder
4		#N		
	12	H_U	0 V / 5 V $R_i \approx 2 \text{ k}\Omega$ at VCC	Phase U hall sensor for commutation
5		H_V		Phase V hall sensor for commutation
	13	H_W		Phase W hall sensor for commutation
6				
	14	A	2 V_{SS} ... 5 V_{SS} $R_i \approx 120 \Omega$	A trace signal RS422 (differential) from digital incremental encoder
7		#A		
	15	B	2 V_{SS} ... 5 V_{SS} $R_i \approx 120 \Omega$	B trace signal RS422 (differential) from digital incremental encoder
8		#B		

¹⁾ Please comply with *Chapter 9 Additional requirements for the servo drives concerning the UL approval on page 121*.



The outer cable shield of the angle encoder cable must additionally be applied to the mounting plate of the controller housing over a large contact area with the aid of the shield connection clamp SK14.

8.7.4 Cable type and design [X2B]

We recommend using the encoder connection cables released for their product by the corresponding manufacturer (Heidenhain, Stegmann, and so on). If the manufacturer does not recommend a particular cable, we recommend the assembly of the encoder connection cables as described below.



For the angle encoder supply US and GND, we recommend

- ❖ a minimum cross-section of 0.25 mm² for an angle encoder cable length up to 25 m, and
- ❖ a minimum cross-section of 0.5 mm² for an angle encoder cable length up to 50 m.

8.7.5 Connection notes [X2B]

D-SUB connector at X2B

Output of the analogue incremental encoder interface at the motor




Figure 22: Pin assignment: Analog incremental encoder – optional [X2B]

D-SUB connector at X2B

Output of the incremental encoder with serial communication interface at the motor




Figure 23: Pin assignment: Incremental encoder with serial communication interface (for example EnDat, HIPERFACE) – optional [X2B]




Figure 24: Pin assignment: Digital incremental encoder – optional [X2B]

8.8 Connection: Incremental encoder input [X10]

8.8.1 Device side [X10]

- ❖ D-SUB connector, 9-pole, female

8.8.2 Counterplug [X10]

- ❖ D-SUB connector, 9-pole, male
- ❖ Housing for 9-pole D-SUB connector with bolting screws 4/40 UNC

8.8.3 Pin assignment [X10]

Table 41: Pin assignment: Incremental encoder input [X10]

Pin No.	Denomination	Values	Specification
1	A / CLK	5 V / $R_i \approx 120 \Omega$	Incremental encoder signal A / Stepper motor signal CLK pos. polarity as per RS422
6	A# / CLK#	5 V / $R_i \approx 120 \Omega$	Incremental encoder signal A / Stepper motor signal CLK neg. polarity as per RS422
2	B / DIR	5 V / $R_i \approx 120 \Omega$	Incremental encoder signal B / Stepper motor signal DIR pos. polarity as per RS422
7	B# / DIR#	5 V / $R_i \approx 120 \Omega$	Incremental encoder signal B / Stepper motor signal DIR neg. polarity as per RS422
3	N	5 V / $R_i \approx 120 \Omega$	Incremental encoder index pulse N pos. polarity as per RS422
8	N#	5 V / $R_i \approx 120 \Omega$	Incremental encoder index pulse N neg. polarity as per RS422
4	GND		Reference GND for encoder
9	GND		Shield for the connection cable
5	VCC	+ 5 V / $\pm 5 \%$ 100 mA	Auxiliary supply (short circuit-proof), load with 100 mA maximum

8.8.4 Cable type and design [X10]

We recommend encoder connection cables twisted in pairs and individually protected.

8.8.5 Connection notes [X10]

Input [X10] can be used to process incremental encoder signals as well as pulse direction signals, as generated by control boards for stepper motors.

The input amplifier at the signal input is designed for the processing of differential signals as per interface standard RS422. Processing of other signals and levels (for example 5V single-ended or 24V_{HTL} from a PLC) may be possible. Please contact your sales representative.




Figure 25: Pin assignment: Input of the incremental encoder [X10]

8.9 Connection: Incremental encoder output [X11]

8.9.1 Device side [X11]

- ❖ D-SUB connector, 9-pole, female

8.9.2 Counterplug [X11]

- ❖ D-SUB connector, 9-pole, male
- ❖ Housing for 9-pole D-SUB connector with bolting screws 4/40 UNC

8.9.3 Pin assignment [X11]

Table 42: Pin assignment: Incremental encoder output [X11]

Pin No.	Denomination	Values	Specification
1	A	5 V / $R_A \approx 66 \Omega$ *)	Incremental encoder signal A
6	A#	5 V / $R_A \approx 66 \Omega$ *)	Incremental encoder signal A#
2	B	5 V / $R_A \approx 66 \Omega$ *)	Incremental encoder signal B
7	B#	5 V / $R_A \approx 66 \Omega$ *)	Incremental encoder signal B#
3	N	5 V / $R_A \approx 66 \Omega$ *)	Incremental encoder index pulse N
8	N#	5 V / $R_A \approx 66 \Omega$ *)	Incremental encoder index pulse N#
4	GND		Reference GND for encoder
9	GND		Shield for connection cable
5	VCC	+ 5 V / $\pm 5 \%$ 100 mA	Auxiliary supply, to be loaded with maximal 100 mA, but short-circuit-proof!

*) The value for R_A is the differential output resistance

8.9.4 Cable type and design [X11]

We recommend encoder connection cables twisted in pairs and individually protected.

8.9.5 Connection notes [X11]




Figure 26: Pin assignment: Incremental encoder output [X11]

The output driver at the signal output provides differential signals (5 V) as per interface standard RS422.

Up to 32 other servo positioning controllers may be driven by one device.

8.10 Connection: CAN-Bus [X4]

8.10.1 Device side [X4]

- ❖ D-SUB connector, 9-pole, female

8.10.2 Counterplug [X4]

- ❖ D-SUB connector, 9-pole, male
- ❖ Housing for 9-pole D-SUB connector with bolting screws 4/40 UNC

8.10.3 Pin assignment [X4]

Table 43: Pin assignment: CAN-Bus [X4]

Pin No.		Denomination	Values	Specification
1				Not occupied
	6	GND	0 V	CAN-GND, galvanically connected to GND in controller
2		CANL	*)	CAN-Low signal line
	7	CANH	*)	CAN-High signal line
3		GND	0 V	See Pin no. 6
	8			Not occupied
4				Not occupied
	9			Not occupied
5		Shield	PE	Connection for cable shield

*) External terminating resistor 120 Ω required on both ends of the bus. If the bus ends are not formed by ARS 2100 FS servo positioning controllers with integrated terminating resistors, we recommend using metal film resistors with a 1 % tolerance of type 0207, for example made by BCC, order no.: 232215621201.

8.10.4 Cable type and design [X4]

The mentioned cable denominations refer to cables by Lapp. They have proven effective and are successfully used in many applications. However, similar cables from other manufacturers, for example Lütze or Helukabel, may also be used.



Technical data CAN bus cable: 2 pairs of 2 twisted cores, $d \geq 0.22 \text{ mm}^2$, shielded, loop resistance $< 0.2 \Omega/\text{m}$, characteristic impedance 100-120 Ω

- ❖ LAPP KABEL UNITRONIC BUS CAN; 2 x 2 x 0.22; \varnothing 7.6 mm, with total Cu shielding

For highly flexible applications:

- ❖ LAPP KABEL UNITRONIC BUS CAN FD P; 2 x 2 x 0,25; \varnothing 8,4 mm, with total Cu shielding

8.10.5 Connection notes [X4]



Caution!

When cabling the servo positioning controllers via the CAN bus, make sure to observe the following information and notes, to ensure a stable and interference-free system. Improper cabling may cause the CAN bus to malfunction which in turn can cause the controller to shut down with an error for safety reasons.

The CAN bus provides a simple and fail-safe way of connecting all components of a system, assuming, however, compliance with the following notes on cabling.




Figure 27: Cabling example for CAN-Bus

- ❖ The individual nodes of a network are always connected in line, so that the CAN cable is looped through from controller to controller (see *Figure 27*)
- ❖ On both ends of the CAN bus cable must be exactly one terminating resistor of 120 Ω \pm 5 %. The ARS 2100 FS servo positioning controller is equipped with an integrated terminating resistor that can be activated/deactivated with the aid of the DIP switch "CAN TERM" that is located on the front panel (see *Figure 11* and *Figure 28*)
- ❖ **Shielded** cables with exactly two **twisted** pairs must be used for cabling

- ❖ Use a twisted pair for the connection of CAN-H and CAN-L
- ❖ The cores of the other pair are used **jointly** for CAN-GND
- ❖ The shield of the cable is led to the CAN shield connections for all nodes
- ❖ For suitable and Metronix-recommended cables please refer to *chapter 8.10.4 Cable type and design [X4]*
- ❖ We advise against the use of plug adaptors for CAN bus cabling. Should this be necessary nonetheless, make sure to use metal connector housings to connect the cable shield
- ❖ In order to keep interferences as low as possible make sure that
 - Motor cables are not installed parallel to signal lines
 - Motor cables comply with Metronix specifications
 - Motor cables are properly shielded and grounded
- ❖ For further information on interference-free CAN bus cabling, please refer to the Controller Area Network protocol specification, Version 2.0 by Robert Bosch GmbH, 1991




Figure 28: Integrated CAN terminating resistor

8.11 Connection: RS232/COM [X5]

8.11.1 Device side [X5]

- ❖ D-SUB connector, 9-pole, male

8.11.2 Counterplug [X5]

- ❖ D-SUB connector, 9-pole, female
- ❖ Housing for 9-pole D-SUB connector with bolting screws 4/40 UNC

8.11.3 Pin assignment [X5]

Table 44: Pin assignment: RS232 interface [X5]

Pin No.		Denomination	Values	Specification
1				Not occupied
	6			Not occupied
2		RxD	$10\text{ V} / R_I > 2\text{ k}\Omega$	Receive line, RS232 specification
	7	-	-	Not occupied
3		TxD	$10\text{ V} / R_A < 2\text{ k}\Omega$	Transmitting line, RS232 specification
	8			Not occupied
4		+RS485		reserved for optional RS485 use
	9	-RS485		reserved for optional RS485 use
5		GND	0 V	Interfaces GND, galvanically connected to GND DGND

8.11.4 Cable type and design [X5]

Interface cable for serial interface (null modem), 3-core.

8.11.5 Connection notes [X5]




Figure 29: Pin assignment: RS232 null modem cable [X5]

8.12 Connection: USB [X19]

8.12.1 Device side [X19]

- ❖ USB female, type B

8.12.2 Counterplug [X19]

- ❖ USB male, type B

8.12.3 Pin assignment [X19]

Table 45: Pin assignment: USB interface [X19]

Pin No.	Denomination	Values	Specification
1	VCC		+ 5 VDC
2	D-		Data -
3	D+		Data +
4	GND		GND




Figure 30: Pin assignment: USB interface [X19], front view

8.12.4 Cable type and design [X19]

Interface cable for the USB interface, 4 cores, shielded and twisted.

In order to set up a USB connection, it is mandatory to use a twisted and shielded (4-core) cable since, otherwise, the transmission may be subject to interferences. In addition, it must be ensured that the cable has a wave impedance of 90 Ω .

8.13 SD/MMC card

8.13.1 Supported card types

- ❖ SD
- ❖ SDHC
- ❖ MMC

8.13.2 Supported functions

- ❖ Load a parameter set (DCO file)
- ❖ Save the current parameter set (DCO file)
- ❖ Load a firmware file

8.13.3 Supported file systems

- ❖ FAT12
- ❖ FAT16
- ❖ FAT32

8.13.4 File names

Only file and directory names according to the 8.3 standard are supported.



8.3 file and directory names have at most eight characters (letters or numbers) followed by a period "." and a filename extension of at most three characters.
File and directory names may only consist of upper-case characters and numbers.

8.13.5 Pin assignment SD/MMC card

Table 46: Pin assignment: SD card

Pin No	Denomination	SD Mode	SPI Mode
1	DATA3/CS	Data Line 3 (Bit 3)	Chip Select
2	CMD/DI	Command/Response	Host to Card Commands and Data
3	Vss1	Supply Voltage Ground	Supply Voltage Ground
4	Vcc	Supply Voltage	Supply Voltage
5	CLK	Clock	Clock
6	Vss2	Supply Voltage Ground	Supply Voltage Ground
7	DAT0/DO	Data Line 0 (Bit 0)	Card to Host Data and Status
8	DAT1	Data Line 1 (Bit 1)	reserved
9	DAT2	Data Line 2 (Bit 2)	reserved

Table 47: Pin assignment: MMC card

Pin No	Denomination	SD Mode	SPI Mode
1	RES/CS	Not connected or Always „1“	Chip Select
2	CMD/DI	Command/Response	Host to Card Commands and Data
3	Vss1	Supply Voltage Ground	Supply Voltage Ground
4	Vcc	Supply Voltage	Supply Voltage
5	CLK	Clock	Clock
6	Vss2	Supply Voltage Ground	Supply Voltage Ground
7	DAT/DO	Data 0	Card to Host Data and Status




Figure 31: Pin assignment: SC/MMC card

8.13.6 BOOT-DIP-Switch

During a restart/reset, the BOOT-DIP-Switch is used to determine whether to perform a firmware download from the SD/MMC card or not.

- ❖ BOOT-DIP-Switch in position "ON" → firmware download requested
- ❖ BOOT-DIP-Switch in position "OFF" → firmware download not requested

When there is no SD/MMC card in the card slot of the servo positioning controller and the BOOT-DIP-Switch is in the position "ON" (firmware download requested), the error 29-0 is triggered after a restart/reset.

This error stops all further performances. This means that there is no communication possible via the serial interface (RS232) or USB.

8.14 Notes on safe and EMC-compliant installation

8.14.1 Definitions and terms

Electromagnetic compatibility (EMC) or electromagnetic interference (EMI) includes the following requirements:

- ❖ Sufficient **immunity** of an electrical installation or an electrical device against outside electrical, magnetic or electromagnetic interferences via cables or the ambient
- ❖ Sufficiently small **unwanted emission** of electrical, magnetic or electromagnetic interference from an electrical installation or an electrical device to other devices in the vicinity via cables or the ambient

8.14.2 General information on EMC

The interference emission and interference immunity of a device always depend on the entire drive concept consisting of the following components:

- ❖ Voltage supply
- ❖ Servo positioning controller
- ❖ Motor
- ❖ Electro mechanics
- ❖ Execution and type of wiring
- ❖ Superimposed control

In order to increase interference immunity and to decrease interference emissions the servo positioning controller ARS 2100 FS already comprises output chokes and mains filters, so that it can be operated without additional shielding and filtering devices in most applications.



The servo positioning controllers ARS 2100 FS are certified as per the product standard EN 61800-3 for electrical drive systems.

In most cases no external filtering is required (see below).

The conformity certificate for EMC directive 2004/108/EC is available from the manufacturer.



Caution!

This product can cause high-frequency interference in residential areas, which could require measures for radio interference suppression.

8.14.3 EMC areas: first and second environment

Proper installation and wiring of all connecting cables provided, the ARS 2100 FS servo positioning controllers fulfil the requirements of product standard EN 61800-3. This standard no longer refers to "classes", but to so-called environments. The first environment includes mains supply networks supplying residential buildings. The second environment includes mains supply networks exclusively supplying industrial buildings.

The following applies to ARS 2100 FS servo positioning controllers without external filter measures:

Table 48: EMC requirements: First and second environment

EMC type	Environment	Compliance with EMC requirements
Interference emission	First environment (domestic environment), C2	Motor cable length up to 25 m
	Second environment (industrial environment), C3	Motor cable length up to 25 m
Interference immunity	First environment (domestic environment), C2	Independent of motor cable length
	Second environment (industrial environment), C3	

8.14.4 EMC-compliant cabling

The following must be considered for an EMC-compliant setup of the drive system (see also *chapter 8 Electrical installation, page 81*):

- ❖ In order to keep the leakage currents and the losses in the motor connection cable as small as possible, the servo positioning controller ARS 2100 FS should be located as close to the motor as possible (see also the following *chapter 8.14.5 Operation with long motor cables, page 119*)
- ❖ Motor cable and angle encoder cable must be shielded
- ❖ The shield of the motor cable is connected to the housing of the servo positioning controller ARS 2100 FS (shield connection terminal). The cable shield also has to be connected to the associated servo positioning controller so that the leakage currents can flow back into the controller causing the leakage
- ❖ The mains-end PE connection is connected to the PE connection point of the supply connection [X9]
- ❖ The inner PE conductor of the motor cable is connected to the PE connection point of the motor connection [X6]
- ❖ The signal lines must be as far away from the power cables as possible. They should not be placed parallel. If intersections cannot be avoided, they should be perpendicular (that is at a 90° angle), if possible

- ❖ Unshielded signal and control lines should not be used. If their use is inevitable they should at least be twisted
- ❖ Even shielded cables will inevitably have short unshielded ends (unless shielded connector housings are used). In general, the following applies:
 - Connect the inner shields to the corresponding pins of the connectors; Maximum length 40 mm
 - Length of the unshielded cores 35 mm maximum
 - Connect the total shield on the controller side plane to the PE terminal; Maximum length 40 mm
 - Connect the total shield on the motor side plane to the connector housing or motor housing; Maximum length 40 mm

**DANGER!**

For safety reasons, all PE ground conductors must be connected prior to initial operation.

The EN 61800-5-1 regulations for protective earthing must be complied with during installation!

8.14.5 Operation with long motor cables



Compliance with the EMC standard EN 61800-3 is only guaranteed for motor cable lengths of up to 25 m. For cable lengths beyond this a new measurement of the interference emission may possibly be required.

In applications involving long motor cables and/or unsuitable motor cables with an inadvertently high cable capacity, the filters may be thermally overloaded. To avoid such problems we highly recommend the following procedure for applications that require long motor cables:

- ❖ With cable lengths of more than 25 m use only cables with a capacitance per unit length between the motor phase and the shield of less than 150 pF/m!
(Please contact the motor cable supplier, if necessary)
- ❖ For motor cable lengths of more than 25 m and up to 50 m the following derating applies regardless of the EMC qualification (see also *Table 7, Technical data: Cable specifications*):

PWM frequency	up to 5 kHz	5,5 kHz	6 kHz	7 kHz	8 kHz
Max. motor cable length	50 m	45 m	40 m	35 m	30 m

8.14.6 ESD protection



Caution!

Unassigned D-Sub connectors may cause damage to the device or other parts of the system due to ESD (electrostatic discharge).



To prevent such discharge, protective caps are available (for example Spoerle).

The servo positioning controller ARS 2100 FS has been designed to provide high interference immunity. For that reason, some individual functional blocks are electrically isolated. Inside the device the signals are transmitted via optocouplers.

The following isolated areas are distinguished:

- ❖ Power module with DC bus and mains input
- ❖ Control electronics with processing of analog signals
- ❖ 24 V supply and digital inputs and outputs

9 Additional requirements for the servo drives concerning the UL approval

This chapter gives further information concerning the UL approval of the ARS 2102 FS, ARS 2105 FS and ARS 2108 FS.

9.1 Circuit protection



In case of a required UL-certification the following data for the main fuse are to be considered:

Listed Circuit Breaker according to UL 489, rated 277 Vac, 16 A, SCR 10 kA

9.2 Wiring and environment regards

- ❖ Use 60/75 or 75°C copper (CU) wire only.
- ❖ The terminal tightening torque is 0.22...0.25 Nm.
- ❖ To be used in a Pollution Degree 2 environment only.

9.3 Motor temperature sensor



Motor overtemperature sensing is not provided by the drive according to UL.

When a UL-certification is required, then in order to prevent motor overtemperatures the servo drives may only be operated in connection with motors that are provided with an integrated motor temperature sensor. The sensor has to be connected to the servo drive and the temperature monitoring has to be activated accordingly on the software side.

10 Initial operation

10.1 General notes on connection



Since the laying of the connection cables is very important in terms of EMC, make sure to comply with the previous *chapter 8.14.4 EMC-compliant cabling (page 118)*!



DANGER!

Noncompliance with *chapter 2 Safety notes for electrical drives and controllers (page 17)* may result in property damage, person injury, electric shock or in extreme cases in death.

10.2 Tools / material

- ❖ Screwdriver for slotted head screws size 1
- ❖ Serial interface cable
- ❖ Angle encoder cable
- ❖ Motor cable
- ❖ Power supply cable
- ❖ Controller enabling cable

10.3 Connecting the motor

- ❖ Plug the connector of the motor cable into the corresponding socket of the motor and screw tight
- ❖ Plug PHOENIX connector into socket **[X6]** of the servo positioning controller
- ❖ Connect the PE line of the motor to the **PE** socket
- ❖ Plug the connector of the encoder cable into the encoder output socket of the motor and screw tight
- ❖ Plug the D-Sub connector into the socket **[X2A] Resolver** or **[X2B] Encoder** of the servo positioning controller and fasten the bolting screws
- ❖ Apply the shield of the motor or angle encoder cable over a large contact area with the aid of the shield connection clamp SK14
- ❖ Check all connections again

10.4 Connecting the servo positioning controller ARS 2100 FS to the power supply

- ❖ Make sure that the power supply has been switched off
- ❖ Plug the PHOENIX connector into socket **[X9]** of the servo positioning controller
- ❖ Connect the PE line of the mains to the **PE** socket
- ❖ Connect the 24 V connections to a suitable power supply unit
- ❖ Make mains supply connections
- ❖ Check all connections again

10.5 Connecting the PC (serial interface)

- ❖ Plug the D-Sub connector of the serial interface cable into the socket for the serial interface of the PC and fasten the bolting screws
- ❖ Plug the D-Sub connector of the serial interface cable into the socket **[X5] RS232/COM** of the servo positioning controller ARS 2100 FS and fasten the bolting screws
- ❖ Check all connections again

10.6 Connecting the PC (USB interface, alternative)

- ❖ Plug the plug A of the USB interface cable into the socket for the USB interface of the PC
- ❖ Plug the plug A of the USB interface cable into the socket **[X19] USB** of the ARS 2100 FS servo positioning controller
- ❖ Check all of the plug-and-socket connections once more

10.7 Checking operability

1. Make sure the controller enabling switch is turned off
2. Switch on the power supply of all devices. The READY / ERROR LED on the front of the servo positioning controller should now be active green

If the READY LED does not light green but red, there is a malfunction. If the seven-segment display indicates a number sequence, it is displaying an error message. You have to take care of the corresponding problem. In this case please continue with *chapter 11.2.2 Error messages (page 129)*. If the device displays nothing, follow these steps:

3. Switch off the power supply
4. Wait 5 minutes, so the DC bus can discharge
5. Check all connection cables
6. Check the functionality of the 24 V power supply
7. Switch the power supply back on

11 Service functions and error messages

11.1 Protection and service functions

11.1.1 Overview

The servo positioning controller ARS 2100 FS has a powerful sensor analysis, which monitors the proper functioning of the controller, power output stage, motor and communication with the outside world. All occurring errors are stored in an internal error memory. Most errors will cause the controller unit to shut down the servo positioning controller and the power output stage. They can only be switched on again after the error memory has been deleted by acknowledging the error and after the error has been eliminated or no longer exists.

A powerful sensor analysis and monitoring function provides operational safety:

- ❖ Measuring of motor temperature
- ❖ Measuring of power module temperature
- ❖ Detection of ground faults (PE)
- ❖ Detection of connections between two motor phases
- ❖ Detection of overvoltage in the DC bus
- ❖ Detection of errors with the internal voltage supply
- ❖ Failure of the supply voltage.

If the 24 V DC supply voltage fails, approx. 20 ms remain to save parameters and shut down the controller properly for example.

11.1.2 Overcurrent and short-circuit monitoring

The overcurrent and short-circuit monitoring detects short-circuits between two motor phases as well as short-circuits at the motor output terminals against the positive and negative reference potential of the DC bus and against PE. If the error monitoring detects an overcurrent, the power output stage will be shut down immediately to guarantee the ability to withstand short-circuits.

11.1.3 Overvoltage monitoring for the DC bus

This monitor responds, if the DC bus voltage exceeds the operating voltage range. The power output stage will be shut down.

11.1.4 Temperature monitoring of the heat sink

The heat sink temperature of the power output stage is measured with a linear temperature sensor. The temperature limit varies from device to device.

11.1.5 Monitoring of the motor

The servo positioning controller ARS 2100 FS has the following protective functions to monitor the motor and the connected encoder:

Monitoring of the encoder: An error of the shaft encoder leads to the shut-down of the power output stage. In the case of resolvers, for example the encoder signal is monitored. In the case of incremental encoders the commutation signals are checked. Other “intelligent” encoders provide further means of error detection.

Measurement and monitoring of the motor temperature: The ARS 2100 FS servo positioning controller has a digital and analogue input for measuring and monitoring the motor temperature. The analog signal detection also supports non-linear sensors. The following temperature sensors can be selected:

- At [X2A], [X2B] and [X6]: Input for PTCs, NTCs, normally closed contacts, normally open contacts and analog sensors, type KTY.

11.1.6 I²t monitoring

The servo positioning controller ARS 2100 FS comprises an I²t monitoring to limit the average power loss in the power output stage and in the motor. Since the occurring power loss in the power electronics and in the motor in the worst case increases square with the current, the squared current value is assumed as the measure for the power loss.

11.1.7 Power monitoring for the brake chopper

Power monitoring for the internal brake resistor is implemented in the operating software.

When the power monitoring “I²t brake chopper” reaches 100% the power of the internal brake resistor is switched back to the rated output power.

11.1.8 I²t monitoring for the PFC stage

I²t monitoring for the PFC is implemented in the operating software (except the ARS 2108 FS).

11.1.9 Initial operation status

Servo positioning controllers, which are sent to Metronix for service, will be equipped with a different firmware and other parameters for testing purposes.

Before the next initial operation at the customer the servo positioning controller ARS 2100 FS must be parameterized again. The parameterisation software Metronix ServoCommander[®] queries the initial operation status and asks the user to parameterize the servo positioning controller. At the same time the device shows an “A” on the seven-segment display to indicate that it is ready but not yet parameterized.

11.1.10 Rapid discharge of the DC bus

If the system detects a failure of the mains supply, the DC bus is rapidly discharged within the safety period in accordance with EN 60204-1.

Delayed activation of the brake chopper according to power classes in the case of parallel operation and mains supply failure ensures that the main energy during rapid discharge of the DC bus is taken over through the braking resistors of the higher power classes.

11.1.11 Operating hours counter






An operating hours counter is implemented, which has been designed for at least 200 000 operating hours. The operating hours counter is displayed in the parameterisation software Metronix ServoCommander[®].

11.2 Display of operating mode and error messages

11.2.1 Operating mode and error display

The system supports a seven-segment display. The following table describes the display and the meaning of the symbols shown:

Table 49: Operating mode and error display

Display	Meaning
	In the operation mode speed control the outer bars “rotate”, depending on the actual speed resp. the actual position of the rotor.
	If the drive is enabled, the center bar of the seven-segment display is on, too.
	The servo positioning controller ARS 2000 FS still has to be parameterised (seven-segment display = “A”).
	Operating mode torque control, the two bars on the left hand of the display are on (seven-segment display = “I”).
P xxx	Positioning, “xxx” stands for the position number. The numbers are successively indicated.
PH x	Homing (“x” stands for the currently active phase of the homing run). 0 : Search phase 1 : Crawling phase 2 : Positioning to zero position The numbers are successively indicated.
E xxy	Error message with index “xx” and subindex “y”. The numbers are successively indicated.
-xxy-	Warning message with Index “xx” and subindex “y”. A warning is displayed at least twice on the seven-segment-display. The numbers are successively indicated.
	Option “STO” (Safe Torque-Off) active for the ARS 2000 FS devices. (seven-segment display = “H”, blinking with a frequency of 2 Hz)

11.2.2 Error messages

If an error occurs, the servo positioning controller ARS 2000 FS will cyclically show an error message in its seven-segment display. The error message is comprised of an E (for Error), a main index (xx) and a sub index (y), for example: **E 0 1 0**.

Warnings have the same code numbers as error messages. As a distinguishing feature, warnings have a centre bar before and after the number, for example **- 1 7 0 -**.

The following *Table 50 Error messages* summarizes the meaning of the messages and the corresponding measures.

The error messages with the main index 00 do not reflect run time errors. They contain information and in general there are no measures required by the user. They appear only in the error buffer and are not displayed on the seven-segment display.

Table 50: Error messages

Error message		Meaning of the error message	Measures
Main index	Sub index		
00	0	Invalid error	Information: Only for connected service module. An invalid (corrupted) entry in the error buffer has been marked by this error number. The system time entry is set to 0. No measures required.
	1	Invalid error detected and corrected	Information: Only for connected service module. An invalid (corrupted) error entry has been detected in the permanent event memory and corrected.
	2	Error cleared	Information: The active errors have been acknowledged. No measures required.
	4	Serial number/device type changed (module change)	Information: Only for connected service module. An exchangeable error buffer has been plugged into another device. No measures required.
	7	Log add-on: Permanent event memory and FSM module	Information: Entry in permanent event memory. "An additional record was found." No measures required.
	8	Servo drive switched on	Information: Entry in permanent event memory. No measures required.
	9	Servo drive safety parameters revised	Information: Entry in permanent event memory. No measures required.
	11	FSM: Module change (previous type): Permanent event memory and FSM module	Information: Entry in permanent event memory. No measures required.
	12	FSM: Module change (current type): Permanent event memory and FSM module	Information: Entry in permanent event memory. No measures required.
	21	Log entry from the FSM-MOV: Permanent event memory and FSM module	Information: Entry in permanent event memory. No measures required.
01	0	Stack overflow	Incorrect firmware? If necessary, reload the standard firmware. Contact the Technical Support.

Error message		Meaning of the error message	Measures
Main index	Sub index		
02	0	Undervoltage of the DC bus circuit	Error priority set too high? Check the power supply. Check (measure) the DC bus circuit voltage. Check the response threshold of the DC bus circuit monitoring system.
03	0	Motor overtemperature (analogue)	Motor too hot? Check the parameterization (current controller, current limits).
	1	Motor overtemperature (digital)	Suitable sensor? Sensor defective? Check the parameterization of the sensor or the characteristic curve of the sensor. If the error occurs also when the sensor is bypassed, return the device to our sales partner.
	2	Motor Overtemperature (analogue): wire break	Check the connecting cables of the temperature sensor (broken wire). Check the parameterisation of wire break detection system (threshold value).
	3	Motor overtemperature (analogue): short circuit	Check the connecting cables of the temperature sensor (short circuit). Check the parameterisation of the short-circuit monitoring system (threshold value).
04	0	Power module overtemperature	Plausible temperature indication? Check the installation conditions. Fan filter mats dirty?
	1	DC bus circuit overtemperature	Device fan defective?
05	0	Failure of internal voltage 1	Disconnect the device from the entire periphery and check whether the error is still present after a reset. If the error is still present, return the device to your sales partner.
	1	Failure of internal voltage 2	
	2	Driver supply failure	
	3	Undervoltage of the digital I/Os	Check the outputs for short circuits or specific load. If necessary, contact the Technical Support.
	4	Overcurrent of the digital I/Os	
	5	Technology module supply voltage failure	Technology module defective? Replace the technology module. If necessary, contact the Technical Support.

Error message		Meaning of the error message	Measures
Main index	Sub index		
	6	X10, X11 and RS232 supply voltage failure	Check the pin assignment of the connected peripheral equipment. Check the connected peripheral equipment for short-circuits.
	7	Safety module internal voltage failure	Safety module defective? Replace the safety module. If the error persists, please send the servo positioning controller to our sales partner.
	8	Failure of internal voltage 15 V	Please return the device to our sales partner.
	9	Faulty encoder supply	
06	0	Short circuit in the power output stage	Motor defective? Short circuit in the cable? Power output stage defective?
	1	Brake chopper overcurrent	Check the external braking resistor for short circuits. Check whether the resistance value is too small. Check the brake chopper output of the device.
07	0	Overvoltage in the DC bus circuit	Check the connection to the braking resistor (internal/external). External braking resistor overloaded? Check the rating.
08	0	Resolver angle encoder error	See items 08-2 .. 08-8.
	1	Sense of rotation of the serial and incremental position evaluation systems not identical	A and B track mixed up? Check / correct the connection of the tracks.
	2	Incremental encoder Z0 track signals error	Angle encoder connected? Angle encoder cable defective? Angle encoder defective? Check the configuration of the angle encoder interface. The encoder signals are disturbed: Check the installation for compliance with EMC recommendations.
	3	Incremental encoder Z1 track signals error	
	4	Digital incremental encoder track signals error	
	5	Incremental encoder Hall generator signals error	
	6	Angle encoder communication error	

Error message		Meaning of the error message	Measures
Main index	Sub index		
	7	Incorrect signal amplitude of the incremental track	<p>The internal monitoring system of the angle encoder at [X2B] has detected an error.</p> <p>Communication error?</p> <p>If necessary, contact the Technical Support.</p>
	8	Internal angle encoder error	
	9	Encoder at [X2B] not supported	
09	0	Old encoder parameter set (type ARS)	Save the data in the encoder EEPROM (reformatting).
	1	Encoder parameter set cannot be decoded	<p>Angle encoder defective?</p> <p>Check the configuration of the angle encoder interface.</p> <p>The encoder signals are disturbed.</p> <p>Check the installation for compliance with the EMC recommendations.</p>
	2	Unknown encoder parameter set version	Save the data into the encoder again.
	3	Corrupted data structure in encoder parameter set	If necessary, re-determine the data and save it in the encoder again.
	4	EEPROM data: faulty customer-specific configuration	<p>Motor repaired: Perform a homing run and save the data in the angle encoder. Then, save to the basic device.</p> <p>Motor replaced: Parameterise the basic device, perform a homing run, save the data in the angle encoder, and then save to the basic device.</p>
	5	Read/Write Error EEPROM parameter set	Please contact the Technical Support.
	7	Write protected EEPROM of the angle encoder	Please contact the Technical Support.
	9	Insufficient capacity of the angle encoder EEPROM	
10	0	Overspeed (motor overspeed protection)	<p>Check the offset angle.</p> <p>Check the parameterisation of the limit value.</p>

Error message		Meaning of the error message	Measures
Main index	Sub index		
11	0	Homing: error during the start	Controller not enabled.
	1	Error during a homing run	The homing run has been interrupted, for example because the controller enabling has been cancelled.
	2	Homing: no valid index pulse	The required index pulse is not provided.
	3	Homing: timeout	The maximum time that has been parameterised for homing has been reached before the homing run could be completed. Check the parameterisation of the time.
	4	Homing: wrong/invalid limit switch	The associated limit switch is not connected. Limit switches mixed up? Move the limit switch so that it is not located in the area of the index pulse.
	5	Homing: l²t/following error	Unsuitable parameterisation of the acceleration ramps. An invalid stop has been reached, for example because no reference switch has been installed. Check the connection of a reference switch. If necessary, contact the Technical Support.
	6	Homing: end of search distance reached	The maximum distance for the homing run has been covered, but the reference point or the target of the homing run have not been reached.
	7	Homing: Encoder difference control	The deviation fluctuates, e.g. due to gear slackness. If necessary, increase the shut-down threshold. Check actual-value encoder connection.
12	0	CAN: two nodes with the same ID	Check the configuration of the devices that are connected to the CAN bus.
	1	CAN: communication error, bus OFF	Check the cabling (compliance with the cable specification, cable break, maximum cable length exceeded, correct terminating resistors, cable shield earthed (grounded), all signals connected?). Replace the device. If the error has been successfully eliminated by replacing the device, return the replaced device to your sales partner.

Error message		Meaning of the error message	Measures
Main index	Sub index		
	2	CAN: CAN communication error during the transmission	<p>Check the cabling (compliance with the cable specification, cable break, maximum cable length exceeded, correct terminating resistors, cable shield earthed (grounded), all signals connected?).</p> <p>Check the start sequence of the application.</p> <p>Replace the device.</p> <p>If the error has been successfully eliminated by replacing the device, return the replaced device to your sales partner.</p>
	3	CAN: CAN communication error during the reception	
	4	CAN: node Guarding	<p>Align the cycle time of the remote frames with the PLC or failure of the PLC.</p> <p>Signals disturbed?</p>
	5	CAN: RPDO too short	Check the configuration.
	9	CAN: protocol error	<p>Check the command syntax of the control (record the data traffic).</p> <p>Please contact the Technical Support.</p>
13	0	CAN bus timeout	Check the CAN parameterisation.
14	0	Insufficient power supply for the identification	<p>Check the power supply.</p> <p>Check the motor resistor.</p>
	1	Current controller identification: insufficient measurement cycle	The automatic parameter identification process delivers a time constant beyond the value range that can be parameterised. The parameters must be optimised manually.
	2	Power output stage could not be enabled	The power output stage has not been enabled. Check the connection of DIN 4.
	3	Power output stage prematurely disabled	The power output stage has been disabled during a running identification process (e.g. via DIN 4).
	4	Selected resolver type not supported by the identification system	<p>The identification cannot be performed with the present angle encoder settings.</p> <p>Check the configuration of the angle encoder. If necessary, contact the Technical Support.</p>

Error message		Meaning of the error message	Measures
Main index	Sub index		
	5	Index pulse not found	The index pulse could not be found after the maximum permissible number of electrical rotations. Check the index pulse signal. Check the angle encoder settings.
	6	Invalid Hall signals	Check the connection. Check the data sheet as to whether the encoder provides 3 Hall signals with 120° or 60° segments. If necessary, contact the Technical Support.
	7	Identification not possible	Check the DC bus circuit voltage. Check the wiring of the motor/encoder system. Motor blocked (holding brake not released)?
	8	Invalid number of pole pairs	The calculated number of pole pairs is beyond the parameterisation range. Check the data sheet of the motor. If necessary, contact the Technical Support.
15	0	Division by 0	Please contact the Technical Support.
	1	Out of range error	
	2	Mathematical underflow	
16	0	Incorrect program execution	Please contact the Technical Support.
	1	Illegal interrupt	
	2	Initialization error	
	3	Unexpected state	
17	0	Max. following error exceeded	Increase the error window. The parameterisation of the acceleration is too high.
	1	Encoder difference monitoring	External angle encoder not connected or defective? The deviation fluctuates, e.g. due to gear slackness. If necessary, increase the shut-down threshold.
	2	Current jerk control	Please contact the Technical Support.

Error message		Meaning of the error message	Measures
Main index	Sub index		
18	0	Analogue motor temperature warning threshold	<p>Motor too hot? Check the parameterisation (current controller, current limits).</p> <p>Suitable sensor?</p> <p>Sensor defective?</p> <p>Check the parameterisation of the sensor or the characteristic curve of the sensor.</p> <p>If the error occurs also when the sensor is bypassed, return the device to our sales partner.</p>
21	0	Error 1 current measurement U	Please contact the Technical Support.
	1	Error 2 current measurement V	
	2	Error 2 current measurement U	
	3	Error 1 current measurement V	
22	0	PROFIBUS: incorrect initialization	<p>Technology module defective?</p> <p>Replace the technology module.</p> <p>If necessary, contact the Technical Support.</p>
	1	PROFIBUS: reserved	Please contact the Technical Support.
	2	PROFIBUS: communication error	<p>Check the slave address.</p> <p>Check the bus terminators.</p> <p>Check the cabling.</p>
	3	PROFIBUS: invalid slave address	Incorrect slave address. Please select another slave address.
	4	PROFIBUS: error in value range	<p>Mathematical error during the conversion of physical units. The value range of the data and of the physical units do not match (fieldbus display units).</p> <p>If necessary, contact the Technical Support.</p>
23	0	No consumable record	Position save and restore failed, homing required.
	1	Record with invalid checksum	
	2	Flash content inconsistent	
25	0	Invalid device type	Please return the device to our sales partner.
	1	Device type not supported	

Error message		Meaning of the error message	Measures
Main index	Sub index		
	2	HW revision not supported	Check the firmware version. If necessary, request an update from the Technical Support.
	3	Device functionality restricted!	Please return the device to our sales partner.
	4	Invalid power module type	Check the firmware version. If necessary, request an update from the Technical Support.
	5	Incompatibility firmware / hardware. The firmware is not suitable for the device.	Check the firmware version. If necessary, request an update from the Technical Support.
26	0	No user parameter set	Load the default parameter set.
	1	Checksum error	If the error is still present, return the device to our sales partner.
	2	Flash: write error	Please return the device to our sales partner.
	3	Flash: delete error	
	4	Flash: error in the internal flash	Reload the firmware.
	5	No calibration data	If necessary, contact the Technical Support.
	6	No user position data set	Save and reset. Load the default parameter set. If the error occurs again, contact the Technical Support.
	7	Error in data tables (CAM)	Load the default parameter set and perform a start-up procedure. If necessary, reload the parameter set. If necessary, contact the Technical Support.
27	0	Following error warning threshold	Check the parameterisation of the following error. Motor blocked?
28	0	No operating hours counter	Acknowledge the error.
	1	Operating hours counter: write error	If the error occurs again, contact the Technical Support.
	2	Operating hours counter corrected	
	3	Operating hours counter converted	

Error message		Meaning of the error message	Measures
Main index	Sub index		
29	0	No SD card	Please contact the Technical Support
	1	SD card: initialisation error	
	2	SD card: data error	
	3	SD card: write error	
	4	SD card: firmware download error	
30	0	Internal conversion error	Please contact the Technical Support.
31	0	Motor I ² t	Motor blocked? Check the power rating of the drive.
	1	Servo positioning controller I ² t	Check the power rating of the drive package.
	2	PFC I ² t	Check the power rating of the drive. Select operation without PFC?
	3	Braking resistor I ² t	Braking resistor overloaded. Use external braking resistor?
	4	I ² t active power overload	Reduce the active power of the drive.
32	0	DC bus circuit charging time exceeded	Bridge for the internal brake resistor installed? Check the connection of the external braking resistor. If necessary, contact the Technical Support.
	1	Undervoltage for active PFC	Check whether the power supply complies with the nominal data.
	5	Brake chopper overload The DC bus circuit could not be discharged.	Check the ON/OFF cycles.
	6	DC bus circuit discharge time exceeded	Bridge for the internal brake resistor installed? Check the connection of the external braking resistor. If necessary, contact the Technical Support.
	7	No power supply for the controller enable signal	No DC bus circuit voltage? Check the power supply. If necessary, contact the Technical Support.

Error message		Meaning of the error message	Measures
Main index	Sub index		
	8	Power supply failure during the controller enabling process	Check the power supply.
	9	Phase failure	
33	0	Following error, encoder emulation	Check the settings of the incremental encoder emulation (number of lines). If necessary, contact the Technical Support.
34	0	No synchronisation via the field bus	Failure of synchronization messages from master?
	1	Field bus synchronisation error	Failure of synchronization messages from master? Insufficient synchronisation interval?
35	0	Overspeed protection of the linear motor	The encoder signals are disturbed. Check the installation for compliance with EMC recommendations.
	5	Error during the determination of the commutation position	The selected method is not suitable for the motor. Please contact the Technical Support.
36	0	Parameter limited	Check the user parameter set.
	1	Parameter not accepted	
37	0	Sercos: received data disturbed	Check the sercos wiring (clean the optical waveguide, for example). Check the luminous power settings. Check the baud rate.
	1	Sercos: optical waveguide loop interrupted	Check the sercos wiring (optical waveguide) for breaks. Check the connections.
	2	Sercos: double MST failure	Check the sercos wiring (optical waveguide). Check the control system (are all of the MSTs being transmitted?)
	3	Sercos: illegal phase specification in the MST info	Check the program in the Sercos master.
	4	Sercos: double MDT failure	Check the sercos wiring (optical waveguide). Check the control system (are all of the MDTs being transmitted?)

Error message		Meaning of the error message	Measures
Main index	Sub index		
	5	Sercos: unknown operation mode selected	Check the settings for the operating modes in the IDN S-0-0032 to S-0-0035.
	6	Sercos: T3 invalid	Increase the baud rate. Shift the point of time T3 manually.
38	0	sercos prog.: SERCON initialisation error	Technology module defective? Replace the technology module. If necessary, contact the Technical Support.
	1	Sercos: no technology module present	Technology module plugged in correctly? Technology module defective? Replace the technology module. If necessary, contact the Technical Support.
	2	Sercos: defective technology module	Replace the technology module. If necessary, contact the Technical Support.
	3	Sercos: S-0-0127: invalid data in S-0-0021	Check the configuration (cyclic data for MDT and AT). Time slot calculation by the master.
	4	Sercos: S-0-0127: illegal IDNs in AT or MDT	Check the configuration (cyclic data transfer).
	5	Sercos: S-0-0128: invalid data in S-0-0022	Check the weighting settings. Check the operating mode settings. Check the internal/external angle encoder settings.
	6	Sercos: S-0-0128: faulty weighting parameters	Check the weighting settings.
	7	Sercos: Invalid IDN in S-0-0026 / S-0-0027	Check the configuration of the signal status and signal control word (S-0-0026 / S-0-0027).
	8	Sercos: error during the conversion	Check the weighting settings. If necessary, contact the Technical Support.
	9	Sercos: SERCON 410b mode active	Technology module defective? Replace the technology module.

Error message		Meaning of the error message	Measures
Main index	Sub index		
39	0	Sercos: List S-0-0370: invalid configuration of the MDT Data container	Please contact the Technical Support.
	1	Sercos: List S-0-0371: invalid configuration of the AT-Data container	
	2	Sercos: error in the cyclic channel MDT	
	3	Sercos: error in the cyclic channel AT	
	4	Sercos: error in the cyclic data container MDT	
	5	Sercos: error in the cyclic data container AT	
40	0	Negative SW limit switch reached	Check the negative range limit.
	1	Positive SW limit switch reached	Check the positive range limit.
	2	Target position beyond the negative SW limit switch	The start of a positioning run has been suppressed, since the target is located beyond the respective software limit switch. Check the target data. Check the positioning range.
	3	Target position beyond the positive SW limit switch	
41	0	Path program: synchronisation error	Check the parameterization. If necessary, contact the Technical Support.
42	0	Positioning: no follow-up position: stop	The positioning target cannot be reached with the current positioning options or boundary conditions. Check the positioning parameters.
	1	Positioning: reversal of rotation not permissible: stop	
	2	Positioning: reversal of rotation not permissible after a stop	

Error message		Meaning of the error message	Measures
Main index	Sub index		
	3	Positioning start rejected: incorrect operating mode	The change of the mode of operation could not be performed by the position set.
	4	Positioning start rejected: homing required	Reset the optional parameterisation "homing required". Perform a new homing run.
	5	Rotary axis: direction of rotation not permissible	In accordance with the selected mode, the calculated direction of rotation of the rotary axis is not permissible. Check the selected mode.
	9	Error during the start of the positioning run	Check the speed and acceleration parameters.
43	0	Limit switches: negative setpoint blocked	The drive has left the intended motion range. Technical defect in the system? Check the limit switches.
	1	Limit switches: positive setpoint blocked	
	2	Limit switches: positioning suppressed	
44	0	Error in the cam disc tables	Check whether the index has been assigned correctly. Check whether there are cam discs present in the device.
	1	Cam disc: general homing error	Ensure that the drive has been homed prior to the activation of the cam disc. Delete the "homing required" option. Ensure that a cam disc cannot be started during a homing run.
47	0	Timeout (set-up mode)	Check the processing of the request by the PLC. Speed threshold too low or timeout too small?
48	0	Drive not referenced	Switch to positioning and perform a homing run.
50	0	CAN: too many synchronous PDOs	Deactivate the PDOs or increase the SYNC interval. The maximum number of PDOs must not be greater than the factor tp between the position controller and IPO (menu: Parameters/Controller parameters/Cycle times).
	1	SDO error occurred	Please contact the Technical Support.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
51	0	No or unknown FSM module or faulty driver supply	Cause:	Internal voltage error of the safety module or of the fieldbus activation module.
			Action:	Module presumably defective. If possible, replace with another module.
			Cause:	No safety module detected or unknown module type.
			Action:	❖ Install safety or fieldbus activation module appropriate for the firmware and hardware. ❖ Load firmware appropriate for the safety or fieldbus activation module, see type designation on the module.
	2	FSM: different module type	Cause:	Type or revision of the module does not fit the project planning.
			Action:	❖ Check whether correct module type and correct version are being used. ❖ With module replacement: Module type not yet configured. Accept currently integrated safety or fieldbus activation module.
	3	FSM: different module version	Cause:	Type or revision of the module is not supported.
			Action:	❖ Install safety or fieldbus activation module appropriate for the firmware and hardware. ❖ If only a module with a more recent version is available: Load firmware that is appropriate for the module, see type designation on the module.
			Cause:	The module type is correct but the module version is not supported by the basic device.
			Action:	❖ Check module version; if possible use module of same version after replacement. Install suitable safety or fieldbus activation module for the firmware and hardware. ❖ If only a module with a more recent version is available: Load firmware that is appropriate for the module, see type designation on the module.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
	4	FSM: Fault in SSIO communication	Cause:	Error in the internal communication connection between the basic device and the safety module.
			Action:	❖ Identify interfering radiators in the environment of the servo drive. ❖ Replace module or basic device. ❖ Please contact the Technical Support.
	5	FSM: Fault in FSM break control	Cause:	Internal hardware error (brake activation control signals) of the safety module or fieldbus activation module.
			Action:	Module presumably defective. If possible, replace with another module.
			Cause:	Error in brake driver circuit section in the basic device.
			Action:	Basic device presumably defective. If possible, replace with another basic device.
	6	FSM: Non-identical module serial number	Cause:	Serial number of currently connected safety module is different from the stored serial number.
			Action:	Error only occurs after replacement of the FSM 2.0 MOV. ❖ With module replacement: Module not yet configured. Accept currently integrated FSM 2.0 MOV. ❖ Check parameterisation of the FSM 2.0 – MOV with regard to the application as modules have been replaced.
52	1	Safety function: Discrepancy time overrun	Cause:	Control ports STO-A and STO-B are not actuated simultaneously.
			Action:	Check discrepancy time.
			Cause:	Control ports STO-A and STO-B are not wired in the same way.
			Action:	Check circuitry of the inputs.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
			Cause:	Upper and lower switch supply voltage not simultaneously activated (discrepancy time exceeded) <ul style="list-style-type: none"> – Error in control / external circuitry of safety module. – Error in safety module.
			Action:	❖ Check circuitry of the safety module <ul style="list-style-type: none"> – are the inputs STO-A and STO-B switched off on two channels and simultaneously? ❖ Replace safety module if you suspect it is faulty.
	2	Safety function: Failure of driver supply with active PWM activation	Cause:	Failure of driver supply voltage with active PWM.
			Action:	The safe status was requested with power output stage enabled. Check integration into the safety-orientated interface.
	3	FSM: Rotational speed limits in basic device overlap	Cause:	Basic device reports error if the currently requested direction of movement is not possible because the safety module has blocked the setpoint value in this direction. Error may occur in connection with the SSFx safe speed functions if an asymmetrical speed window is used where one limit is set to zero. In this case, the error occurs when the basic device moves in the blocked direction in the Positioning mode.
			Action:	Check application and change if necessary.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
53	0	USF0: Safety condition violated	Cause:	Violation of monitored speed limits of the SSF0 in operation / when USF0 / SSF0 requested.
			Action:	<p>Check when the violation of the safety condition occurs:</p> <ul style="list-style-type: none"> a) During dynamic braking to safe rotational speed. b) After the drive has reached the safe speed. <ul style="list-style-type: none"> ❖ With a) Check of braking ramp – record measuring data - can the drive follow the ramp? ❖ Change parameters for the slowdown ramp or start time / delay times for monitoring. <p>With b) Check how far the current speed is from the monitored limit speed; increase distance if necessary (parameter in safety module) or correct speed specified by controller.</p>
	1	USF1: Safety condition violated	Cause:	Violation of monitored speed limits of the SSF1 in operation / when USF1 / SSF1 requested.
			Action:	See USF0, error 53-0.
	2	USF2: Safety condition violated	Cause:	Violation of monitored speed limits of the SSF2 in operation / when USF2 / SSF2 requested.
			Action:	See USF0, error 53-0.
	3	USF3: Safety condition violated	Cause:	Violation of monitored speed limits of the SSF3 in operation / when USF3 / SSF3 requested.
			Action:	See USF0, error 53-0.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
54	0	SBC: Safety Condition Violated	Cause:	Brake should engage; no feedback received within the expected time.
			Action:	<ul style="list-style-type: none"> ❖ Check how the feedback signal is configured – was the correct input selected for the feedback signal? ❖ Does the feedback signal have the correct polarity? ❖ Check whether the feedback signal is actually switching. ❖ Is the parameterised time delay for the analysis of the feedback signal appropriate to the brake used (measure switching time if necessary)?
	2	SS2: Safety Condition Violated	Cause:	Actual speed outside permitted limits for too long.
			Action:	<p>Check when the violation of the safety condition occurs:</p> <ul style="list-style-type: none"> a) During dynamic braking to zero. b) After the drive has reached zero speed. ❖ With a) Check of braking ramp – record measuring data - can the drive follow the ramp? Change parameters for the slowdown ramp or start time / delay times for monitoring. ❖ With a) If the option “Trigger basic device quick stop” is activated: Check of the basic device’s quick stop ramp. ❖ With b) Check whether the drive continues to oscillate after reaching the zero speed or remains at idle and stable – increase monitoring tolerance time if necessary. ❖ With b) If the actual speed value is very noisy at rest. Check and if necessary adjust expert parameters for speed recording and detection of idling

Error message		Meaning of the error message	Measures	
Main index	Sub index			
	3	SOS: Safety Condition Violated	Cause:	<ul style="list-style-type: none"> – Angle encoder analysis reports “Motor running” (actual speed exceeds limit). – Drive has rotated out of its position since reaching the safe state.
			Action:	<ul style="list-style-type: none"> ❖ Check the position tolerance for the SOS monitoring and increase if necessary, if this is permissible. ❖ If the actual speed value is very noisy when at rest: Check and if necessary adjust expert parameters for speed recording and detection of idling.
	4	SS1: Safety Condition Violated	Cause:	Actual speed is outside of permitted limits for too long.
			Action:	<p>Check when the violation of the safety condition occurs:</p> <ul style="list-style-type: none"> a) During dynamic braking to zero. b) After the drive has reached zero speed. <ul style="list-style-type: none"> ❖ With a) Check of braking ramp – record measuring data - can the drive follow the ramp? Change parameters for the slowdown ramp or start time / delay times for monitoring. ❖ With a) If the option “Trigger basic device quick stop” is activated: Check of the basic device’s quick stop ramp. ❖ With b) Check whether the drive continues to oscillate after reaching the zero speed or remains at idle and stable – increase monitoring tolerance time if necessary. ❖ With b) If the actual speed value is very noisy when at rest: Check and if necessary adjust expert parameters for speed recording and detection of standstill.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
	5	STO: Safety Condition Violated	Cause:	Internal hardware error (voltage error) of the safety module.
			Action:	Module presumably defective. If possible, replace with another module.
			Cause:	Error in driver circuit section in the basic device.
			Action:	Basic device presumably defective. If possible, replace with another basic device.
			Cause:	No feedback received from basic device to indicate that output stage was switched off.
			Action:	Check whether the error can be acknowledged and whether it occurs again upon a new STO request – if yes: Basic device is presumably faulty. If possible, replace with another basic device.
	6	SBC: Brake not vented for > 24 hrs	Cause:	Error occurs when SBC is requested and the brake has not been opened by the basic device in the last 24 hours.
			Action:	<ul style="list-style-type: none"> ❖ If the brake is actuated via the brake driver in the basic device [X6]: The brake must be energised at least once within 24 hours before the SBC request because the circuit breaker check can only be performed when the brake is switched on (energised). ❖ Only if brake control takes place via DOUT4x and an external brake controller: Deactivate 24 hr monitoring in the SBC parameters if the external brake controller allows this.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
	7	SOS: SOS requested > 24 hrs	Cause:	If SOS is requested for more than 24 hours, the error is triggered.
			Action:	Terminate SOS and move axle at least once during this time.
55	0	No actual rotational speed / position value available or idle > 24 hrs	Cause:	<ul style="list-style-type: none"> Subsequent error when a position encoder fails. Safety function SSF, SS1, SS2 or SOS requested and actual rotational speed value is not valid.
			Action:	Check the function of the position encoder(s) (see following error).
	1	SINCOS encoder [X2B] - Tracking signal error	Cause:	<ul style="list-style-type: none"> Vector length $\sin^2 + \cos^2$ is outside the permissible range. The amplitude of one of the two signals is outside the permissible range. Offset between analogue and digital signal is greater than 1 quadrant.
			Action:	Error may occur with SIN/COS and Hiperface encoders. <ul style="list-style-type: none"> ❖ Check the position encoder. ❖ Check the connection wiring (broken wire, short between two signals or signal / screening). ❖ Check the supply voltage for the position encoder. ❖ Check the motor cable / screening on motor and drive side – EMC malfunctions may trigger the error.
	2	SINCOS encoder [X2B] - Standstill > 24 hrs	Cause:	Input signals of the SinCos encoder have not changed by a minimum amount for 24 hours (when safety function is requested).
			Action:	Terminate SS2 or SOS and move axle at least once during this time.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
	3	Resolver [X2A] - Signal error	Cause:	<ul style="list-style-type: none"> – Vector length $\sin^2 + \cos^2$ is outside the permissible range. – The amplitude of one of the two signals is outside the permissible range. – Input signal is static (same values to right and left of maximum).
			Action:	<ul style="list-style-type: none"> ❖ Check the resolver. ❖ Check the connection wiring (broken wire, short between two signals or signal / screening). ❖ Check for a failure of the primary radiator signal ❖ Check the motor and encoder cable / screening on motor and drive side. EMC malfunctions can trigger the error.
	7	Other encoder [X2B] - Faulty angle information	Cause:	<ul style="list-style-type: none"> – “Angle faulty” message is sent from basic device when status lasts for longer than the allowed time. – Encoder at X2B is analysed by the basic device. – Encoder is faulty.
			Action:	<ul style="list-style-type: none"> ❖ Check the position encoder at X2B. ❖ Check the connection wiring (broken wire, short between two signals or signal / screening). ❖ Check the supply voltage for the ENDAT encoder. ❖ Check the motor cable / screening on motor and drive side – EMC malfunctions may trigger the error.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
	8	Impermissible acceleration detected	Cause:	<ul style="list-style-type: none"> – Error in connected position encoder. – EMC malfunctions affecting the position encoder. – Impermissibly high acceleration rates in the movement profiles. – Acceleration limit parameterised too low. – Angle jump after reference movement in the position data transmitted from the basic device to the safety module.
			Action:	<ul style="list-style-type: none"> ❖ Check the connected position encoder: If further error messages occur in conjunction with the encoders, then eliminate their cause first. ❖ Check the motor and encoder cable / screening on motor and drive side. EMC malfunctions can trigger the error. ❖ Check the setpoint specifications / Movement profiles of the controller: Do they contain impermissibly high temperatures above the limit value for acceleration monitoring (P06.07)? ❖ Check whether the limit value for acceleration monitoring was parameterised correctly - the limit value (P06.07) should be at least 30% ... 50% above the maximum acceleration actually occurring. ❖ In case of an angle jump in the position data transmitted from the basic device - Acknowledge error once.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
56	8	Rotational speed / angle difference, encoder 1 - 2	Cause:	<ul style="list-style-type: none"> Rotational speed difference between encoder 1 and 2 of one μC outside the permissible range for longer than the allowed time. Angle difference between encoder 1 and 2 of one μC outside the permissible range for longer than the allowed time.
			Action:	<ul style="list-style-type: none"> ❖ Problem may occur if two position encoders are used in the system and they are not "rigidly coupled". ❖ Check for elasticity or looseness, improve mechanical system. ❖ Adjust the expert parameters for the position comparison if this is acceptable from an application point of view.
	9	Error, cross-comparison of encoder analysis	Cause:	Cross-comparison between $\mu\text{C}1$ and $\mu\text{C}2$ has detected an angle difference or rotational speed difference or difference in capture times for the position encoders.
			Action:	Timing disrupted. If the error occurs again after a reset, the safety module is presumably faulty.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
57	0	Error, I/O self test (internal/external)	Cause:	<ul style="list-style-type: none"> – Internal error of digital inputs DIN40 ... DIN43 (detected via internal test signals). – Error at brake output at X6 (signalling, detected by test pulses). – Internal error of brake output (detected via internal test signals). – Internal error of digital outputs DOUT40 – DOUT42 (detected via internal test signals).
			Action:	<ul style="list-style-type: none"> ❖ Check the connection wiring for the digital outputs DOUT40 ... DOUT42 (short circuit, cross circuit, etc.). ❖ Check the connection wiring for the brake (short circuit, cross circuit, etc.). ❖ Brake connection: The error may occur with long motor cables if: <ol style="list-style-type: none"> 1. The brake output X6 was configured for the brake (this is the case with factory settings!) and 2. A motor without a holding brake is used and the brake connection lines in the motor cable are terminated at X6. In this case: Disconnect the brake connection lines at X6. ❖ If there is no error in the connection wiring, there may be an internal error in the module (check by swapping the module).

Error message		Meaning of the error message	Measures	
Main index	Sub index			
	1	Digital inputs - Signal level error	Cause:	❖ Exceeding / violation of discrepancy time with multi-channel inputs (DIN40 ... DIN43, two-handed control device, mode selector switch).
			Action:	❖ Check the external active and passive sensors – do they switch on two channels and simultaneously (within the parameterised discrepancy time). ❖ Two-handed control device: Check how the device is operated by the user – are both pushbuttons pressed within the discrepancy time? Give training if necessary. ❖ Check the set discrepancy times – are they sufficient?
	2	Digital inputs - Test pulse error	Cause:	One or more inputs (DIN40 ... DIN49) were configured for the analysis of the test pulses of the outputs (DOUT40 ... DOUT42). The test pulses from DOUTx do not arrive at DIN4x.
			Action:	❖ Check the wiring (shorts after 0 V, 24 V, cross circuits). ❖ Check the assignment – correct output selected / configured for test pulse?
	6	Electronics temperature too high	Cause:	The safety module's temperature monitor has been triggered; the temperature of $\mu C1$ or $\mu C2$ was below -20° or above $+75^{\circ}\text{C}$.
			Action:	❖ Check the operating conditions (ambient temperature, control cabinet temperature, installation situation in the control cabinet). ❖ If the servo drive is experiencing high thermal load (high control cabinet temperature, high power consumption / output to motor, large number of occupied slots), a servo drive of the next higher output level should be used.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
58	0	FSM: Plausibility check of parameters	Cause:	The plausibility check in the safety module produced errors, e.g. an invalid angle encoder configuration; the error is triggered when a validation code is requested by the SafetyTool and when parameters are backed up in the safety module.
			Action:	Note instructions for SafetyTool for complete validation; check parameterisation.
	1	General error, parameterisation	Cause:	Parameter session active for > 8 hrs. The safety module has thus terminated the parameterisation session. The error message is saved in the permanent event memory.
			Action:	Terminate parameterisation session within 8 hrs. If necessary, start a new parameterisation session and continue.
	4	Buffer, internal communication	Cause:	<ul style="list-style-type: none"> Communication connection faulty. Timeout / data error / incorrect sequence (packet counter) in data transmission between the basic device and safety module. Too much data traffic, new requests are being sent to safety module before old ones have been responded to.
			Action:	<ul style="list-style-type: none"> ❖ Check communication interfaces, wiring, screening, etc. ❖ Check whether other devices have read access to the servo drive and safety module during a parameterisation session - this may overload the communication connection. ❖ Check whether the firmware versions of the safety module and basic device and the versions of the Metronix ServoCommander® and SafetyTool are compatible.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
	5	Communication module - basic device	Cause:	<ul style="list-style-type: none"> – Packet counter error during transmission $\mu\text{C1} \leftrightarrow \mu\text{C2}$ – Checksum error during transmission $\mu\text{C1} \leftrightarrow \mu\text{C2}$.
			Action:	<ul style="list-style-type: none"> ❖ Internal malfunction in the servo drive. ❖ Check whether the firmware versions of the safety module and basic device and the versions of the Metronix ServoCommander® and SafetyTool are compatible.

Error message		Meaning of the error message	Measures	
Main index	Sub index			
	6	Error in cross-comparison for processors 1 - 2	<p>Cause:</p> <p>Timeout during cross-comparison (no data) or cross-comparison faulty (data for μC1 and μC2 are different).</p> <ul style="list-style-type: none"> – Error in cross-comparison for digital I/O. – Error in cross-comparison for analogue input. – Error in cross-comparison for internal operating voltage measurement (5 V, 3.3 V, 24 V) and reference voltage (2.5 V). – Error in cross-comparison for SIN/COS angle encoder analogue values. – Error in cross-comparison for programme sequence monitoring. – Error in cross-comparison for interrupt counter. – Error in cross-comparison for input map. – Error in cross-comparison for violation of safety conditions. – Error in cross-comparison for temperature measurement. 	
			<p>Action:</p> <p>This is an internal error in the module that should not occur during operation.</p> <ul style="list-style-type: none"> ❖ Check the operating conditions (temperature, air humidity, condensation). ❖ Check the EMC wiring as specified and screening design; are there any external interference sources? ❖ Safety module may be faulty – is error eliminated after replacing the module? ❖ Check whether new firmware for the servo drive or a new version of the safety module is available from the manufacturer. 	

Error message		Meaning of the error message	Measures	
Main index	Sub index			
59	1	FSM: Fail-safe mode supply/safe pulse inhibitor	Cause:	Internal error in module in failsafe supply circuit section or in the driver supply for the upper and lower switches.
			Action:	Module faulty, replace.
	2	FSM: Logic failure / intermediate circuit	Cause:	<ul style="list-style-type: none"> Reference voltage 2.5 V outside tolerance. Logic supply overvoltage +24 V detected.
			Action:	Module faulty, replace.
	3	FSM: Error internal power supply	Cause:	Voltage (internal 3.3 V, 5 V, ADU reference) outside the permissible range.
			Action:	Module faulty, replace.
	4	FSM: Error management, too many errors	Cause:	Too many errors have occurred simultaneously.
			Action:	<ul style="list-style-type: none"> ❖ Clarify: What is the status of the installed safety module - does it contain a valid parameter set? ❖ Read out and analyse the permanent event memory of the basic device via Metronix ServoCommander® ❖ Eliminate error causes step by step. ❖ Install safety module with "delivery status" and perform commissioning of basic device. ❖ If this is not available: Set factory settings in the safety module, then copy data from the basic device and perform complete validation. Check whether the error occurs again.
	5	FSM: Log file - write error	Please contact the Technical Support.	
	6	FSM: Parameter set - save error	Please contact the Technical Support.	

Error message		Meaning of the error message	Measures	
Main index	Sub index			
	7	FSM: Flash checksum error	Cause:	<ul style="list-style-type: none"> – Voltage interruption / power off while parameters were being saved. – Flash memory in safety module corrupted (e.g. by extreme malfunctions).
			Action:	Check whether the error recurs after a reset. If it does: <ul style="list-style-type: none"> ❖ Parameterise the module again and validate the parameter set again. If error persists: ❖ Module faulty, replace.
	8	FSM: Internal monitoring, processor 1 - 2	Cause:	<ul style="list-style-type: none"> – Serious internal error in the safety module: Error detected while dynamising internal signals. – Disrupted programme sequence, stack error or OP code test failed, processor exception / interrupt.
			Action:	Check whether the error recurs after a reset. If it does: <ul style="list-style-type: none"> ❖ Module faulty, replace.
	9	FSM: Structure error, invalid software state	Cause:	Triggering of internal programme sequence monitoring.
			Action:	<ul style="list-style-type: none"> ❖ Check the firmware version of the basic device and the version of the safety module – update available? ❖ Safety module faulty; replace.
60	0	Ethernet user-specific (1)	Please contact the Technical Support.	
61	0	Ethernet user-specific (2)	Please contact the Technical Support.	
62	0	EtherCAT: general bus error	No EtherCAT bus available. Check the cabling.	
	1	EtherCAT: initialization error	Replace the technology module. If necessary, contact the Technical Support.	
	2	EtherCAT: protocol error	Wrong protocol (no CAN over EtherCAT)? Check the EtherCAT wiring.	
	3	EtherCAT: invalid RPDO length	Check the RPDO configuration of the servo positioning controller and of the control system.	
	4	EtherCAT: invalid TPDO length		

Error message		Meaning of the error message	Measures
Main index	Sub index		
	5	EtherCAT: faulty cyclic data transfer	Check the EtherCAT wiring. Check the configuration of the master.
63	0	EtherCAT: defective module	Technology module defective? Replace the technology module.
	1	EtherCAT: invalid data	Check the protocol. Check the EtherCAT wiring.
	2	EtherCAT: TPDO data has not been read	Reduce the cycle time (EtherCAT bus).
	3	EtherCAT: no distributed clocks active	Check whether the master supports the "distributed clocks" feature. If necessary, contact the Technical Support.
	4	Missing SYNC message in IPO cycle	Check the cycle times of the servo positioning controller and of the control system.
64	0	DeviceNet: duplicated MAC ID	Change the MAC ID.
	1	DeviceNet: bus power lost	Check the DeviceNet wiring.
	2	DeviceNet: overflow of receive buffer	Reduce the number of messages per time unit during the transmission.
	3	DeviceNet: overflow of transmit buffer	Reduce the number of message per time unit that are to be transmitted.
	4	DeviceNet: IO send error	Please contact the Technical Support.
	5	DeviceNet: bus Off	Check the DeviceNet wiring.
	6	DeviceNet: CAN controller overflow	Please contact the Technical Support.
65	0	DeviceNet: no module	Technology module defective? Replace the technology module.
	1	DeviceNet: I/O connection timeout	Please contact the Technical Support.

Error message		Meaning of the error message	Measures
Main index	Sub index		
72	0	Profinet: Initialization error	Replace the Profinet module.
	1	Profinet: Bus error	No communication possible, e.g. because the bus cable is disconnected. Check the cabling and restart the Profinet communication.
	3	Profinet: Invalid IP configuration	IP address, subnet mask or gateway address are not valid or not permissible. Change IP configuration.
	4	Profinet: Invalid device name	According to the Profinet standard, the Profinet device name is not permissible. Change device name.
	5	Profinet: Technology module defect	Replace the Profinet module.
	6	Profinet: Invalid / not supported indication	A Profinet feature has been used that is not supported by the module. If necessary, contact the Technical Support.
78	0	NRT frame send error	Reduce bus traffic, for example by using less devices in a line.
80	0	IRQ: current controller overflow	Please contact the Technical Support.
	1	IRQ: speed controller overflow	
	2	IRQ: position controller overflow	
	3	IRQ: interpolator overflow	
81	4	IRQ: low-level overflow	Please contact the Technical Support.
	5	IRQ: MDC overflow	
82	0	Sequence control: general	For information only, no measures required.
	1	CO write access started multiple times	Please contact the Technical Support.

Error message		Meaning of the error message	Measures
Main index	Sub index		
83	0	Invalid technology module or Technology module: (slot/combination)	Load the correct firmware. Check the slot. If necessary, contact the Technical Support.
	1	Technology module not supported	Load the correct firmware. If necessary, contact the Technical Support.
	2	Technology module: HW revision not supported	
	3	Service memory module: write error	Please contact the Technical Support.
	4	Technology module: MC2000 watchdog	
84	0	State change of the sequence control	Detailed information concerning internal processes. No measures required. If necessary, select the option "Entry into buffer" in the error management.
90	0	Missing hardware component (SRAM)	Please contact the Technical Support.
	1	Missing hardware component (FLASH)	
	2	Error during booting of FPGA	
	3	Error during start of SD-ADUs	
	4	SD-ADU synchronisation error after start	
	5	SD-ADU not synchronous	
	6	IRQ 0 (current controller): trigger error	
	7	CAN controller not available	
	8	Device parameters checksum error	
	9	DEBUG-Firmware loaded	

Error message		Meaning of the error message	Measures
Main index	Sub index		
91	0	Internal initialisation error	Please contact the Technical Support.
	1	Memory error	
	2	Controller/power stage code read error	
	3	Internal software initialization error	
92	0	Error during firmware download	Incorrect firmware? Load the correct firmware. If necessary, contact the Technical Support.
	1	Error during Bootloader Update	Please contact the Technical Support.

12 Technology modules

12.1 EA88 interface (terminal extension)

12.1.1 Product description

The EA88 interface can be used in technology slot TECH 1 or TECH 2 of the ARS 2000 FS servo positioning controller to extend the already existing digital IOs. Up to two EA88 interfaces can be supported simultaneously.

This technology module can be used to actuate up to 8 digital 24V outputs independently. In addition, 8 digital 24V inputs are available.

The EA88 interface has the following characteristics:

- ❖ Digital 24V inputs
- ❖ Digital 24V outputs which can be activated separately and loaded with 100 mA each
- ❖ MicroCombicon pin-and-socket connectors made by PHOENIX
- ❖ Pin-and-socket connectors via male multipoint connector in accordance with EN 60603-1
- ❖ The inputs and outputs are floating due to the optocouplers
- ❖ The inputs and outputs are protected against short circuits and overload

12.1.2 Technical data

12.1.2.1 General data

Table 51: Technical data: EA88 interface

Range	Values
Storage temperature range	-25 °C to +75°C
Operating temperature range / deratings	0°C to 50°C
Atmospheric humidity	0..90%, non-condensing
Altitude	Up to 2000 m above msl
External dimensions (LxWxH):	87mm x 65mm x 19mm; suitable for technology slot TECH 1 and/or TECH 2
Weight:	approx. 50g

12.1.2.2 Digital inputs

8 digital inputs 24V, protected against inverse polarity and short-circuit-proof.

Table 52: Digital inputs: EA88 interface [X21]

Parameter	Values
Input	High level switches the input
Nominal voltage	24 VDC
Voltage range	-30 V...30 V
"High" detection at	$U_{in} > 8 \text{ V}$
"Low" detection at	$U_{in} < 2 \text{ V}$
Hysteresis	$> 1 \text{ V}$
Input impedance	$\geq 4.7 \text{ k}\Omega$
Inverse polarity protection	Up to -30V
Switching delay up to port pin (low-high transition)	$< 100 \mu\text{s}$

12.1.2.3 Digital outputs

8 digital outputs 24V, protected against inverse polarity and short-circuit-proof, protection against thermal overload.

Table 53: Digital outputs: EA88 interface [X22]

Parameter	Values
Switch type	High-side switch
Nominal voltage	24 VDC
Voltage range	18 V...30 V
Output current (nominal)	$I_{L,nominal} = 100 \text{ mA}$
Voltage loss at $I_{L,nominal}$	$\leq 1 \text{ V}$
Residual current with switch in OFF position	$< 100 \mu\text{A}$
Protection against short-circuit / overcurrent	$> 500 \text{ mA}$ (approx. value)
Temperature protection	Shut-down if the temperature is too high, $T_J > 150^\circ$
Supply	Protection in the case of inductive loads and voltage supply via the output, also if the supply is turned off
Loads	$R > 220 \Omega$; L at random; $C < 10 \text{ nF}$
Switching delay as of port pin	$< 100 \mu\text{s}$

12.1.3 Pin assignment and cable specifications

12.1.3.1 Power supply

- ❖ The admissible input voltage range during operation is 15VDC....32VDC.
- ❖ The digital outputs of the EA88 technology module are supplied with voltage exclusively by an external 24VDC power supply. The nominal input voltage for the I/O supply is 24VDC.
- ❖ If digital inputs are used, the reference potential GND24V of the 24VDC supply also has to be connected to the EA88 interface technology module.

12.1.3.2 Pin assignments

The following elements can be found on the front plate of the EA88 interface:

- ❖ Connector [X21] for 8 digital inputs:
PHOENIX Contact MicroCombicon MC 0.5/9-G-2.5 (9-pin type)

Table 54: EA88: Connector [X21] for 8 digital inputs

Pin	1	2	3	4	5	6	7	8	9
Signal	GND 24V	In 1	In 2	In 3	In 4	In 5	In 6	In 7	In 8

- ❖ Connector [X22] for 8 digital outputs:
PHOENIX Contact MicroCombicon MC 0.5/10-G-2.5 (10-pin type)

Table 55: EA88: Connector [X22] for 8 digital outputs

Pin	1	2	3	4	5	6	7	8	9	10
Signal	GND 24V	Out 1	Out 2	Out 3	Out 4	Out 5	Out 6	Out 7	Out 8	+24VDC external

The following *Figure 32* shows the position of the connectors and their numbering:




Figure 32: E88: Position of the pin-and-socket connectors [X21] and [X22] at the front plate

12.1.3.3 Counterplug

- ❖ Connector [X21] for 8 digital inputs: PHOENIX Contact MicroCombicon FK-MC 0.5/9-ST-2.5
- ❖ Connector [X22] for 8 digital outputs: PHOENIX Contact MicroCombicon FK-MC 0.5/10-ST-2.5

12.1.3.4 Connection notes

The MicroCombicon counterplugs made by PHOENIX Contact regarding [X21] (FK-MC 0.5/9-ST-2.5) and [X22] (FK-MC 0.5/10-ST-2.5) are supplied together with the EA88 interface technology module. The cables are connected in the form of crimp connections. To do so, first strip the cable at a length of about 8 mm. Then insert it into the desired opening by pressing down the orange crimp lock using a suitable screwdriver, the tip of a ball-pen or something similar. Release the lock to fix the cable in place. The maximum admissible wire cross-section (wire gauge) is 0.5 mm² or AWG20.

If the EA88 interface is also used to control digital outputs, an additional external 24V supply voltage has to be connected to [X22], pin 10.

As the lines GND24V and +24Vext. have to transfer the entire current of all outputs connected, their cross-section has to be sized accordingly (recommended: AWG 20).

12.2 PROFIBUS-DP interface

12.2.1 Product description

The PROFIBUS-DP interface provides an additional field bus connection. All functions and parameters can be addressed directly, for example from a Simatic S7 control system. The interface is plugged into the technology slot TECH 2 of the ARS 2000 FS servo positioning controller.



The PROFIBUS-DP interface is supported solely in the **TECH 2** technology slot.

In addition to the PROFIBUS-DP interface, the TECH 1 technology slot can also be used for the I/O extension module EA88.

Additional technology modules will not be supported if the PROFIBUS-DP interface is used.

If your specific requirements are more complex, please contact your sales partner in order to find a solution for your particular application.

As a special feature, S7 function blocks have been developed for the servo positioning controllers. Using these function blocks, the servo positioning controllers can be controlled directly by the PLC program and the users can integrate their systems easily and clearly into the Simatic S7 environment.

12.2.2 Technical data

Table 56: Technical data: PROFIBUS-DP interface: Ambient conditions, dimensions and weight

Range	Values
Storage temperature range	-25 °C to +75°C
Operating temperature range / deratings	0°C to 50°C
Atmospheric humidity	0..90%, non-condensing
Altitude	Up to 2000 m above msl
External dimensions (LxWxH):	approx. 92 x 65 x 19mm suitable for the technology slot TECH 2
Weight:	approx. 50g

Table 57: Technical data: PROFIBUS-DP interface: Interfaces and communication

Communication interface	PROFIBUS module
Controller	PROFIBUS controller VPC3+, 12 Mbaud max.
Protocol	PROFIBUS-DP, 32-byte telegrams with operating-mode-depending configuration
Interface	Floating, D-SUB 9-pin, integrated bus terminating resistors (can be activated by DIP switches)
Special functions	Support of diagnosis data, RTS signal led out, fail-safe mode, sync/freeze

The following elements can be found on the front plate of the PROFIBUS-DP interface (see *Figure 33*):

- ❖ a green LED to indicate readiness for operation
- ❖ a 9-pin female DSUB connector
- ❖ two DIP switches for activating the terminating resistors

**Figure 33: PROFIBUS-DP interface: Front view**

12.2.3 Pin assignments and cable specifications

12.2.3.1 Pin assignment

- ❖ 9-pin DSUB connector, female

Table 58: Pin assignment: PROFIBUS-DP interface

Pin no.		Denomination	Values	Specification
1		Shield	-	Cable shield
	6	+5V	+5 V	+5V output (floating) ¹⁾
2		-	-	Not used
	7	-	-	Not used
3		RxD / TxD-P		B-line transmission / reception data
	8	RxD / TxD-N		A-line transmission / reception data
4		RTS / LWL		Request to Send ²⁾
	9	-	-	Not used
5		GND5V	0 V	Reference potential GND 5V ¹⁾

¹⁾ Can be used for external bus termination or to supply the transmitter/receiver of an external optical waveguide transmission.

²⁾ The signal is optional. It is used to identify the direction of an external optical waveguide connection.

12.2.3.2 Counterplug

- ❖ 9-pin DSUB connector, for example Erbic MAX PROFIBUS IDC Switch, made by ERNI

12.2.3.3 Cable type and configuration

The cable names given refer to cables made by Lapp. They have proven to be reliable and are successfully used in many applications. However, it is also possible to use comparable cables from other manufacturers, for example Lütze or Helukabel.

- ❖ LAPP KABEL UNITRONIC BUS L2/FIP FC; 1 x 2 x 0.64; Ø 7.8 mm,
with tinned total CU shielding for quick-connect applications with IDC connectors

For highly flexible applications:

- ❖ LAPP KABEL UNITRONIC BUS FD P L2/FIP; 1 x 2 x 0.64; Ø 8 mm,
with tinned total CU shielding for highly flexible use in drag chains

12.2.4 Termination and bus terminating resistors

Every bus segment of a PROFIBUS network has to be equipped with bus terminating resistors to minimise line reflections and to adjust a defined rest potential on the line. The bus termination has to be provided at the **beginning** and at the **end of every bus segment**.

Most PROFIBUS connectors come supplied with integrated terminating resistors. For bus connections with connectors without integrated terminating resistors, the PROFIBUS-DP interface has its own terminating resistors. They can be activated with the help of the **two DIP switches** on the module (switch set to ON).

To ensure safe operation of the network, **only one bus termination may be used at a time**.

The external connection can also be set up discretely (see *Figure 34*). The power supply of 5 V required for the externally connected terminating resistors is supplied at the PROFIBUS connector of the PROFIBUS-DP interface (see pin assignment in *Table 58*).




Figure 34: PROFIBUS-DP interface: Connection with external terminating resistors

12.3 Sercos II module

12.3.1 Product description

The Sercos II module is used to connect the ARS 2000 FS servo positioning controller to a Sercos-compatible CNC control. The communication on the Sercos II bus uses a ring-shaped optical fibre link with transmission rates of up to 16 Mbaud. If six servo positioning controllers are connected to one bus, setpoints and actual values (position, speed and torque values) can be exchanged with the CNC control every 500 µs.



The Sercos II module is supported solely in the **TECH 2** technology slot.

In addition to the Sercos II module, the TECH 1 technology slot can also be used for the I/O extension module EA88.

Additional technology modules will not be supported if the Sercos II module is used.

If your specific requirements are more complex, please contact your sales partner in order to find a solution for your particular application.

A special feature of the Sercos II bus is the synchronisation of all the devices connected to the bus. If several ARS 2000 FS servo positioning controllers are connected, the internal controllers and output stages of the servo positioning controllers operate in a phase-locked manner.

Via the 8-pole DIP switch the Sercos II bus address can optionally be set. When restarted, the servo positioning controller checks whether there has been set a bus address via these switches (all switches in position OFF → no bus address set). If no bus address has been set via the 8-pole DIP switches, the servo positioning controller uses the bus address set via the Metronix ServoCommander® (menu: Parameters/Field bus/ Sercos...).

Example for setting the bus address via the 8-pole DIP switch: Switches 1, 4 and 8 are active (in position ON). From this the (decimal) bus address 137 (89h) is derived.

Switch 1:	$2^0 \rightarrow$	1
Switch 4:	$2^3 \rightarrow$	8
Switch 8:	$2^7 \rightarrow$	128
Sum:		$1 + 8 + 128 = \underline{137}$

12.3.2 Technical data

Table 59: Technical data: Sercos II module: Ambient conditions, dimensions and weight

Range	Values
Storage temperature range	-25 °C to +75°C
Operating temperature range / deratings	0°C to 50°C
Atmospheric humidity	0..90%, non-condensing
Altitude	up to 2000 m above msl
External dimensions (LxWxH):	approx. 92 x 65 x 19mm suitable for technology slot TECH 2
Weight	approx. 50g

The following elements can be found on the front plate of the Sercos II module (see *Figure 35*):

- ❖ a green LED to indicate that the bus is ready for operation
- ❖ a connection for the optical waveguide receiver / type HFD 7000-402 (metal connection)
→ Connection directly underneath the 8-pole DIP switch
- ❖ a connection for the optical waveguide transmitter / type HFD 7000-210 (plastic connection)
→ Connection directly above the LED
- ❖ 8-pole DIP switch to set the fieldbus address




Figure 35: Sercos II module: Front view

12.3.3 Optical waveguide specification

More information concerning the type and setup of suitable optical waveguides can be found in the standard Sercos literature, for example:

<http://www.sercos.org/>

Interests Group Sercos interface e.V.
Landhausstrasse 20, 70190 Stuttgart
Germany

12.4 EtherCAT

12.4.1 Product description

The EtherCAT technology module enables the connection of the ARS 2000 FS servo positioning controller to the EtherCAT fieldbus system. The communication via the EtherCAT interface (IEEE-802.3u) is realised with the aid of standard EtherCAT cabling.



In the case of the ARS 2000 FS Metronix supports the CoE protocol (CANopen over EtherCAT) with the FPGA ESC20 made by Beckhoff.



The EtherCAT technology module is supported solely in the **TECH 2** technology slot.

In addition to the EtherCAT technology module, the TECH 1 technology slot can also be used for the I/O extension module EA88.

Additional technology modules will not be supported if the EtherCAT technology module is used.

If your specific requirements are more complex, please contact your sales partner in order to find a solution for your particular application.

12.4.2 Characteristics of the EtherCAT technology module

The EtherCAT technology module has the following characteristics:

- ❖ It can be fully mechanically integrated in the Metronix servo positioning controllers of the ARS 2000 FS series
- ❖ EtherCAT corresponding to IEEE-802.3u (100Base-TX) with 100 Mbps (full duplex)
- ❖ Star and line topology
- ❖ Connector: RJ45
- ❖ Electrically isolated EtherCAT interface
- ❖ Communication cycle: 1ms
- ❖ 127 slaves max.
- ❖ EtherCAT slave implementation based on FPGA ESC20 by Beckhoff
- ❖ Support of the “Distributed Clocks” feature for synchronised set value transfer
- ❖ LED display for indicating readiness and link-detect



Figure 36: EtherCAT module: Front view

12.4.3 Technical data

Table 60: Technical data: EtherCAT module: Ambient conditions, dimensions and weight

Range	Values
Storage temperature range	-25°C to +75°C
Operating temperature range	0°C to 50°C
Atmospheric humidity	0..90%, non-condensing
Altitude	up to 2000 m above msl
External dimensions (LxWxH):	approx. 92 x 65 x 19 mm
Weight:	approx. 55 g
Slot	Technology slot TECH 2

12.4.4 Display elements

The front panel of the EtherCAT technology module is equipped with two LEDs for indicating the operating states.

Table 61: Display elements

Element	Function
LED 1 Two-colour-LED (green/red)	Run (green), link/activity EtherCAT port 1 (red), EtherCAT active (yellow)
LED 2 (red)	Link/activity EtherCAT port 2

12.4.5 EtherCAT interface

Table 62: Signal level and differential voltage

Signal level	0 ... 2.5 VDC
Differential voltage	1.9 ... 2.1 VDC

12.5 MC 2000 “Drive-In” 4-Axis Motion Coordinator

12.5.1 Product description

The technology module MC 2000 motion coordinator can control up to four servo axes of the ARS 2000 and ARS 2000 FS servo positioning controller series in a multi-axis-coordinated way.



The Motion Coordinator MC 2000 technology module is supported solely in the **TECH 2** technology slot.

In addition to the MC 2000 module, the TECH 1 technology slot can also be used for the I/O extension module EA88.

Additional technology modules will not be supported if the MC 2000 module is used.

If your specific requirements are more complex, please contact your sales partner in order to find a solution for your particular application.

With the MC 2000 complex motion control can be realised fast and easy, for example.

- ❖ Electronic cam drives and gears
- ❖ Joint axes
- ❖ Point-to-point positioning
- ❖ Several types of interpolation (Interpolation, Circular Interpolation, Helical Interpolation).

Simply insert the MC 2000 module into the servo positioning controller. As the MC 2000 master, it can control up to three additional ARS 2000 servo drive slaves via CANopen DSP402. In addition, an external encoder can be connected directly to the ARS 2000. This external encoder can then be evaluated as an additional axis by the MC 2000. All of the available standard I/Os in the ARS 2000 can be used for this purpose.

In addition, the ARS 2000 can be expanded by using the I/O module EA88. A second CAN-interface is available for connecting external CAN I/Os via the master.




Figure 37: MC 2000 4-Axis Motion Coordinator

12.5.2 Features

12.5.2.1 Compact

- ❖ Plug-in module that is directly integrated in the servo positioning controller
- ❖ Controls up to 4 real servo axes
- ❖ Easy wiring via CAN-bus



Figure 38: MC 2000 4-Axis Motion Coordinator maximum capacity

12.5.2.2 Fast

- ❖ 1 ms cycle time with up to 4 servo axes
- ❖ Short start up time with the Trio Motion BASIC software with numerous predefined commands
- ❖ High-speed sample input for fast measuring and interpretation of actual values

12.5.2.3 Easy

- ❖ Application programming with the proven Trio Motion software “Motion Perfect”
- ❖ Program generation of complex motion sequences like camming, gearing and interpolated multi axis movements
- ❖ Minimal external wiring thanks to the integration of the MC 2000 into a servo positioning controller (technology slot TECH 2)

12.5.3 Technical data

Table 63: Technical data: MC 2000 4-Axis Motion Coordinator

Size (L x B x H)	92 x 65 x 19 mm
Temperature range	0° C to 50° C
Current consumption	Max. 350 mA / 3,3 VDC and 150 mA / 5 VDC (internally via servo positioning controller)
Max. number of axes	8 (4x servo drives, 1x encoder, 3x virtual)
Additional encoder input	Bi-directional connection (via servo positioning controller –X10)
Servo cycle time	1 ms
Built-in digital inputs	6x 24 VDC (via servo positioning controller)
Built-in digital outputs	3x 24 VDC (via servo positioning controller)
Built-in analogue inputs	3x ± 10 VDC via servo positioning controller (1x 16 Bit differential and 2x 10 Bit single ended)
Built-in analogue outputs	2 x ± 10 VDC, 9 bit (via servo positioning controller)
Input function	Forward limit / reverse limit / datum / F hold
Serial ports	1x RS232 (programming) + 1x RS485 (for example HMI)
CAN ports	2x CAN interfaces (1x remote drive max. 1 Mbaud and 1x remote CAN I/O max. 500 kBaud via servo positioning controller)
Extension module	EA88 IO extension module (via servo positioning controller)
User memory	512 kBytes
Table memory	32,000 values
Multi-tasking	2 fast tasks + 5 normal tasks
EMC Compliance	EN 61800-3
CANopen protocol	CiA Draft Standard Proposal 402
Order number	9200-0008-00
RS232 cable for MC 2000	9200-0008-10

12.6 General installation notes for technology modules

**DANGER!**

Non-observance of the instructions that are stated in *chapter 2 Safety notes for electrical drives and controllers (page 17)* may lead to property damage, injuries, electric shock, or – in extreme cases – even death.

**DANGER!**

Prior to installing technology modules, the servo positioning controller has to be disconnected from any current-carrying conductors. After the operating voltage has been disconnected, wait for 5 minutes so that the capacities in the servo positioning controller can be completely discharged.

**Caution!**

Make sure that ESD protection measures are taken when handling technology modules.

To insert a technology module into the ARS 2100 FS servo positioning controller, please proceed as follows:

1. Remove the front plate of the technology slot (TECH 1 or TECH 2) of the servo positioning controller with a suitable Phillips screwdriver.
2. Push the technology module into the open technology slot so that the lateral guides hold the board.
3. Push the technology module into the slot until it reaches the stop.
4. Screw the technology module onto the front side of the housing of the servo positioning controller with the Phillips screw.
5. Ensure that the front plate of the technology module has conducting contact with the housing of the servo positioning controller (PE).



Figure 39: Servo positioning controller with integrated technology module MC 2000 (example)