



EtherCAT and CANopen manual

Important!
Read thoroughly before use!
Retain for future reference!

Original EtherCAT and CANopen manual

› Copyright

© 2022 Metronix Meßgeräte und Elektronik GmbH. All rights reserved.

The information and data in this document have been composed to the best of our knowledge. However, deviations between the document and the product cannot be excluded entirely. For the devices and the corresponding software in the version handed out to the customer, Metronix guarantees the contractual use in accordance with the user documentation. In the case of serious deviations from the user documentation, Metronix has the right and the obligation to repair, unless it would involve an unreasonable effort. A possible liability does not include deficiencies caused by deviations from the operating conditions intended for the device and described in the user documentation.

Metronix does not guarantee that the products meet the buyer's demands and purposes or that they work together with other products selected by the buyer. Metronix does not assume any liability for damage resulting from the combined use of its products with other products or resulting from improper handling of machines or systems.

Metronix reserves the right to modify, amend or improve the document or the product without prior notification.

This document may, neither entirely nor in part, be reproduced, translated into any other natural or machine-readable language nor transferred to electronic, mechanical, optical or any other kind of data media, without the express authorisation of the author.

› Trademarks

Any product names in this document may be registered trademarks. The sole purpose of any trademarks in this document is the identification of the corresponding products.

Metronix ServoCommander® is a registered trademark of Metronix Meßgeräte und Elektronik GmbH.

› Contact

Metronix Meßgeräte und Elektronik GmbH
Kocherstraße 3
38120 Braunschweig
Germany
Telephone: +49 (0)531 8668 0
Fax: +49 (0)531 8668 555
E-mail: vertrieb@metronix.de
<https://www.metronix.de>

› Revision Information

| | |
|--------------|-----------------------------|
| Manual title | EtherCAT and CANopen manual |
| File name | EC_CO-HB1p0_EN.pdf |
| Version | 1.0 |
| Year | 2022 |

Table of Contents

| | |
|--|-----------|
| 1 About this manual | 11 |
| 1.1 Structure of the warning notes | 11 |
| 1.2 Notation in this manual | 12 |
| 2 Quick-start guide | 13 |
| 2.1 CANopen | 13 |
| 2.1.1 Basics | 13 |
| 2.1.2 Wiring and pin assignment | 14 |
| 2.1.3 Wiring instructions | 16 |
| 2.1.4 Status LEDs | 17 |
| 2.1.5 Activate CANopen | 18 |
| 2.1.6 Integration of the servo drive in a master project | 20 |
| 2.2 EtherCAT | 26 |
| 2.2.1 Basics | 26 |
| 2.2.2 Wiring and pin assignment | 27 |
| 2.2.3 Wiring instructions | 28 |
| 2.2.4 Status LEDs (BL 4000-C) | 29 |
| 2.2.5 Activate EtherCAT | 29 |
| 2.2.6 Integration of the servo drive in a master project | 30 |
| 2.2.7 EoE (Ethernet over EtherCAT®) | 34 |
| 2.2.7.1 Activating EoE in the master | 35 |
| 2.2.7.2 Configure Bridge | 37 |
| 3 Parameterisation | 38 |
| 3.1 Loading and saving parameter sets | 40 |
| 3.1.1 Overview | 40 |
| 3.1.2 Description of objects | 41 |
| 3.1.2.1 Object 1011h: restore_default_parameters | 41 |
| 3.1.2.2 Object 1010h: store_parameters | 42 |
| 3.2 Compatibility settings | 43 |
| 3.2.1 Overview | 43 |
| 3.2.2 Description of objects | 43 |
| 3.2.2.1 Object 6510h_F0h: compatibility_control | 43 |
| 3.3 Factor Group | 45 |
| 3.3.1 Overview | 45 |
| 3.3.2 Parameterisation of the Factor Group | 46 |
| 3.3.3 Description of objects | 47 |
| 3.3.3.1 Object 6093h: position_factor | 47 |
| 3.3.3.2 Object 6094h: velocity_encoder_factor | 47 |
| 3.3.3.3 Object 6097h: acceleration_factor | 48 |
| 3.3.3.4 Object 607Eh: polarity | 48 |
| 3.4 Power stage parameters | 49 |
| 3.4.1 Overview | 49 |
| 3.4.2 Description of objects | 49 |
| 3.4.2.1 Object 6510h_10h: enable_logic | 49 |

| | | |
|----------|---|----|
| 3.4.2.2 | Object 6510h_30h: pwm_frequency | 50 |
| 3.4.2.3 | Object 6510h_3Ah: enable_enhanced_modulation | 51 |
| 3.4.2.4 | Object 6510h_31h: power_stage_temperature | 51 |
| 3.4.2.5 | Object 6510h_32h: max_power_stage_temperature | 52 |
| 3.4.2.6 | Object 6510h_33h: nominal_dc_link_circuit_voltage | 52 |
| 3.4.2.7 | Object 6510h_34h: actual_dc_link_circuit_voltage | 53 |
| 3.4.2.8 | Object 6510h_35h: max_dc_link_circuit_voltage | 53 |
| 3.4.2.9 | Object 6510h_36h: min_dc_link_circuit_voltage | 54 |
| 3.4.2.10 | Object 6510h_37h: enable_dc_link_undervoltage_error | 54 |
| 3.4.2.11 | Object 6510h_40h: nominal_current | 55 |
| 3.4.2.12 | Object 6510h_41h: peak_current | 55 |
| 3.5 | Current controller and motor adaption | 56 |
| 3.5.1 | Overview | 56 |
| 3.5.2 | Description of objects | 56 |
| 3.5.2.1 | Object 6075h: motor Rated current | 56 |
| 3.5.2.2 | Object 6073h: max_current | 57 |
| 3.5.2.3 | Object 604Dh: pole_number | 57 |
| 3.5.2.4 | Object 6410h_11h: encoder_offset_angle | 57 |
| 3.5.2.5 | Object 6410h_10h: phase_order | 58 |
| 3.5.2.6 | Object 6410h_03h: iit_time_motor | 58 |
| 3.5.2.7 | Object 6410h_04h: iit_ratio_motor | 59 |
| 3.5.2.8 | Object 6510h_3Dh: iit_ratio_servo | 59 |
| 3.5.2.9 | Object 6510h_38h: iit_error_enable | 60 |
| 3.5.2.10 | Object 6510h_2Eh: motor_temperature | 60 |
| 3.5.2.11 | Object 6410h_14h: motor_temperature_sensor_polarity | 61 |
| 3.5.2.12 | Object 6510h_2Fh: max_motor_temperature | 61 |
| 3.5.2.13 | Object 60F6h: torque_control_parameters | 62 |
| 3.5.2.14 | Object 203Ah: torque_feed_forward | 62 |
| 3.6 | Velocity controller | 63 |
| 3.6.1 | Overview | 63 |
| 3.6.2 | Description of objects | 63 |
| 3.6.2.1 | Object 60F9h: velocity_control_parameters | 63 |
| 3.6.2.2 | Object 2073h: velocity_display_filter_time | 64 |
| 3.7 | Position Controller | 65 |
| 3.7.1 | Overview | 65 |
| 3.7.2 | Description of objects | 66 |
| 3.7.2.1 | Object 60FBh: position_control_parameter_set | 66 |
| 3.7.2.2 | Object 6062h: position_demand_value | 68 |
| 3.7.2.3 | Object 202Dh: position_demand_sync_value | 68 |
| 3.7.2.4 | Object 6064h: position_actual_value | 68 |
| 3.7.2.5 | Object 6066h: following_error_time_out | 68 |
| 3.7.2.6 | Object 6065h: following_error_window | 69 |
| 3.7.2.7 | Object 60F4h: following_error_actual_value | 69 |
| 3.7.2.8 | Object 60FAh: control_effort | 69 |
| 3.7.2.9 | Object 6410h_0Fh: rotor_position | 70 |

| | | |
|----------|---|----|
| 3.7.2.10 | Object 6067h: position_window | 70 |
| 3.7.2.11 | Object 6068h: position_window_time | 70 |
| 3.7.2.12 | Object 6510h_22h: position_error_switch_off_limit | 71 |
| 3.7.2.13 | Object 2030h: set_position_absolute | 71 |
| 3.7.2.14 | Object 607Dh: software_position_limit | 72 |
| 3.7.2.15 | Object 607Bh: position_range_limit | 72 |
| 3.7.2.16 | Object 6510h_20h: position_range_limit_enable | 73 |
| 3.8 | Setpoint limitation | 74 |
| 3.8.1 | Object 2415h: current_limitation | 74 |
| 3.8.2 | Object 2416h: speed_limitation | 75 |
| 3.9 | Encoder adaptation | 76 |
| 3.9.1 | Overview | 76 |
| 3.9.2 | Description of objects | 76 |
| 3.9.2.1 | Object 2024h: encoder_x2a_data_field | 76 |
| 3.9.2.2 | Object 2026h: encoder_x2b_data_field | 77 |
| 3.9.2.3 | Object 2025h: encoder_x10_data_field | 77 |
| 3.9.2.4 | Object 202Ch: max_comm_enc_pos_enc_difference | 79 |
| 3.10 | Master frequency output | 80 |
| 3.10.1 | Overview | 80 |
| 3.10.2 | Description of objects | 80 |
| 3.10.2.1 | Object 201Ah: encoder_emulation_data | 80 |
| 3.10.2.2 | Object 2028h: encoder_emulation_resolution | 80 |
| 3.11 | Setpoint / actual value selection | 81 |
| 3.11.1 | Overview | 81 |
| 3.11.2 | Description of objects | 81 |
| 3.11.2.1 | Object 201Fh: commutation_encoder_select | 81 |
| 3.11.2.2 | Object 2021h: position_encoder_selection | 82 |
| 3.11.2.3 | Object 2022h: synchronisation_encoder_selection | 82 |
| 3.11.2.4 | Object 202Fh: synchronisation_selector_data | 83 |
| 3.11.2.5 | Object 2023h: synchronisation_filter_time | 83 |
| 3.12 | Analogue inputs | 84 |
| 3.12.1 | Overview | 84 |
| 3.12.2 | Description of objects | 84 |
| 3.12.2.1 | Object 2400h: analog_input_voltage | 84 |
| 3.12.2.2 | Object 2401h: analog_input_offset | 85 |
| 3.13 | Digital inputs and outputs | 86 |
| 3.13.1 | Overview | 86 |
| 3.13.2 | Description of objects | 86 |
| 3.13.2.1 | Object 60FDh: digital_inputs | 86 |
| 3.13.2.2 | Object 60FEh: digital_outputs | 86 |
| 3.13.2.3 | Object 2420h: digital_output_state_mapping | 87 |
| 3.14 | Limit switch / Reference switch | 89 |
| 3.14.1 | Overview | 89 |
| 3.14.2 | Description of objects | 89 |
| 3.14.2.1 | Object 6510h_11h: limit_switch_polarity | 89 |

| | | |
|-----------|--|------------|
| 3.14.2.2 | Object 6510h_12h: limit_switch_selector | 90 |
| 3.14.2.3 | Object 6510h_15h: limit_switch_deceleration | 90 |
| 3.14.2.4 | Object 6510h_14h: homing_switch_polarity | 91 |
| 3.14.2.5 | Object 6510h_13h: homing_switch_selector | 91 |
| 3.15 | Position capturing (Sampling) | 92 |
| 3.15.1 | Overview | 92 |
| 3.15.2 | Description of objects | 92 |
| 3.15.2.1 | Object 204Ah: sample_data | 92 |
| 3.16 | Brake control | 95 |
| 3.16.1 | Overview | 95 |
| 3.16.2 | Description of objects | 95 |
| 3.16.2.1 | Object 6510h_18h: brake_delay_time | 95 |
| 3.17 | Device information | 96 |
| 3.17.1 | Description of objects | 96 |
| 3.17.1.1 | Object 1000h: device_type | 96 |
| 3.17.1.2 | Object 1008h: manufacturer_device_name | 96 |
| 3.17.1.3 | Object 1009h: manufacturer_hardware_version | 96 |
| 3.17.1.4 | Object 100Ah: manufacturer_software_version | 97 |
| 3.17.1.5 | Object 1018h: identity_object | 97 |
| 3.17.1.6 | Object 6510h_A0h: drive_serial_number | 98 |
| 3.17.1.7 | Object 6510h_A1h: drive_type | 99 |
| 3.17.1.8 | Object 6510h_A9h: firmware_main_version | 99 |
| 3.17.1.9 | Object 6510h_AAh: firmware_custom_version | 99 |
| 3.17.1.10 | Object 6510h_ADh: km_release | 100 |
| 3.17.1.11 | Object 6510h_ACh: firmware_type | 100 |
| 3.17.1.12 | Object 6510h_B0h: cycletime_current_controller | 101 |
| 3.17.1.13 | Object 6510h_B1h: cycletime_velocity_controller | 101 |
| 3.17.1.14 | Object 6510h_B2h: cycletime_position_controller | 101 |
| 3.17.1.15 | Object 6510h_B3h: cycletime_trajectory_generator | 102 |
| 3.17.1.16 | Object 6510h_C0h: commissioning_state | 103 |
| 3.17.1.17 | Object 20FDh: user_device_name | 103 |
| 3.18 | Error management | 104 |
| 3.18.1 | Overview | 104 |
| 3.18.2 | Description of objects | 104 |
| 3.18.2.1 | Object 2100h: error_management | 104 |
| 3.18.2.2 | Object 200Fh: last_warning_code | 105 |
| 4 | Device Control | 106 |
| 4.1 | Overview | 106 |
| 4.2 | State Machine | 107 |
| 4.2.1 | State diagram: States | 109 |
| 4.2.2 | State diagram: State transitions | 110 |
| 4.3 | controlword | 112 |
| 4.4 | Reading the servo drive status | 115 |
| 4.5 | Statuswords | 116 |
| 4.5.1 | Object 6041h: statusword | 116 |

| | | |
|----------|---|------------|
| 4.5.2 | Object 2000h: manufacturer_statuswords | 120 |
| 4.5.3 | Object 2005h: manufacturer_status_masks | 123 |
| 4.5.4 | Object 200Ah: manufacturer_status_invert | 123 |
| 4.5.5 | Object 2001h: manufacturer_warnings | 123 |
| 4.5.6 | Object 2006h: manufacturer_warning_masks | 124 |
| 4.6 | Description of further objects | 125 |
| 4.6.1 | Object 605Bh: shutdown_option_code | 125 |
| 4.6.2 | Object 605Ch: disable_operation_option_code | 125 |
| 4.6.3 | Object 605Ah: quick_stop_option_code | 126 |
| 4.6.4 | Object 605Eh: fault_reaction_option_code | 126 |
| 5 | Operating modes | 127 |
| 5.1 | Setting the operating mode | 127 |
| 5.1.1 | Overview | 127 |
| 5.1.2 | Description of objects | 127 |
| 5.1.2.1 | Object 6060h: modes_of_operation | 127 |
| 5.1.2.2 | Object 6061h: modes_of_operation_display | 128 |
| 5.2 | Homing Mode | 129 |
| 5.2.1 | Overview | 129 |
| 5.2.2 | Description of objects | 130 |
| 5.2.2.1 | Important objects in other sections | 130 |
| 5.2.2.2 | Object 607Ch: home_offset | 130 |
| 5.2.2.3 | Object 6098h: homing_method | 130 |
| 5.2.2.4 | Object 6099h: homing_speeds | 131 |
| 5.2.2.5 | Object 609Ah: homing_acceleration | 132 |
| 5.2.2.6 | Object 2045h: homing_timeout | 132 |
| 5.2.3 | Homing sequences | 133 |
| 5.2.3.1 | Methods -17 and -18: Stop | 133 |
| 5.2.3.2 | Methods -1 and -2: stop with index pulse evaluation | 133 |
| 5.2.3.3 | Methods 17 and 18: positive and negative limit switch | 134 |
| 5.2.3.4 | Methods 1 and 2: positive and negative limit switch with index pulse evaluation | 134 |
| 5.2.3.5 | Methods 23 and 27: reference switch | 135 |
| 5.2.3.6 | Methods 7 and 11: reference switch and index pulse evaluation | 136 |
| 5.2.3.7 | Methods -23 and -27: homing run (positive/negative) to the reference switch | 137 |
| 5.2.3.8 | Methods 32 and 33: homing to the index pulse | 137 |
| 5.2.3.9 | Method 34: homing to the current position | 137 |
| 5.2.4 | Homing control | 138 |
| 5.3 | Profile Position Mode | 139 |
| 5.3.1 | Overview | 139 |
| 5.3.2 | Functional description | 139 |
| 5.3.3 | Description of objects | 141 |
| 5.3.3.1 | Important objects in other sections | 141 |
| 5.3.3.2 | Object 607Ah: target_position | 141 |
| 5.3.3.3 | Object 6081h: profile_velocity | 141 |
| 5.3.3.4 | Object 6082h: end_velocity | 142 |
| 5.3.3.5 | Object 6083h: profile_acceleration | 142 |

| | | |
|----------|--|-----|
| 5.3.3.6 | Object 6084h: profile_deceleration | 142 |
| 5.3.3.7 | Object 6085h: quick_stop_deceleration | 142 |
| 5.3.3.8 | Object 6086h: motion_profile_type | 143 |
| 5.4 | Interpolated Position Mode | 144 |
| 5.4.1 | Overview | 144 |
| 5.4.2 | Functional description | 144 |
| 5.4.3 | Description of objects | 147 |
| 5.4.3.1 | Important objects in other sections | 147 |
| 5.4.3.2 | Object 60C0h: interpolation_submode_select | 147 |
| 5.4.3.3 | Object 60C1h: interpolation_data_record | 148 |
| 5.4.3.4 | Object 60C2h: interpolation_time_period | 148 |
| 5.4.3.5 | Object 60C3h: interpolation_sync_definition | 149 |
| 5.4.3.6 | Object 60C4h: interpolation_data_configuration | 150 |
| 5.4.3.7 | Object 1006h: communication_cycle_period | 151 |
| 5.5 | Cyclic Synchronous Position Mode | 152 |
| 5.5.1 | Overview | 152 |
| 5.5.2 | Description of objects | 152 |
| 5.5.2.1 | Important objects in other sections | 152 |
| 5.6 | Profile Velocity Mode | 153 |
| 5.6.1 | Overview | 153 |
| 5.6.2 | Description of objects | 154 |
| 5.6.2.1 | Important objects in other sections | 154 |
| 5.6.2.2 | Object 6069h: velocity_sensor_actual_value | 155 |
| 5.6.2.3 | Object 606Ah: sensor_selection_code | 155 |
| 5.6.2.4 | Object 606Bh: velocity_demand_value | 155 |
| 5.6.2.5 | Object 202Eh: velocity_demand_sync_value | 155 |
| 5.6.2.6 | Object 606Ch: velocity_actual_value | 156 |
| 5.6.2.7 | Object 2074h: velocity_actual_value_filtered | 156 |
| 5.6.2.8 | Object 606Dh: velocity_window | 157 |
| 5.6.2.9 | Object 606Eh: velocity_window_time | 157 |
| 5.6.2.10 | Object 606Fh: velocity_threshold | 157 |
| 5.6.2.11 | Object 6070h: velocity_threshold_time | 158 |
| 5.6.2.12 | Object 6080h: max_motor_speed | 158 |
| 5.6.2.13 | Object 60FFh: target_velocity | 158 |
| 5.6.2.14 | Speed ramps | 159 |
| 5.7 | Profile Torque Mode | 161 |
| 5.7.1 | Overview | 161 |
| 5.7.2 | Description of objects | 162 |
| 5.7.2.1 | Important objects from other sections | 162 |
| 5.7.2.2 | Object 6071h: target_torque | 162 |
| 5.7.2.3 | Object 6072h: max_torque | 162 |
| 5.7.2.4 | Object 6074h: torque_demand_value | 162 |
| 5.7.2.5 | Object 6076h: motorRated_torque | 163 |
| 5.7.2.6 | Object 6077h: torque_actual_value | 163 |
| 5.7.2.7 | Object 6078h: current_actual_value | 163 |

| | |
|---|------------|
| 5.7.2.8 Object 6079h: dc_link_circuit_voltage | 163 |
| 5.7.2.9 Object 6087h: torque_slope | 164 |
| 5.7.2.10 Object 6088h: torque_profile_type | 164 |
| 6 Detailed description of the CANopen protocol | 165 |
| 6.1 Introduction | 165 |
| 6.2 Access via SDO | 166 |
| 6.2.1 SDO sequences for reading and writing | 167 |
| 6.2.2 SDO error response (abort codes) | 168 |
| 6.2.3 Simulation of SDO accesses | 169 |
| 6.3 Access via PDO | 170 |
| 6.3.1 Description of objects | 171 |
| 6.3.2 Objects for PDO configuration | 173 |
| 6.3.3 Activation of PDOs | 178 |
| 6.4 EMERGENCY message | 179 |
| 6.4.1 Overview | 179 |
| 6.4.2 Structure of the EMERGENCY message | 180 |
| 6.4.3 Description of objects | 180 |
| 6.5 SYNC message | 181 |
| 6.6 Network Management (NMT service) | 182 |
| 6.7 Bootup | 185 |
| 6.7.1 Overview | 185 |
| 6.7.2 Structure of the Bootup message | 185 |
| 6.8 Heartbeat (Error Control Protocol) | 185 |
| 6.8.1 Overview | 185 |
| 6.8.2 Structure of the Heartbeat message | 186 |
| 6.8.3 Description of objects | 186 |
| 6.9 Nodeguarding (Error Control Protocol) | 187 |
| 6.9.1 Overview | 187 |
| 6.9.2 Structure of the Nodeguarding messages | 187 |
| 6.9.3 Description of objects | 188 |
| 6.9.3.1 Object 100Ch: guard_time | 188 |
| 6.9.3.2 Object 100Dh: life_time_factor | 188 |
| 6.10 Table of identifiers | 189 |
| 7 Appendix | 190 |
| 7.1 CANopen | 190 |
| 7.2 Characteristics of the CAN interface | 190 |
| 7.3 Error codes of the EMERGENCY message | 191 |

1 About this manual

This manual describes how the servo drives of the ARS 2000 FS devices series and smartServo BL 4000 (BL 4000-C und BL 4000-M / BL 4000-D) can be integrated into a CANopen or Ethercat network. The physical connection, activation of the fieldbus protocol, integration into the network and the parameters for adaptation to the respective application are described.

It is intended for persons who are already familiar with the respective servo drive series and have read and understood the corresponding product manual.

The product manual contains instructions for the proper and professional transport, storage, assembly, installation, project planning and correct and safe operation of the servo drive.

The product manual contains safety instructions which must be strictly observed.

The product manuals are available for download on our homepage (<https://www.metronix.de>).

1.1 Structure of the warning notes

Warning notes have the following structure:

- Signal word
- Type of hazard
- Measures to prevent the hazard

> Signal words

⚠ DANGER

Indicates an imminent hazard.

If the situation is not avoided, extremely serious and possibly fatal injuries will result.

⚠ WARNING

Indicates a potentially hazardous situation.

If the situation is not avoided, extremely serious and possibly fatal injuries may result.

⚠ CAUTION


Indicates a potentially hazardous situation.

If the situation is not avoided, slight or minor injuries may result.

NOTICE

Warns against damage to property.

> Warning signs as per ISO 7010

| Warning sign | Explanation |
|---|---|
|  | Warning against fatal electric voltage. |

1.2 Notation in this manual

› Structure of notes

The notes in this manual have the following structure:

- Signal word "NOTE"
- Introductory phrase
- Explanations and special tips

› Operating elements, menus

Operating elements, menus and menu paths are written in orange.

Example: Double-clicking the desired device or clicking the button **Establish connection** will establish an online connection.

› CAN Objects, bit constants

Terms from the CANopen standards such as parameter names (CAN objects) are written in blue. Bit constants are highlighted by a different font.

Example: If this bit is set, bit 4 of the **statusword** (**voltage_enabled**) is output according to DSP 402 v2.0.

› States, commands

Servo drive states (see section 4 *Device Control* on page 106) are set in a different font and are capitalised. Commands are highlighted with a white box.

Example:

| | | | | | |
|------------------------|------------------|--|---|---|---|
| NOT_READY_TO_SWITCH_ON | | The servo drive carries out a self-test. | | | |
| 4 | Enable Operation | 1 | 1 | 1 | Motor control according to the current operating mode |

2 Quick-start guide

This chapter describes how to connect the servo drives to a commercially available CANopen or Ethercat controller and put them into operation in order to obtain a quick setup for starting application development. Depending on which fieldbus interface is used, the respective other chapter can be skipped.

Section 3 *Parameterisation* on page 38 then describes all available parameters, which can usually be used equally under CANopen and EtherCAT, in order to adapt the servo drive to the respective application. This chapter is intended for users who already have an industrial controller.

2.1 CANopen

CANopen is a standard maintained by the association "CAN in Automation", which defines the use of CAN in automation technology independently of manufacturers. The CANopen interface in the ARS 2000 FS servo drives and BL 4000 is designed according to CiA 301 (transmission layer) and CiA 402 (drive controller profile).

2.1.1 Basics

The CANopen fieldbus protocol defines how data is exchanged via the CAN fieldbus in industrial automation.

In general, there are two types of messages (communication objects) that are exchanged between the master (e.g. CoDeSys controller) and the slave.

- **SDO (Service Data Objects)**

This type of message is used for acyclic communication between master and slave, e.g. during the initialization phase of the application or in a very simple application where no cyclic data exchange is required.

- **PDO (Process Data Objects)**

This type of message is exchanged cyclically/automatically between master and slave to transfer process data. Process data is all the data required by the master or slave to execute the application. In our example, this process data contains e.g. position setpoint/actual values, control and status words and other important information to be able to use the servo drive as a SoftMotion axis.

There are further message types, such as [Emergency Messages](#), [Heartbeat Messages](#) or [Node Guarding Messages](#), which are also exchanged between master and slave, but only in case of a special event or in special applications. For example, an [Emergency Message](#) is sent from the slave to the master when a serious error has occurred in the servo drive. A detailed description of these message types can be found in section 6 *Detailed description of the CANopen protocol* on page 165.

2.1.2 Wiring and pin assignment

The CAN interface is integrated in the servo drives ARS 2000 FS and BL 4000-C and therefore always available. For servo drives of the BL 4000-M / BL 4000-D series, the CAN interface is only available with the CAN field bus variant. More detailed information on this can be found in the *Product Description* section of the Product manual BL 4000-D and BL 4000-M.

INFORMATION CAN bus wiring

When wiring the servo drive via the CAN bus, it is essential that you observe the following information and notes in order to obtain a stable, trouble-free system.

If the cabling is not correct, faults can occur on the CAN bus during operation, which can cause the servo drive to switch off with a fault for safety reasons.

INFORMATION 120Ω terminating resistor

No terminating resistor is integrated in the BL 4000-C, BL 4000-D and BL 4000-M servo drives. In the ARS 2000 FS servo drives, a terminating resistor can be connected via the CAN TERM DIP switch.

➤ BL 4000-C, ARS 2000 FS

The CAN bus connection is designed as a 9-pin DSUB connector (servo drive side) according to the standard.




Figure 1: CAN connector

| Pin | Name | Description |
|-----|---------|---|
| 1 | | Not used |
| 6 | CAN-GND | CAN-GND (directly coupled to GND in the BL 4000-C servo drive) |
| 2 | CAN-L | CAN low signal line |
| 7 | CAN-H | CAN high signal line |
| 3 | CAN-GND | See pin no. 6 |
| 8 | | Not used |
| 4 | | Not used |
| 9 | | Not used |
| 5 | Shield | Connection for cable shield |

➤ BL 4000-D and BL 4000-M (Fieldbus variant CAN)

On these devices, the CAN bus connection is designed as an M8 connector according to IEC 61076-114 (4-pin, socket, D-coded). Note that although the fieldbus variant PROFINET/EtherCAT uses the identical connectors, it is not electrically compatible. The fieldbus variants must not be mixed up and must never be used simultaneously in the same network!




Figure 2: Pin assignment of the fieldbus connector

Pin assignment **CANopen**:

| Pin | Name | Description | Colour |
|-----|---------|--------------------------|--------|
| 1 | CAN-H | Differential Signal High | Yellow |
| 2 | CAN-GND | Reference potential | Orange |
| 3 | CAN-L | Differential Signal High | White |
| 4 | CAN-GND | Reference potential | Blue |

For wiring, we recommend using the following pre-assembled cables or comparable products from other manufacturers:

Assembled network cable Phoenix Contact:

M8 plug to M8 plug: NBC-M8MSD/ 1,0-93C/M8MSD - 1423707

M8 plug to RJ45: NBC-M8MSD/ 1,0-93C/R4AC - 1423711

M8 plug to free cable end: NBC-M8MSD/ 1,0-93C - 1423703

2.1.3 Wiring instructions

The CAN bus offers a simple and fail-safe way of connecting all the components of a system. A prerequisite for this is that all the following instructions for wiring are observed.




Figure 3: Wiring example

The individual nodes of the network are always connected in a linear manner so that the CAN cable is looped through from servo drive to servo drive.

At both ends of the CAN cable there must be exactly one terminating resistor of 120Ω +/-5%. Often such a terminating resistor is already installed in CAN interfaces or in a PLC, which must be taken into account accordingly.

For wiring, **shielded** cable with exactly two **twisted** pairs of wires must be used.

- One twisted wire pair is used to connect CAN-H and CAN-L.
- The wires of the other pair are used **together** for CAN-GND.
- The shield of the cable is connected to the CAN shield connections at all nodes.

We do not recommend the use of adapter plugs for CAN bus cabling. If this is required, please note that metallic connector housings are used to connect the cable shield.

In order to keep the interference as low as possible:

- Motor cables must not be laid parallel to signal lines.
- Motor cables must be designed according to Metronix specifications.
- Motor cables must be properly shielded and earthed.

› Technical data CAN cable:

- 2 pairs of 2 twisted wires, $d \geq 0,22 \text{ mm}^2$, shielded
- Loop resistance $< 0,2 \text{ } \Omega/\text{m}$
- Characteristic impedance 100-120 Ω

2.1.4 Status LEDs

> BL 4000-C

For easy indication of the CAN bus status, the servo drive is equipped with two fieldbus status LEDs:

The LEDs indicate the following states:

| Name | Colour | Description |
|-----------|--------|---|
| RUN/SF/MS | Green | This LED indicates ongoing communication between the master and the servo drive. It is triggered when a message is received from the master. If this LED is continuously OFF, there is no communication with the Servo drive. |
| ERR/BF/NS | Red | This LED indicates the fieldbus error related to the CAN fieldbus. The LED flashes if a CAN-related fieldbus error is present and has not yet been acknowledged. |

In normal operation the RUN LED is on, because communication with the servo drive is taking place and the ERR LED is off.

If the ERR LED is flashing, one of the following CAN fieldbus errors has occurred:


| Group 12: CAN communication | | |
|-----------------------------|--------------------------------------|--|
| 12-1 | CAN: communication error, bus OFF | Check the wiring: compliance with the cable specification, cable break, maximum cable length exceeded, correct terminating resistors, cable shield earthed, all signals connected? |
| 12-2 | CAN: communication error (sending) | |
| 12-3 | CAN: communication error (receiving) | |
| 12-4 | CAN: Node Guarding | Failure of the PLC or the cycle time of the remote frames of the servo drive and PLC do not match. |
| 12-5 | CAN: RPDO too short | The number of bytes of a received RPDO is smaller than the number that is parameterised in the servo drive. |
| 12-9 | CAN: protocol error | Please contact the Technical Support team. |

> ARS 2000 FS

The CAN-ON LED flashes briefly when the servo drive has received a telegram.

2.1.5 Activate CANopen

The CANopen fieldbus communication must be activated once via the CANopen window of the Metronix ServoCommander® (**Parameter / Fieldbus / CANopen / Operation parameters**). Depending on the devices series, not all options may be available, so that the appearance of the window may be different.



A total of 3 different parameters must be set:

| Parameter | Description |
|-------------|---|
| Bit rate | This parameter determines the bit rate in kBit/s used on the CAN bus. It must match the bit rate in the master. Note that the maximum permissible cable length decreases at high bit rates. |
| Node number | For clear identification in the network, each participant must be assigned a node number that may only occur once in the network. The device is addressed via this node number. As an additional option it is possible to make the node number of the servo drive dependent on the external connection. The input combination of the digital inputs DIN0...DIN3 is added once to the basic node number after the reset. With the ARS 2000 FS it is also possible to add the analogue inputs with a value of 32 or 64, if the respective input is bridged to $V_{ref} = 10V$. |

| Parameter | Description |
|-----------|---|
| Options | <p>Test for double node number (ARS 2000 FS only): All devices in a CANopen network send a boot-up message with their own node number. If the servo drive receives such a boot-up message, which corresponds to its own node number, error 12-0 is raised.</p> <p>Add node number to COB-IDs of the PDOs: By setting this option, the COB-IDs of the PDOs do not have to be adapted manually to the node number (see section 6.3.2 <i>Objects for PDO configuration</i> on page 173).</p> |

Finally, the CANopen protocol can be activated. The above mentioned parameters can only be changed if the protocol is deactivated.

INFORMATION DIP switch on ARS 2000 FS

With the ARS 2000 FS servo drive, fieldbus settings can also be set via the DIP switches of the plug-in safety modules. The possible options are listed in the Product manual.

INFORMATION Parametrisation of the CANopen functionality

Please note that the parametrisation of the CANopen functionality is only retained after a reset if the parameter set of the servodrive has been saved.

INFORMATION Identical node numbers

It is not permitted to operate several servo drives on the CANopen fieldbus with the same node number. Therefore, make sure that each servo drive on the CANopen fieldbus has a unique node number before you activate communication.

2.1.6 Integration of the servo drive in a master project


As an example, this chapter shows how to integrate the servo drive into a CoDeSys V3.5 project and operate them as SoftMotion drives.

As a prerequisite, you must download the CANopen EDS file (Electronic Data Sheet) for the corresponding servo drive from the Metronix website (<https://www.metronix.de>).

This file contains a complete description of the drive characteristics and the object dictionary and is used by CoDeSys (or another CANopen master) for the automatic configuration of the servo drive. The following example shows the installation of a **BL 4104-C**.

➤ Create a new project

Start CoDeSys, connect to your CANopen master and create an empty project.




➤ Install the EDS file in the CoDeSys device directory

- Open the CoDeSys device directory.
Path: **Tools / Device Repository**
- Click the **Install** button
- Select the downloaded EDS file from your location.
- Confirm by clicking the **Open** button

Now the CoDeSys software knows the servo drive and it can be used.


➤ Add CANopen Master

Next, a CANopen master must be added. Therefore right click on the Master device and select **Add Device**. The CAN Master must be configured to the same bit rate as the one selected for the servo drive via the Metronix ServoCommander®.



To be able to connect the servo drive to the CAN master, an additional CANopen SoftMotion Manager must be added to the CAN master.


To do this, right click on the CAN master again and select **Add Device**.



› Set cycle period


The SoftMotion Manager runs with a specific cycle time. As cyclic PDO data exchange is used in our application, the master synchronises the servo drive to this cycle time. To do this, the cycle time of the master (**Cycle Period**) must match the cycle time configured in the servo drive.

In the Metronix ServoCommander® you will find the dialog for configuring the cycle time in the menu **Parameters\Controller parameters\Cycle times**. For more information on setting the cycle times, refer to the section *Control circuit cycle times* in the product manual BL 4000 or the ARS 2000 FS product manual.



› Adding devices to the project


Finally, the generation of synchronisation telegrams must be activated in the SoftMotion Manager (**Enable Sync Producing**). Log on to the master by clicking on the **Online Config Mode** button. Search for servo drives on the CANopen field bus by right-clicking on the CANopen SoftMotion Manager and selecting **Scan devices**.



All servo drives connected to the fieldbus are detected and can be added to the project by clicking the **Copy to project** button. Afterwards the selected servo drives are displayed as devices connected to SoftMotion Manager.

➤ Set PDO configuration

After the servo drive has been found, the cyclic data to be exchanged between servo drive and master must be specified. This is called PDO configuration and can be found on the tab with the corresponding servo drive name (in this case **BL 4104-C**).



The standard PDO mapping only uses the PDOs **1400_h** (TPDO0-Master►Slave) and **1800_h** (RPDO0-Master◄Slave).

These PDOs contain the following parameters for operating the servo drive as a SoftMotion axis:


TPDO 0

| Name | ID | Description | See |
|--------------------|-------------------|--|----------|
| controlword | 6040 _h | Control word for activating / deactivating the servo drive | page 106 |
| modes_of_operation | 6060 _h | Configuration of the operating mode of the drive | page 127 |
| homing_method | 6098 _h | Configuring the homing method to be used | page 129 |
| target_position | 607A _h | Position setpoints | page 152 |

RPDO 0


| Name | ID | Description | See |
|----------------------------|-------------------|-------------------------------------|----------|
| statusword | 6041 _h | Current status of the drive | page 106 |
| modes_of_operation_display | 6061 _h | Current operation mode of the drive | page 127 |
| error_register | 1001 _h | Current error code of the drive | page 179 |
| position_actual_value | 6064 _h | Actual position value | page 68 |

Both PDOs must be set to "Cyclic transmission at 1 Sync". This is done by selecting the corresponding PDO and clicking the **Edit** button.




Once the PDO configuration is complete, a SoftMotion axis can be added to the servo drive.

To do this, select the servo drive in SoftMotion Manager. A context menu opens by right-clicking on the list entry (BL_4104_C). Click on the menu item **Add SoftMotion CiA402 Axis**.




➤ Adjust conversion factors

To ensure that the units of the cyclically exchanged values (e.g. for position and speed) match between master and servo drive, the scaling in the servo drive must be adapted to the scaling in the master. Therefore the following scaling should be set in the Metronix ServoCommander® under **Parameters/Field bus/CANopen/Display units**:



With this scaling a maximum of +-32768 revolutions with 16 bit resolution can be displayed on the bus. If this is not sufficient, the scaling of the setpoints transmitted on the bus can be adapted. This is described in section 3.3 *Factor Group* on page 45.

If the scaling is configured correctly, the actual position values should now be displayed in the **Commissioning** window of the CoDeSys SoftMotion axis:



The axis can now be moved from the **Commissioning** tab for testing. In addition, the axis is now ready for implementation in the PLC project. A detailed description of all parameters of the servo drive and the implemented operating modes can be found in section 3 *Parameterisation* on page 38.

2.2 EtherCAT

EtherCAT is a real-time Ethernet developed by Beckhoff Automation. The *CAN application protocol over EtherCAT (CoE)* has been defined to enable an easy changeover from CAN to EtherCAT. This allows the CiA 402 drive controller profile to be used via EtherCAT.

2.2.1 Basics

CoE is based on the CANopen field bus protocol and therefore uses the same object dictionary and the same message types:

- **SDO (Service Data Objects)** This type of message is used for acyclic communication between master and slave, e.g. during the initialization phase of the application or in a very simple application where no cyclic data exchange is required.
- **PDO (Process Data Objects)**
This type of message is exchanged cyclically/automatically between master and slave to exchange process data. Process data is all the data required by the master or slave to execute the application. In our example, this process data contains e.g. position setpoint/actual values, control and status words and other important information to be able to use the servo drive as a SoftMotion axis.

The message type [Emergency Message](#) is also available. This message is sent from the slave to the master if a serious error has occurred in the servo drive.

Other message types, such as [Sync](#) messages, are not supported by EtherCAT CoE, because there are other mechanisms to synchronise several slaves on the fieldbus to a common clock. The most important one is [Distributed Clocks](#) (DC), which are fully supported by the BL 4000 devices series.


Synchronisation is important for motion applications in which several drives execute interpolated movements.

2.2.2 Wiring and pin assignment

In the ARS 2000 FS servo drives, the EtherCAT interface is designed as a plug-in technology module, whereas it is already integrated in the BL 4000-C servo drives. For servo drives of the BL 4000-M / BL 4000-D series, the EtherCAT interface is only available with the PROFINET/EtherCAT field bus variant. For more detailed information, see the *Product Description* section of the Product manual BL 4000-D and BL 4000-M.

>> BL 4000-C, ARS 2000 FS

According to the EtherCAT specification, two RJ45 connectors are available as RTE0 and RTE1 [X21]. One for uplink (connection from the previous drive) and one as downlink (connection to the next servo drive in the line).



The two connections RTE0 and RTE1 are RJ45 sockets, Cat. 6

| Pin | Designation | Description |
|-----|-------------|----------------------|
| 1 | RX- | Receiver signal - |
| 2 | RX+ | Receiver signal + |
| 3 | TX- | Transmitter signal - |
| 4 | - | - |
| 5 | - | - |
| 6 | TX+ | Transmitter signal + |
| 7 | - | - |
| 8 | - | - |

> BL 4000-D and BL 4000-M (Fieldbus variant PROFINET/EtherCAT)

On these devices, the EtherCAT connection is designed as an M8 connector according to IEC 61076-114 (4-pin, socket, D-coded). Note that although the fieldbus variant CAN uses the identical connectors, it is not electrically compatible. The fieldbus variants must not be mixed up and must never be used simultaneously in the same network!




Figure 4: Pin assignment of the fieldbus connector

Pin assignment **EtherCAT/PROFINET**:

| Pin | Name | Description | Colour |
|-----|------|-----------------------|--------|
| 1 | TD+ | Transmission signal + | Yellow |
| 2 | RD+ | Reception signal + | White |
| 3 | TD- | Transmission signal - | Orange |
| 4 | RD- | Reception signal - | Blue |

We recommend using the following pre-assembled cables or comparable products from other manufacturers.

Assembled network cable Phoenix Contact:


M8 plug to M8 plug: NBC-M8MSD/ 1,0-93C/M8MSD - 1423707

M8 plug to RJ45: NBC-M8MSD/ 1,0-93C/R4AC - 1423711

M8 plug to free cable end: NBC-M8MSD/ 1,0-93C - 1423703

2.2.3 Wiring instructions

For cabling, shielded twisted pair Ethernet cables that comply with STP, Cat.5 are used for the EtherCAT bus. All nodes of a network are connected in a linear manner.



2.2.4 Status LEDs (BL 4000-C)

For easy indication of the EtherCAT bus status, the servo drive series BL 4000-C is equipped with two fieldbus status LEDs. The behaviour of the LEDs is predefined by the EtherCAT User Group (ETG).

The green RUN LED indicates the current EtherCAT® CoE state:


| Flashing code | Status of the State Machine |
|------------------|---|
| LED is off | No communication yet. |
| LED flashes | Pre-Operational (PreOp) The master sets up the slave for cyclic communication. Only asynchronous communication via SDOs is active. |
| LED flashes once | Safe Operation (SafeOp) Cyclic communication via PDOs is running. The slave ignores the setpoint data, but sends actual values to the master. |
| LED is on | Operational (OP) The slave accepts setpoints from the master and follows them. |

The red ERR-LED indicates possible fieldbus errors:

| Flashing code | Status of the State machine |
|-------------------|---|
| LED is off | No error |
| LED flashes twice | Cyclic process data watchdog error The fieldbus communication is interrupted. The slave has not received setpoints from the master. |

2.2.5 Activate EtherCAT

The EtherCAT fieldbus communication must be activated once via the EtherCAT window of the Metronix ServoCommander® ([Parameters / Field bus / EtherCAT / Operating parameters](#)).



INFORMATION Servo drive blocks communication to succeeding slaves

Note that a servo drive with a deactivated Ethercat interface blocks communication to all following slaves on the fieldbus. Therefore a deactivated servo drive should be removed from the network.

2.2.6 Integration of the servo drive in a master project


As an example, the servo drive BL 4104-C is to be inserted as a SoftMotion axis in a PLC project based on CoDeSys V3.5 and Beckhoff TwinCAT. The integration of other servo drives, e.g. of an ARS 2000 FS, is done in the same way.

› Integration into the CoDeSys V3.5 project

As a prerequisite you must download the EtherCAT ESI file for the corresponding servo drive from the Metronix website (<https://www.metronix.de>). This file contains a complete description of the drive features and the object dictionary and is used by CoDeSys (or any other EtherCAT master) to automatically configure the servo drive.

In contrast to the CANopen EDS file, this file contains not only the object dictionary, but also the complete configuration of the servo drive, including the selection of cyclically exchanged setpoints and actual values via PDOs, the configuration of the fieldbus cycle time and all necessary initialization commands to be sent to the servo drive when the fieldbus is started up.


- After downloading the ESI XML file, connect the servo drive to the CoDeSys master via an Ethernet cable.
- Start CoDeSys, connect to your EtherCAT master and create an empty project.



› Install the ESI XML file in the CoDeSys device directory


- Call up the CoDeSys device directory. **Path:** **Tools / Device Repository**
- Click the Install button.
- Select the downloaded EDS file from your location.
- Confirm by clicking the **Open** button.

Now the CoDeSys software knows the servo drive BL 4000-C and it can be used.



➤ Add EtherCAT Master


Next an EtherCAT Master must be added. To do this, right click on the Master device and select **Add Device**.



› Set cycle time


The EtherCAT master exchanges PDOs with the servo drive at a certain cycle time. For this purpose, the servo drive is synchronised by the master to this cycle time. The **Cycle Time** of the servo drive must therefore correspond to the cycle time configured in the EtherCAT master, and Distributed Clock (DC) must be activated in the master.

In the Metronix ServoCommander® you will find the dialog for configuring the cycle time in the menu **Parameters\Controller parameters\Cycle times**. For more information on setting the cycle times, refer to the section *Control circuit cycle times* in the product manual BL 4000 or the ARS 2000 FS product manual.



› Adding devices to the project

Finally, the generation of synchronisation telegrams must be activated in the SoftMotion Manager (**Enable Sync Producing**). Log on to the master by clicking on the **Online Config Mode** button. Search for servo drives on the CANopen field bus by right-clicking on the EtherCAT SoftMotion Manager and selecting **Scan devices**.




All servo drives connected to the fieldbus are detected and can be added to the project by clicking the **Copy to project** button. Afterwards the selected servo drives are displayed as devices connected to SoftMotion Manager.

› Set PDO configuration


In contrast to CANopen, the complete PDO configuration of the cyclic data is done automatically via the ESI XML file, so that a SoftMotion axis can now be added directly to the servo drive.

Right click on the **BL 4104-C** to add a DSP402-compatible SoftMotion axis:




› Adjust conversion factors

To ensure that the units of the cyclically exchanged values (e.g. for position and speed) match between master and servo drive, the scaling in the servo drive must be adapted to the scaling in the master. Therefore the following scaling should be set in the Metronix ServoCommander® under **Parameters/Field bus/CANopen/Display units**:



With this scaling a maximum of ± 32768 revolutions with 16 bit resolution can be displayed on the bus. If this is not sufficient, the scaling of the setpoints transmitted on the bus can be adapted. This is described in section 3.3 *Factor Group* on page 45.

If the scaling is configured correctly, the actual position values should now be displayed in the **Commissioning** window of the CoDeSys SoftMotion axis:




The axis can now be moved from the **Commissioning** tab for testing. In addition, the axis is now ready for implementation in the PLC project. A detailed description of all parameters of the servo drive and the implemented operating modes can be found from section 3 *Parameterisation* on page 38.

2.2.7 EoE (Ethernet over EtherCAT®)

Servo drives of the BL 4000 series support the EoE profile (Ethernet over EtherCAT®). In this case, normal Ethernet packets are also routed by the Ethernet master via the EtherCAT® network. This enables the Metronix ServoCommander® to establish Ethernet communication with the servo drives in the EtherCAT® network without additional cabling of the LAN interfaces.

EoE does not have to be activated separately in the servo drive, but only configured in the EtherCAT® master.


There are two different connection options for the EoE profile. In the first case, the laptop/PC running the Metronix ServoCommander® is connected directly to the controller, in the second case both are operated on a common LAN.




2.2.7.1 Activating EoE in the master

The activation of the EoE function is explained below using the example of a Beckhoff controller. The example assumes that an EtherCAT® network already exists and that cyclic communication with the drives is possible.

Select **Device 1 (EtherCAT®)** in the TwinCAT System Manager and click on **Advanced Settings** in the **EtherCAT** tab




Select the entry **EoE Support** and activate **Virtual Ethernet Switch** and **Connect to TCP/IP Stack**. In the **Windows IP Routing** section, the **IP Enable Router** field must be selected. This enables the forwarding of standard Ethernet packets in the controller.




Finally, EoE support must be activated in the servo drive for each servo drive.

Select the corresponding drive, in this example **Drive 5 (BL 4104)** and click on **Advanced Settings** in the **EtherCAT** tab.



Click **Mailbox / EoE**, enable **Virtual Ethernet Port** and select **IP Port**. At this point you have the choice whether you want to assign a fixed IP address to the device or whether it should be obtained dynamically via DHCP. This requires that a corresponding DHCP server is located in the network.




Finally, the new configuration must be loaded and activated on the controller. The servo drive is now displayed in the device search of the Metronix ServoCommander® as if the servo drive is connected directly via the Ethernet parameterisation interface (X18). If this is not the case, a "bridge" must also be activated within the Beckhoff controller. This is described in the following chapter.

2.2.7.2 Configure Bridge


To make this setting, you must log in directly to the operating system of the Beckhoff controller.

Select **Network and Internet** in the Control Panel. Select the appropriate Ethernet connections (in our case TwinCAT Intel PCI Ethernet Adapter and Beckhoff Virtual Ethernet Adapter).

Press the right mouse button and select **Bridge Connections**.



Afterwards a **Network Bridge** is displayed.



3 Parameterisation

Before the servo drive can perform the desired task (torque control, speed control, positioning), numerous parameters of the servo drive must be adapted to the motor used and the specific application. This can be done either via the Metronix ServoCommander® or via CANopen.

The order in which the parameters are set can be based on the order of the following chapters. If the servo drive is already fully parameterised, you can continue directly with section 4 *Device Control* on page 106 or section 5 *Operating modes* on page 127.

INFORMATION Seven-segment display of the servocontroller shows an "A"

Servo drives with a seven-segment display show an "A" (Attention) if the servo drive has not yet been parameterised. If the servo drive is to be parameterised completely via CANopen, you must write to object `6510h_C0h` to suppress this display. (See section 3.17.1.16 *Object 6510h_C0h: commissioning_state* on page 103).

In addition to the parameters described here in detail, the object directory of the servo drive contains further parameters that must be implemented according to CANopen. However, they usually do not contain any information that can be used meaningfully when building an application with Metronix servo drives. If required, the specification of such objects can be found in the corresponding standards (see section 7.1 *CANopen* on page 190).

› Description of the parameters

All parameters of the drive are described in a uniform way. If the parameter is a simple data type (VAR), it is described as follows:

| | | | | |
|-------|-----------------------|----|---------------|-----------|
| Index | Index (hexadecimal) | | | |
| Name | Name of the parameter | | | |
| Info | Unit | rw | PDO | Data type |
| Value | Value range | | Default value | |

If the parameter is a structured data type (ARRAY/RECORD), it is described as follows:

| | | | | |
|-----------|-----------------------------|----|----------------|-----------|
| Index | Index (hexadecimal) | | | |
| Name | Name of the parameter group | | | |
| Type | Object Code | | | Max |
| Sub-Index | Subindex (hexadecimal) | | | |
| Name | Name of the parameter | | | |
| Info | Unit | rw | PDO | Data type |
| Value | Value range | | Default value | |

The individual fields have the following meaning:

| Field | Meaning |
|-----------------------------|---|
| Index (hexadecimal) | The main index of the described parameter. |
| Subindex (hexadecimal) | The subindex of the described parameter. If this is not specified, the subindex is zero. |
| Name of the parameter group | Plain text name of the parameter group. |
| Name of the parameter | Plain text name of the parameter. |
| Object Code | Specifies whether the data type is simple or structured: <ul style="list-style-type: none"> • VAR: Simple data type • ARRAY: Group of parameters that all have the same data type. • RECORD: Group of parameters that have different data types. |
| Max | Maximum subindex of the group. |
| Data type | Data type of the parameter or the ARRAY: A list of the supported data types can be found in section 6.2 <i>Access via SDO</i> on page 166. |
| Unit | Physical unit of the parameter. |
| Access | Specifies whether the parameter may be read (ro), written (wr) or read and written (rw). |
| PDO PDO | Specifies whether the parameter may be mapped into a PDO. |
| Value range | The range of permissible values for this parameter. |
| Default value | Value that is effective on factory setting or after successful writing to 3.1.2.1 <i>Object 1011h: restore_default_parameters</i> . |

3.1 Loading and saving parameter sets

3.1.1 Overview

The servo drive has three parameter sets:

Current parameter set

This parameter set is located in the servo drive's volatile memory (RAM) and contains the parameters that are currently in use. It can be read and written as required with the parameterization program Metronix ServoCommander® or via the CAN bus. When the servo drive is switched on, the **Application parameter set** is copied to the **Current parameter set**.


Application parameter set

The **Current parameter set** can be saved in the non-volatile flash memory (EEPROM) so that it is available again after the next power-up. The saving process is triggered with a write access to the CANopen object 1010_h (save_all_parameters).

Default parameter set

This is the unchangeable parameter set of the servo drive specified by the manufacturer as standard. The **Default parameter set** can be copied to the **Current parameter set** by a write operation to the CANopen object 1011_h (restore_all_default_parameters). This copying process is only possible when the power stage is switched off.

The following diagram illustrates the relationships between the individual parameter sets.



Two different concepts for parameter set management are conceivable:

Concept 1: The parameter set is created with the Metronix ServoCommander® and also transferred completely to the individual servo drives with the Metronix ServoCommander®. Using this method, only the objects that are exclusively accessible via CANopen must be set via the CAN bus. The disadvantage here is that the parameterization software is required for each commissioning of a new machine or in the event of a repair (servo drive replacement).

Concept 2: This variant is based on the fact that most application-specific parameter sets differ from the default parameter set only in a few parameters. This makes it possible to rebuild the **Current parameter set** each time the system is switched on via the CAN bus. For this purpose, the master controller first loads the **Default parameter set** by calling the CANopen object 1011_h (restore_all_default_parameters). Then only the deviating objects are transferred, which is very fast due to the small number of objects. An advantage is that this procedure also works with unparameterised servo

drives, so that commissioning new systems or replacing individual servo drives is unproblematic and the parameterization software Metronix ServoCommander® is not required for this purpose.

⚠ CAUTION Risk of injury due to incorrectly parameterised servo drive

An incorrectly parameterised servo drive can cause uncontrolled rotary movements and thus personal injury or damage to property.

Before switching on the power stage for the very first time, make sure that the servo drive contains the desired parameters.

3.1.2 Description of objects

3.1.2.1 Object 1011_h: restore_default_parameters

| | | | |
|-----------|--|----|----------------------|
| Index | 1011 _h | | |
| Name | restore_parameters | | |
| Type | ARRAY | | 01 _h |
| Sub-Index | 01 _h | | |
| Name | restore_all_default_parameters | | |
| Info | -- | rw | DD UINT32 |
| Value | 64616F6C _h („load“), 1 (read access) | -- | |

The object 1011_h_01_h (restore_all_default_parameters) allows the **Current parameter set** to be set to a defined state. To do this, the **Default parameter set** is copied into the **Current parameter set**. The copying process is triggered when "load" is written in hexadecimal form to this object.

This command is only executed when the output stage is deactivated. Otherwise the SDO error is issued. If the wrong identifier is sent, error is issued. If the object is accessed in read mode, a 1 is returned to indicate that resetting to default values is supported.

3.1.2.2 Object 1010_h: store_parameters

| | | | | |
|-----------|--|----|----------------|-----------------|
| Index | 1010 _h | | | |
| Name | store_parameters | | | |
| Type | ARRAY | | | 01 _h |
| Sub-Index | 01 _h | | | |
| Name | save_all_parameters | | | |
| Info | -- | rw | PBO | UINT32 |
| Value | 65766173 _h („save“), 1 (read access) | -- | | |

If the **Default parameter set** is also to be saved as the **Application parameter set**, 1010_h_01_h (save_all_parameters must be called in addition.

If the object is written via an SDO, the default behavior is that the SDO is answered immediately. The response therefore does not reflect the end of the saving process. However, the behavior can be changed using object 6510_h_F0_h (compatibility_control).

3.2 Compatibility settings

3.2.1 Overview

The object `compatibility_control` has been introduced in order to remain compatible with earlier device series on the one hand, and to be able to carry out changes and corrections compared to the DSP402 and DS301 on the other. In the default parameter set, this object returns 0, that is, compatibility with earlier versions. For new applications, we recommend that you set the defined bits to ensure the highest possible level of compliance with the standards mentioned.

3.2.2 Description of objects

3.2.2.1 Object 6510_hF0_h: `compatibility_control`

| | | | |
|-----------|-----------------------|----|-----------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | F0 _h | | |
| Name | compatibility_control | | |
| Info | -- | rw | DDQ UINT16 |
| Value | 0...7FFh, see Table | -- | |

| Bit | Name | Value | Description |
|-------|-----------------------|-------------------|---|
| Bit 0 | homing_method_scheme* | 0001 _h | The bit has the same meaning as bit 2 and is present for compatibility reasons. If bit 2 is set, this bit is also set and vice versa. |
| Bit 1 | reserved | 0002 _h | The bit is reserved. It must not be set. |
| Bit 2 | homing_method_scheme | 0004 _h | If this bit is set, the homing methods 32... 35 are numbered according to DSP402, otherwise the numbering is compatible with earlier Metronix implementations (see also section 5.2.3 <i>Homing sequences</i> on page 133). If this bit is set, bit 0 is also set and vice versa. |
| Bit 3 | reserved | 0008 _h | The bit is reserved. It must not be set. |
| Bit 4 | response_after_save | 0010 _h | If this bit is set, the response to <code>save_all_parameters</code> is not sent until saving is complete. This can take several seconds, which may cause a timeout in the PLC. If the bit is cleared, the response is sent immediately, but it must be taken into account that the saving process is not yet complete. |
| Bit 5 | reserved | 0020 _h | The bit is reserved. It must not be set. |

| Bit | Name | Value | Description |
|--------|-------------------|-------------------|--|
| Bit 6 | homing_to_zero | 0040 _h | <p>When using CANopen, the homing run consists of only 2 phases (search run and crawl run). The drive does NOT move to the determined zero position (which may be shifted to the found reference position, e.g. by the homing_offset).</p> <p>If this bit is set, the option selected in the Metronix ServoCommander® under Go to zero position after homing is used. In addition, the value given under max. homing distance permitted is used for the maximum search distance of the reference run.</p> <p>See section 5.2 <i>Homing Mode</i> on page 129.</p> |
| Bit 7 | device_control | 0080 _h | <p>If this bit is set, bit 4 of the statusword (voltage_enabled) is output according to DSP 402 v2.0. In addition, the FAULT_REACTION_ACTIVE state can be distinguished from the FAULT state. See section 4 <i>Device Control</i> on page 106.</p> |
| Bit 8 | reserved | 0100 _h | The bit is reserved. It must not be set. |
| Bit 9 | uzk_preload_ready | 0200 _h | <p>If this bit is set, a set bit 4 (voltage_enabled) in the statusword indicates that the DC link is fully loaded. If this bit is cleared, bit 4 indicates that the output stage is switched on. See section 4 <i>Device Control</i> on page 106.</p> |
| Bit 10 | home_offset_sign | 0400 _h | <p>If this bit is set, the home_offset(607C_h) is subtracted from the reference position instead of added, so that the drive is at the home_offset position (instead of -home_offset) after the reference run.</p> |


3.3 Factor Group

3.3.1 Overview

Usually, the values transmitted via the CAN bus are converted by the controller in such a way that they match the application used. If this is not the case, the scaling of the values transmitted on the bus can be adjusted directly using the [Factor Group](#).

This may also be necessary if the resolution of the values transmitted on the bus is not sufficient, e.g. because the standard settings only allow a differentiation of ± 32768 revolutions.

The servo drive converts the read or written values into its internal units with the help of the [Factor Group](#). For each physical quantity (position, velocity and acceleration) a conversion factor is available to adapt the user units to the own application. The units set by the [Factor Group](#) are generally referred to as `position_unit`, `speed_unit` or `acceleration_unit`. The following figure illustrates the function of the [Factor Group](#):



All parameters in the servo drive are always stored in internal units and are only converted by means of the [Factor Group](#) when writing or reading.

For this reason, the [Factor Group](#) should be set before the very first parameterisation and should not be changed afterwards.

By default, the **Factor Group** is set to the following units:

| Quantity | Designation | Unit | Description |
|--------------|-------------------|------------------------|---|
| Length | position_unit | Increments | 65536 increments per revolution |
| Speed | speed_unit | min ⁻¹ | Revolution per minute |
| Acceleration | acceleration_unit | (min ⁻¹)/s | Speed increase in revolutions per minute per second |

3.3.2 Parameterisation of the Factor Group

The **Factor Group** can be conveniently set via the Metronix ServoCommander®:

Parameters/Field bus/CANopen/Display units or
Parameters/Feld bus/Ethercat/Display units




Figure 5: "CANopen Factor Group" window

Under **Settings/Physical Units** the desired unit for the position values (**Position**), **Speed** and **Acceleration** can be selected separately. In addition, the desired number of decimal places (**Decimals**) and a gear (**Gearbox**) can be included.

If a length unit is selected as the position unit, the **Feed constant** can also be specified.

The results of the setting selected in this way are displayed under **Calculated Factor Group** and can be transferred to the servo drive by clicking the **Apply Factor Group** button.

3.3.3 Description of objects

3.3.3.1 Object 6093_h: position_factor

The object **position_factor** is used to convert all length units of the application from **position_unit** to the internal unit **increments** (65536 increments correspond to 1 revolution). It consists of numerator and denominator. The **position_factor** must not be greater than 2^{24} .

| | | | | |
|-----------|-------------------|----|-----|-----------------|
| Index | 6093 _h | | | |
| Name | position_factor | | | |
| Type | ARRAY | | | 02 _h |
| Sub-Index | 01 _h | | | |
| Name | numerator | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | 1 | | |
| Sub-Index | 02 _h | | | |
| Name | divisor | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | 1 | | |

3.3.3.2 Object 6094_h: velocity_encoder_factor

The object **velocity_encoder_factor** is used to convert all velocity values of the application from **speed_unit** to the internal unit **revolutions per 4096 minutes**. It consists of numerator and denominator.

| | | | | |
|-----------|-------------------------|-------------------|-----|-----------------|
| Index | 6094 _h | | | |
| Name | velocity_encoder_factor | | | |
| Type | ARRAY | | | 02 _h |
| Sub-Index | 01 _h | | | |
| Name | numerator | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | 1000 _h | | |
| Sub-Index | 02 _h | | | |
| Name | divisor | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | 1 | | |

3.3.3.3 Object 6097_h: acceleration_factor

The object [acceleration_factor](#) is used to convert all acceleration values of the application from [acceleration_unit](#) to the internal unit **revolutions per minute per 256 seconds**. It consists of numerator and denominator.

| | | | | |
|-----------|---------------------|------------------|-----|-----------------|
| Index | 6097 _h | | | |
| Name | acceleration_factor | | | |
| Type | ARRAY | | | 02 _h |
| Sub-Index | 01 _h | | | |
| Name | numerator | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | 100 _h | | |
| Sub-Index | 02 _h | | | |
| Name | divisor | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | 1 | | |

3.3.3.4 Object 607E_h: polarity

The sign of the position and velocity values of the servo drive can be set with the [polarity](#) object. This can be used to invert the direction of rotation of the motor with identical setpoints.

In most applications it is useful to set the [position_polarity_flag](#) and the [velocity_polarity_flag](#) to the same value.

Setting the [position_polarity_flag](#) or the [velocity_polarity_flag](#) only affects parameters during reading and writing. Parameters already present in the servo drive are not changed.

| | | | | |
|-------|--|----|-----|-------|
| Index | 607E _h | | | |
| Name | polarity | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 0, 40 _h , 80 _h , C0 _h | | | -- |

| Bit | Value | Name | Description |
|-----|-----------------|------------------------|--|
| 6 | 40 _h | velocity_polarity_flag | 0: multiply by 1 (default) 1: multiply by -1 (invers) |
| 7 | 80 _h | position_polarity_flag | 0: multiply by 1 (default) 1: multiply by -1 (invers) |

3.4 Power stage parameters

3.4.1 Overview

The DC link is supplied with mains voltage via a pre-charging circuit. This limits the current and controls the charging process. The precharge control is bypassed when the DC link is fully charged. This state is a condition for enabling the servo drive. The rectified mains voltage is smoothed with the capacitors of the DC link. The motor is supplied from the DC link via the IGBTs.

The output stage contains a number of monitoring functions, some of which can be parameterised:

- Controller enable logic (software- and hardware enable)
- Overvoltage / undervoltage monitoring of the DC link
- Overcurrent monitoring
- Power section monitoring

3.4.2 Description of objects

3.4.2.1 Object 6510_h_10_h: enable_logic

To enable the power stage of the servo drive, the digital inputs **Power stage enable** (ARS 2000 FS only) and **Controller enable** must be set: The **Power stage enable** acts directly on the control signals of the power transistors and would be able to interrupt them even if the microprocessor were defective. Removing the **Power stage enable** while the motor is running thus causes the motor to coast down unbraked or to be stopped only by the possibly existing holding brake. The **Controller enable** is processed by the microcontroller of the servo drive. Depending on the operating mode, the servo drive reacts differently after this signal is disabled:

› Positioning mode and speed-controlled operation

After resetting the signal, the motor is braked with a defined braking ramp. The output stage is only switched off when the motor speed is below 10 min⁻¹ and the holding brake, if present, has been applied.

› Torque-controlled operation

The output stage is switched off immediately after the signal is reset. At the same time a possibly existing holding brake is applied. The motor coasts down unbraked or is only stopped by a possibly existing holding brake.

⚠ DANGER ⚠ **Danger to life due to electric shock!**

Removing the **Controller enable** or the **Power stage enable** does not guarantee that the motor is voltage-free.

When operating the servo drive via CAN or EtherCAT, the two digital inputs **Power stage enable** and **Controller enable** can be commonly connected to 24V and the enable controlled via the bus. To do this, object **6510_h_10_h** (**enable_logic**) must be set to 2 (for CAN) or 8 (for EtherCAT). For safety reasons, this is done automatically when the fieldbus is activated (even after a reset of the servo drive).

| | | | | |
|-----------|---------------------|----|----------------|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 10 _h | | | |
| Name | enable_logic | | | |
| Info | -- | rw | PBO | UINT16 |
| Value | 0...18 _h | -- | | |

| Value | Description |
|-----------------|-----------------------------------|
| 0 | Digital Input DIN5 |
| 1 _h | DIN5 + Parameterisation interface |
| 2 _h | DIN5 + CAN |
| 3 _h | DIN5 + PROFIBUS/PROFINET |
| 8 _h | DIN5 + EtherCAT |
| 11 _h | Parameterisation interface only |
| 12 _h | CAN bus only |
| 13 _h | PROFIBUS/PROFINET only |
| 18 _h | EtherCAT only |

3.4.2.2 Object 6510_h_30_h: pwm_frequency

The switching losses of the output stage are proportional to the switching frequency of the power transistors. Some servo drives can draw a little more power by halving the normal PWM frequency. However, this increases the current ripple caused by the output stage. Switching is only possible when the output stage is switched off.

| | | | | |
|-----------|-------------------|----|----------------|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 30 _h | | | |
| Name | pwm_frequency | | | |
| Info | -- | rw | PBO | UINT16 |
| Value | 0, 1 | 0 | | |

| Value | Description |
|-------|--------------------------------|
| 0 | Standard power stage frequency |
| 1 | Half power stage frequency |

3.4.2.3 Object 6510_h3A_h: enable_enhanced_modulation

With the object [enable_enhanced_modulation](#) the enhanced sine modulation can be activated. It allows for a better utilization of the DC bus voltage and thus about 14% higher speeds. The disadvantage is that the control behavior and the smooth running of the motor is slightly worse at very low speeds. The parameter may only be changed with the power stage switched off and only becomes effective after a reset. To do this, the parameter set must first be saved ([save_all_parameters](#)).

| | | | | |
|-----------|----------------------------|----|----------------|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 3A _h | | | |
| Name | enable_enhanced_modulation | | | |
| Info | -- | rw | PDO | UINT16 |
| Value | 0, 1 | 0 | | |

| Value | Description |
|-------|------------------------------|
| 0 | Enhanced sine modulation OFF |
| 1 | Enhanced sine modulation ON |

3.4.2.4 Object 6510_h31_h: power_stage_temperature

The temperature of the power stage can be read out via the object [power_stage_temperature](#). If the temperature specified in object 6510_h32_h ([max_power_stage_temperature](#)) is exceeded, the power stage switches off and an error message is issued.

| | | | | |
|-----------|-------------------------|----|-----|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 31 _h | | | |
| Name | power_stage_temperature | | | |
| Info | °C | ro | PDO | INT16 |
| Value | -- | -- | | |

3.4.2.5 Object 6510_h32_h: max_power_stage_temperature

The temperature of the power stage can be read out via the object 6510_h31_h (power_stage_temperature). If the temperature specified in object max_power_stage_temperature is exceeded, the power stage switches off and an error message is issued.

| | | | | | |
|-----------|-----------------------------|----|---------------|-------|-----------------|
| Index | 6510 _h | | | | |
| Name | drive_data | | | | |
| Type | RECORD | | | | F0 _h |
| Sub-Index | 32 _h | | | | |
| Name | max_power_stage_temperature | | | | |
| Info | °C | ro | DD | INT16 | |
| Value | -- | -- | | | |

| Device type | Value | Device type | Value | Device type | Value |
|-------------|-------|-------------|-------|-------------|-------|
| ARS 2102 FS | 100°C | ARS 2320 FS | 80°C | BL 4102-C | 85°C |
| ARS 2105 FS | 80°C | ARS 2340 FS | 80°C | BL 4104-C | 85°C |
| ARS 2302 FS | 80°C | | | BL 4304-C | 90°C |
| ARS 2305 FS | 80°C | | | BL 4308-C | 85°C |
| ARS 2310 FS | 80°C | | | BL 4312-C | 75°C |

3.4.2.6 Object 6510_h33_h: nominal_dc_link_circuit_voltage

Via the object nominal_dc_link_circuit_voltage the device nominal voltage can be read out in millivolts.

| | | | | | |
|-----------|---------------------------------|----|---------------|--------|-----------------|
| Index | 6510 _h | | | | |
| Name | drive_data | | | | |
| Type | RECORD | | | | F0 _h |
| Sub-Index | 33 _h | | | | |
| Name | nominal_dc_link_circuit_voltage | | | | |
| Info | mV | ro | DD | UINT32 | |
| Value | -- | -- | | | |

| Device type | Value | Device type | Value | Device type | Value |
|-------------|--------|-------------|--------|-------------|--------|
| ARS 2102 FS | 360000 | ARS 2320 FS | 560000 | BL 4102-C | 325000 |
| ARS 2105 FS | 360000 | ARS 2340 FS | 560000 | BL 4104-C | 325000 |
| ARS 2302 FS | 560000 | | | BL 4304-C | 560000 |
| ARS 2305 FS | 560000 | | | BL 4308-C | 560000 |
| ARS 2310 FS | 560000 | | | BL 4312-C | 560000 |

3.4.2.7 Object 6510_h34_h: actual_dc_link_circuit_voltage

The object **actual_dc_link_circuit_voltage** can be used to read the current voltage of the DC link in millivolts.

| | | | | | |
|-----------|--------------------------------|----|-----|--------|-----------------|
| Index | 6510 _h | | | | |
| Name | drive_data | | | | |
| Type | RECORD | | | | F0 _h |
| Sub-Index | 34 _h | | | | |
| Name | actual_dc_link_circuit_voltage | | | | |
| Info | mV | ro | PDO | UINT32 | |
| Value | -- | -- | | | |

3.4.2.8 Object 6510_h35_h: max_dc_link_circuit_voltage

The object **max_dc_link_circuit_voltage** specifies the DC link voltage at which the output stage is immediately switched off for safety reasons and an error message is sent.

| | | | | | |
|-----------|-----------------------------|----|----------------|--------|-----------------|
| Index | 6510 _h | | | | |
| Name | drive_data | | | | |
| Type | RECORD | | | | F0 _h |
| Sub-Index | 35 _h | | | | |
| Name | max_dc_link_circuit_voltage | | | | |
| Info | mV | ro | PDO | UINT32 | |
| Value | -- | -- | | | |

| Device type | Value | Device type | Value | Device type | Value |
|-------------|--------|-------------|--------|-------------|--------|
| ARS 2102 FS | 460000 | ARS 2320 FS | 800000 | BL 4102-C | 439979 |
| ARS 2105 FS | 460000 | ARS 2340 FS | 800000 | BL 4104-C | 439979 |
| ARS 2302 FS | 800000 | | | BL 4304-C | 799976 |
| ARS 2305 FS | 800000 | | | BL 4308-C | 799976 |
| ARS 2310 FS | 800000 | | | BL 4312-C | 799976 |

3.4.2.9 Object 6510_h36_h: min_dc_link_circuit_voltage

The servo drive has an undervoltage monitor. This can be activated via object 6510_h37_h (enable_dc_link_undervoltage_error). Object 6510_h36_h (min_dc_link_circuit_voltage) specifies the minimum DC link voltage. Below this voltage, error E 02-0 is raised.

| | | | |
|-----------|-----------------------------|----|-----------------------|
| Index | 6410 _h | | |
| Name | motor_data | | |
| Type | RECORD | | 14 _h |
| Sub-Index | 36 _h | | |
| Name | min_dc_link_circuit_voltage | | |
| Info | mV | rw | PBO UINT32 |
| Value | 0...1000000 | -- | |

3.4.2.10 Object 6510_h37_h: enable_dc_link_undervoltage_error

The undervoltage monitoring can be activated with the object enable_dc_link_undervoltage_error. The undervoltage monitoring can be activated with the object enable_dc_link_undervoltage_error. Object 6510_h36_h (min_dc_link_circuit_voltage) defines the DC link voltage below which an error is raised.

| | | | |
|-----------|-----------------------------------|----|-----------------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | 37 _h | | |
| Name | enable_dc_link_undervoltage_error | | |
| Info | -- | rw | PBO UINT16 |
| Value | 0, 1 | 0 | |

| Value | Description |
|-------|--|
| 0 | Undervoltage error OFF (reaction Warning) |
| 1 | Undervoltage error ON (reaction Disable servo drive) |

If this object is written, the error reaction of error 02-0 is modified. If 0 is written, the error reaction **Warning** is set. If 1 is written, the error reaction **Disable servo drive** is set. If the object is read, the reaction **Disable servo drive** or higher is reported as 1, all other error reactions as 0. See also section 3.18 *Error management* on page 104.

3.4.2.11 Object 6510_h40_h: nominal_current

The **nominal_current** object can be used to read the nominal device current. This is the upper limit value which can be written into the object 6075_h (**motor Rated current**). Due to a power derating, different values may be read depending on the servo drive cycle time and the power stage clock frequency.

| | | | | | |
|-----------|-------------------|-----------|----------------|--------|-----------------|
| Index | 6510 _h | | | | |
| Name | drive_data | | | | |
| Type | RECORD | | | | F0 _h |
| Sub-Index | 40 _h | | | | |
| Name | nominal_current | | | | |
| Info | mA | ro | PDO | UINT32 | |
| Value | -- | see Table | | | |

| Device type | Value | Device type | Value | Device type | Value |
|-------------|-------|-------------|-------|-------------|-------|
| ARS 2102 FS | 2500 | ARS 2320 FS | 17427 | BL 4102-C | 2000 |
| ARS 2105 FS | 5000 | ARS 2340 FS | 34672 | BL 4104-C | 4000 |
| ARS 2302 FS | 2500 | | | BL 4304-C | 4000 |
| ARS 2305 FS | 5000 | | | BL 4308-C | 8000 |
| ARS 2310 FS | 7127 | | | BL 4312-C | 12000 |

3.4.2.12 Object 6510_h41_h: peak_current

The **peak_current** object can be used to read the maximum device current. This is the upper limit value which can be written into the object 6073_h (**max current**). Due to a power derating, different values may be read depending on the servo drive cycle time and the power stage clock frequency.

| | | | | |
|-----------|-------------------|-----------|----------------|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 41 _h | | | |
| Name | peak_current | | | |
| Info | mA | ro | PDO | UINT32 |
| Value | -- | see Table | | |

| Device type | Value | Device type | Value | Device type | Value |
|-------------|-------|-------------|-------|-------------|-------|
| ARS 2102 FS | 5000 | ARS 2320 FS | 31461 | BL 4102-C | 6400 |
| ARS 2105 FS | 10000 | ARS 2340 FS | 53248 | BL 4104-C | 12800 |
| ARS 2302 FS | 7500 | | | BL 4304-C | 12000 |
| ARS 2305 FS | 15000 | | | BL 4308-C | 24000 |
| ARS 2310 FS | 14254 | | | BL 4312-C | 30000 |

3.5 Current controller and motor adaption

NOTICE Damage to property due to incorrect settings

Incorrect settings of the current controller parameters and the current limits can destroy the motor and possibly also the servo drive within a very short time.

3.5.1 Overview

CAUTION Danger of injury due to dangerous movements

If the phase order of the motor or angle encoder cable is twisted, positive feedback may occur, which means that the speed in the motor cannot be controlled. The motor can rotate uncontrolled.

The parameter set of the servo drive must be adapted for the connected motor and the cable set used. The following parameters are affected:

Rated current (depending on the motor)

Overload capacity (depending on the motor)

Number of poles (depending on the motor)

Current controller (depending on the motor)

Direction of rotation (depending on the motor and the phase sequence in the motor and angle encoder cable)

Offset angle (depending on motor and phase sequence in motor and angle encoder cable)

These data must be determined with the program Metronix ServoCommander® when a motor type is used for the first time. For a number of motors you can also obtain ready-made parameter sets from your dealer. Please note that the direction of rotation and offset angle also depend on the cable set used. The parameter sets therefore only work with identical wiring.

3.5.2 Description of objects

3.5.2.1 Object 6075_h: motorRatedCurrent

This value can be taken from the motor nameplate and is entered as an effective value (RMS) in the unit milliamperere. No current can be entered which is above the servo drive rated current (6510_{h_40h}, nominalCurrent).

| | | | | |
|-------|--------------------|----|-----|--------|
| Index | 6075 _h | | | |
| Name | motorRatedCurrent | | | |
| Info | mA | rw | PDO | UINT32 |
| Value | 0...nominalCurrent | -- | | |

INFORMATION Objects not independent

If object 6075_h (motorRatedCurrent) is written with a new value, object 6073_h (maxCurrent) must also be reparameterised in any case.

3.5.2.2 Object 6073_h: max_current

Servo motors may normally be overloaded for a certain period of time. This object is used to set the maximum permissible motor current. It refers to the rated motor current (Object 6075_h, motor Rated current) and is set in thousandths. The value range is limited upwards by the maximum servo drive current (Object 6510_h, 41_h, peak current). Many motors can be overloaded by a factor of 2 for a short time. In this case, the value 2000 must be written into this object. Object 6073_h (max_current) may only be written to after Object 6075_h (motor Rated current) has previously been written with a valid value.

| | | | | |
|-------|--------------------------------|----|-----|--------|
| Index | 6073 _h | | | |
| Name | max_current | | | |
| Info | ‰ (1000 = motor Rated current) | rw | PDO | UINT16 |
| Value | -- | | -- | |

3.5.2.3 Object 604D_h: pole_number

The number of poles of the motor can be taken from the motor data sheet or the parameterization program Metronix ServoCommander®. The number of poles is always even. Often the number of pole pairs is given instead of the number of poles. In this case, the number of poles is twice the number of pole pairs. This object is not changed by restore_default_parameters, but it can be reset by selecting **File / Parameter set / Load default servo parameter set**.

| | | | | |
|-------|-------------------|----|-----|-------|
| Index | 604D _h | | | |
| Name | pole_number | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 2...254 | | -- | |

3.5.2.4 Object 6410_h 11_h: encoder_offset_angle

The servo motors used have permanent magnets on the rotor. These generate a magnetic field whose orientation to the stator depends on the rotor position. For electronic commutation, the servo drive must always adjust the electromagnetic field of the stator at the correct angle to this permanent magnetic field. To do this, it continuously determines the rotor position with an angle encoder (resolver etc.).

The orientation of the angle encoder to the permanent magnetic field must be entered in the object encoder_offset_angle. This angle can be determined with the parameterisation program Metronix ServoCommander® (**Parameters / Device parameters / Encoder / Settings**).

The angle determined with the Metronix ServoCommander® is in the range of ±180°. It must be converted as follows:

$$\text{encoder_offset_angle} = \text{Offset of encoder} \times 32767 / 180^\circ$$

This object is not changed by restore_default_parameters, but it can be reset by selecting **File / Parameter set / Load default servo parameter set**.

| | | | | | |
|-----------|----------------------|----|-----|-------|-----------------|
| Index | 6410 _h | | | | |
| Name | motor_data | | | | |
| Type | RECORD | | | | 14 _h |
| Sub-Index | 11 _h | | | | |
| Name | encoder_offset_angle | | | | |
| Info | 180° / 32767 | rw | PDO | INT16 | |
| Value | -- | -- | | | |

3.5.2.5 Object 6410_h_10_h: phase_order

The **phase_order** object considers twists between motor cable and angle encoder cable. It can be taken from the parameterisation program Metronix ServoCommander®. This object is not changed by **restore_default_parameters**, but it can be reset by selecting **File / Parameter set / Load default servo parameter set**

| | | | | |
|-----------|-------------------|----|----------------|-----------------|
| Index | 6410 _h | | | |
| Name | motor_data | | | |
| Type | RECORD | | | 14 _h |
| Sub-Index | 10 _h | | | |
| Name | phase_order | | | |
| Info | -- | rw | PDO | UINT16 |
| Value | 0, 1 | 0 | | |

| Value | Description |
|-------|-------------|
| 0 | Right |
| 1 | Left |

3.5.2.6 Object 6410_h_03_h: iit_time_motor

Servo motors may normally be overloaded for a certain period of time. This object is used to specify how long the connected motor may be operated with the current specified in object 6073_h (**max_current**). After the I²t time has expired, the current is automatically limited to the value specified in object 6075_h (**motor_rated_current**) to protect the motor. The default setting is two seconds and is applicable for most motors.

| | | | | | |
|-----------|-------------------|----|----------------|-----------------|--|
| Index | 6410 _h | | | | |
| Name | motor_data | | | | |
| Type | RECORD | | | 14 _h | |
| Sub-Index | 03 _h | | | | |
| Name | iit_time_motor | | | | |
| Info | ms | rw | PDO | UINT16 | |
| Value | 0...10000 | -- | | | |

3.5.2.7 Object 6410_h04_h: iit_ratio_motor

The object `iit_ratio_motor` can be used to read the current I²t limitation of the motor in per mille.

| | | | | |
|-----------|-------------------|----|----------------|-----------------|
| Index | 6410 _h | | | |
| Name | motor_data | | | |
| Type | RECORD | | | 14 _h |
| Sub-Index | 04 _h | | | |
| Name | iit_ratio_motor | | | |
| Info | % | ro | PDO | UINT16 |
| Value | -- | -- | | |

3.5.2.8 Object 6510_h3D_h: iit_ratio_servo

The object `iit_ratio_servo` can be used to read the current I²t limitation of the power stage in per mille.

| | | | | |
|-----------|-------------------|----|-----|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 3D _h | | | |
| Name | iit_ratio_servo | | | |
| Info | % | ro | PDO | UINT16 |
| Value | -- | -- | | |

3.5.2.9 Object 6510_h38_h: iit_error_enable

The object `iit_error_enable` defines how the servo drive behaves when the I²t limitation occurs. Either this is only indicated in the `statusword`, or error E 31-0 is raised.

| | | | | |
|-----------|-------------------|----|----------------|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 38 _h | | | |
| Name | iit_error_enable | | | |
| Info | -- | rw | PDO | UINT16 |
| Value | 0, 1 | 0 | | |

| Value | Description |
|-------|--|
| 0 | I ² t error OFF (Reaction Warning) |
| 1 | I ² t error ON (Reaction Disable Servo Drive) |

If this object is written, the error reaction of error 31-0 is modified. If 0 is written, the error reaction **Warning** is set. If 1 is written, the error reaction **Disable servo drive** is set. If the object is read, the reaction **Disable servo drive** or higher is reported as 1, all other error reactions as 0. See section 3.18 *Error management* on page 104.

3.5.2.10 Object 6510_h2E_h: motor_temperature

This object can be used to read out the current motor temperature if an analog temperature sensor is connected. Otherwise, the value of the object is undefined.

| | | | | |
|-----------|-------------------|----|-----|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 2E _h | | | |
| Name | motor_temperature | | | |
| Info | °C | ro | PDO | INT16 |
| Value | -- | -- | | |

3.5.2.11 Object 6410_h 14_h: motor_temperature_sensor_polarity

This object can be used to define whether a normally closed contact or a normally open contact is used as a digital motor temperature sensor.

| | | | | |
|-----------|-----------------------------------|----|-----|-----------------|
| Index | 6410 _h | | | |
| Name | motor_data | | | |
| Type | RECORD | | | 14 _h |
| Sub-Index | 14 _h | | | |
| Name | motor_temperature_sensor_polarity | | | |
| Info | -- | rw | PDO | INT16 |
| Value | 0, 1 | 0 | | |

| Value | Description |
|-------|-------------------------|
| 0 | Normally closed contact |
| 1 | Normally open contact |

3.5.2.12 Object 6510_h 2F_h: max_motor_temperature

If the motor temperature defined in this object is exceeded, the reaction as set in the error management (error E 03-0, motor overtemperature analog) is executed. If a reaction is parameterised which leads to the drive being switched off, an emergency message is sent. For parameterisation of the error management, see section 3.18 *Error management* on page 104.

| | | | | |
|-----------|-----------------------|----|----------------|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 2F _h | | | |
| Name | max_motor_temperature | | | |
| Info | °C | rw | PDO | INT16 |
| Value | 20...300 | -- | | |

3.5.2.13 Object 60F6_h: torque_control_parameters

The data of the current controller must be taken from the parameterisation program Metronix ServoCommander®. The following conversions must be observed:

The gain of the current controller must be multiplied by 256. For a gain of 1.5 in the "Current controller" menu of the parameterisation program Metronix ServoCommander®, the value $384 = 180_{\text{h}}$ must be written into the `torque_control_gain` object.

The time constant of the current controller is specified in milliseconds in the parameterisation program Metronix ServoCommander®. In order to be able to transfer this time constant into the `torque_control_time` object, it must first be converted into microseconds. For a specified time of 0.6 milliseconds, the value 600 must be entered into the `torque_control_time` object accordingly. The lower limit must not be smaller than the current cycle time of the current controller (see section 3.17.1.12 *Object 6510_h_B0_h: cycletime_current_controller* on page 101).

| | | | | |
|-----------|---------------------------|----|----------------|-----------------|
| Index | 60F6 _h | | | |
| Name | torque_control_parameters | | | |
| Type | RECORD | | | 02 _h |
| Sub-Index | 01 _h | | | |
| Name | torque_control_gain | | | |
| Info | 256 = „1“ | rw | PBO | UINT16 |
| Value | 0...(32*256) | -- | | |
| Sub-Index | 02 _h | | | |
| Name | torque_control_time | | | |
| Info | μs | rw | PBO | UINT16 |
| Value | 104...64401 | -- | | |

3.5.2.14 Object 203A_h: torque_feed_forward

Specifies the current feedforward factor. This is parameterised in 10^{-7} A per set acceleration. This allows an acceleration profile set via CANopen to be run and the current during acceleration to be recorded. The quotient of current and acceleration can then be written directly to this object.

| | | | | |
|-------|---------------------|----|----------------|--------|
| Index | 203A _h | | | |
| Name | torque_feed_forward | | | |
| Info | A / (rev/min/s) | rw | PBO | UINT32 |
| Value | 0...208 | -- | | |

3.6 Velocity controller

3.6.1 Overview

NOTICE Damage to property due to incorrect settings

Incorrect settings of the controller parameters can lead to strong vibrations and possibly destroy parts of the machine.

The parameter set of the servo drive must be adapted for the application. Especially the gain is highly dependent on any masses coupled to the motor. The data must be optimally determined during commissioning of the system using the Metronix ServoCommander® parameterisation program.

3.6.2 Description of objects

3.6.2.1 Object 60F9_h: velocity_control_parameters

The data of the speed controller can be taken from the parameterisation program Metronix ServoCommander®. The following conversions must be observed:

The gain of the speed controller must be multiplied by 256. For a gain of 1.5 in the "Speed controller" menu of the parameterisation program, the value 384 = 180_h must be written into the velocity_control_gain object.

The time constant of the speed controller is given in milliseconds in the parameterisation program. In order to be able to transfer this time constant into the object [velocity_control_time](#), it must first be converted into microseconds. For a given time of 2.0 milliseconds, the value 2000 must be entered into the object [velocity_control_time](#) accordingly. The same applies to the object [velocity_control_filter_time](#), with which the actual speed value filter is parameterised.

| | | | | |
|-----------|--------------------------------|----|----------------|-----------------|
| Index | 60F9 _h | | | |
| Name | velocity_control_parameter_set | | | |
| Type | RECORD | | | 04 _h |
| Sub-Index | 01 _h | | | |
| Name | velocity_control_gain | | | |
| Info | 256 = „1“ | rw | PBC | UINT16 |
| Value | 20...(64*256) | -- | | |
| Sub-Index | 02 _h | | | |
| Name | velocity_control_time | | | |
| Info | µs | rw | PBC | UINT16 |
| Value | 1...32000 | -- | | |

| | | | | |
|-----------|-------------------------------------|----|---------------|--------|
| Sub-Index | 04_h | | | |
| Name | velocity_control_filter_time | | | |
| Info | µs | rw | DD | UINT16 |
| Value | 1...32000 | -- | | |

3.6.2.2 Object 2073_h: velocity_display_filter_time

The **velocity_display_filter_time** object can be used to set the filter time of the speed actual value filter, which filters the actual value for display.

| | | | | |
|-------|-------------------------------------|----|---------------|--------|
| Index | 2073_h | | | |
| Name | velocity_display_filter_time | | | |
| Info | µs | rw | DD | UINT32 |
| Value | 1000...50000 | -- | | |

INFORMATION Object is also used for overspeed-protection

Note that the object **velocity_actual_value_filtered** is used for the overspeed-protection. If the filter time is very long, a overspeed error is only detected after a respective delay.

3.7 Position Controller

3.7.1 Overview

This chapter describes all parameters required for the position controller. The position setpoint (`position_demand_value`) from the trajectory generator is applied to the input of the position controller. In addition, the actual position value (`position_actual_value`) is supplied by the angle encoder (resolver, incremental encoder etc.). The behavior of the position controller can be influenced by parameters. To keep the position control loop stable, a limitation of the output variable (`control_effort`) is possible. The output variable is fed into the speed controller as a speed setpoint value. All input and output variables of the position controller are converted by the Factor Group from the application-specific units into the respective internal units of the servo drive.

➤ Following error

The `following_error_actual_value` is the deviation of the actual position value (`position_actual_value`) from the position setpoint (`position_demand_value`). If this following error is larger than specified in the `following_error_window` for a certain period of time, bit 13 `following_error` is set in the `statusword` object. The permissible time period can be specified via the object `following_error_time_out`.




Figure 6: Following error – function overview

Figure 6 "Following error". It is monitored whether the difference between target position (`position_demand_value`) and actual position (`position_actual_value`) leaves the symmetrical `following_error_window`. If the position difference does not return to the window within a certain period of time (`following_error_time_out`), bit 13 in the `statusword` is set.

› Position reached (Target reached)

This function offers the possibility to define a position window around the **target position**. If the actual position of the drive is within this range for a certain time - the **position_window_time** - the associated bit 10 (**target_reached**) is set in the **statusword**.




Figure 7: Position reached - function overview

Figure 7. It is monitored whether the actual position (**position_actual_value**) is within the symmetrical target position window (**target_position+position_window**, **target_position-position_window**). If the actual position remains in the target window longer than the waiting time (**target_window_time**) and the positioning is completed, bit 10 in the **statusword** is set.

3.7.2 Description of objects

3.7.2.1 Object 60FB_n: position_control_parameter_set

The parameter set of the servo drive must be adapted for the application. The data of the position controller must be optimally determined with the aid of the program Metronix ServoCommander® when the machine is commissioned.

NOTICE Damage to property due to incorrect settings

Incorrect settings of the controller parameters can lead to strong vibrations and possibly destroy parts of the machine.

The position controller compares the setpoint position with the actual position and forms a correction speed (object 60FA_n: **control_effort**) from the difference - taking into account the gain and possibly the integrator - which is fed to the speed controller. The position controller is relatively slow compared to the current and speed controller. Therefore, the servo drive works internally with feedforward controls, so that the correction work for the position controller is minimised and the servo drive is quickly in the steady state. A proportional element is normally sufficient as position controller.

The position controller data can be taken from the parameterization program Metronix ServoCommander®. The following conversions must be observed: The gain of the position controller must be multiplied by 256. For a gain of 1.5 in the **Position Controller** window of the parameterization program, the value 384 must be written into the object `position_control_gain`.

Normally the position controller does not need an integrator. In this case, the value zero must be entered in the object `position_control_time`. Otherwise, the time constant of the position controller must be converted into microseconds. For a time of 4.0 milliseconds, the value 4000 must be entered in the object `position_control_time` accordingly. Since the position controller converts even the smallest position deviations into significant correction speeds, in the event of a brief malfunction (e.g. brief clamping of the system), this would result in very violent control reactions with very high correction speeds. This can be avoided if the output of the position controller is limited sensibly (e.g. 500 min⁻¹) via the object `position_control_v_max`.

The object `position_error_tolerance_window` can be used to define the size of a position deviation up to which the position controller does not act (dead band). This can be used for stabilization purposes, for example, if there is backlash in the system.

| | | | | |
|-----------|--|----|----------------|-----------------|
| Index | 60FB_h | | | |
| Name | position_control_parameter_set | | | |
| Type | RECORD | | | 05 _h |
| Sub-Index | 01_h | | | |
| Name | position_control_gain | | | |
| Info | 256 = „1“ | rw | PBO | UINT16 |
| Value | 0...(64*256) | -- | | |
| Sub-Index | 02_h | | | |
| Name | position_control_time | | | |
| Info | µs | rw | PBO | UINT16 |
| Value | 0 | -- | | |
| Sub-Index | 04_h | | | |
| Name | position_control_v_max | | | |
| Info | speed_unit | rw | PBO | UINT32 |
| Value | 0...131072 min ⁻¹ | -- | | |
| Sub-Index | 05_h | | | |
| Name | position_error_tolerance_window | | | |
| Info | position_unit | rw | PBO | UINT32 |
| Value | -- | -- | | |

3.7.2.2 Object 6062_h: position_demand_value

The current position setpoint can be read out via this object. This is fed into the position controller by the travel curve generator.

| | | | | |
|-------|-----------------------|----|-----|-------|
| Index | 6062 _h | | | |
| Name | position_demand_value | | | |
| Info | position_unit | ro | PDO | INT32 |
| Value | -- | -- | | |

3.7.2.3 Object 202D_h: position_demand_sync_value

This object can be used to read the position setpoint of the synchronisation encoder. This is defined by object 2022_h [synchronization_encoder_select](#).

| | | | | |
|-------|----------------------------|----|----------------|-------|
| Index | 202D _h | | | |
| Name | position_demand_sync_value | | | |
| Info | position_unit | ro | PDO | INT32 |
| Value | -- | -- | | |

3.7.2.4 Object 6064_h: position_actual_value

The actual position can be read out via this object. This is fed to the position controller from the angle encoder.

| | | | | |
|-------|-----------------------|----|-----|-------|
| Index | 6064 _h | | | |
| Name | position_actual_value | | | |
| Info | position_unit | ro | PDO | INT32 |
| Value | -- | -- | | |

3.7.2.5 Object 6066_h: following_error_time_out

If a following error - longer than defined in this object - occurs, the corresponding bit 13 [following_error](#) is set in the [statusword](#).

| | | | | |
|-------|--------------------------|----|-----|--------|
| Index | 6066 _h | | | |
| Name | following_error_time_out | | | |
| Info | ms | rw | PDO | UINT16 |
| Value | 0...27314 | -- | | |

3.7.2.6 Object 6065_h: following_error_window

The object `following_error_window` defines a symmetrical range around the position setpoint (`position_demand_value`). If the actual position value (`position_actual_value`) is outside the `following_error_window`, then a following error occurs and bit 13 in the `statusword` is set. The reasons below can cause a following error:

- The drive is blocked
- The positioning speed is too high
- The acceleration values are too high
- The object `following_error_window` has a value that is too small
- The position controller is not correctly parameterised

| | | | | |
|-------|-------------------------------|----|-----|--------|
| Index | 6065_h | | | |
| Name | following_error_window | | | |
| Info | position_unit | rw | PDO | UINT32 |
| Value | -- | | -- | |

3.7.2.7 Object 60F4_h: following_error_actual_value

The current difference between `position_demand_value` (6062_h) and `position_actual_value` (6064_h) can be read from this object.

| | | | | |
|-------|-------------------------------------|----|-----|-------|
| Index | 60F4_h | | | |
| Name | following_error_actual_value | | | |
| Info | position_unit | ro | PDO | INT32 |
| Value | -- | | -- | |

3.7.2.8 Object 60FA_h: control_effort

The output value of the position controller can be read out via this object. This value is fed internally into the speed controller as setpoint value.

| | | | | |
|-------|-------------------------|----|-----|-------|
| Index | 60FA_h | | | |
| Name | control_effort | | | |
| Info | speed_unit | ro | PDO | INT32 |
| Value | -- | | -- | |

3.7.2.9 Object 6410_h_0F_h: rotor_position

The [rotor_position](#) can be read out via the object in per mil of one revolution.

| | | | | | |
|-----------|-------------------|----|-----|--------|-----------------|
| Index | 6410 _h | | | | |
| Name | motor_data | | | | |
| Type | RECORD | | | | 14 _h |
| Sub-Index | 0F _h | | | | |
| Name | rotor_position | | | | |
| Info | % (1000 = 1 rev) | ro | PDO | UINT16 | |
| Value | -- | -- | | | |

3.7.2.10 Object 6067_h: position_window

The object [position_window](#) defines a symmetrical range around the target position. If the actual position value ([position_actual_value](#)) is within this range for a certain time, the [target_position](#) is considered to be reached.

| | | | | | |
|-------|-------------------|----|-----|--------|--|
| Index | 6067 _h | | | | |
| Name | position_window | | | | |
| Info | position_unit | rw | PDO | UINT32 | |
| Value | -- | | -- | | |

3.7.2.11 Object 6068_h: position_window_time

If the actual position of the drive is within the positioning window ([position_window](#)) for as long as defined in this object, the corresponding bit 10 [target_reached](#) is set in the [statusword](#).

| | | | | | |
|-------|----------------------|----|-----|--------|--|
| Index | 6068 _h | | | | |
| Name | position_window_time | | | | |
| Info | ms | rw | PDO | UINT16 | |
| Value | -- | | -- | | |

3.7.2.12 Object 6510_h22_h: position_error_switch_off_limit

The maximum permissible deviation between the target and actual position can be entered in the object `position_error_switch_off_limit`. In contrast to the [Following Error](#) message above, the output stage is switched off immediately if this limit is exceeded and an error is raised. The motor thus coasts down unbraked (unless there is a holding brake).

| | | | |
|-----------|---------------------------------|----|-----------------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | 22 _h | | |
| Name | position_error_switch_off_limit | | |
| Info | position_unit | rw | PDO UINT32 |
| Value | -- | -- | |

| Value | Description |
|-------|--|
| 0 | Switch-off limit following error OFF (Reaction No action) |
| > 0 | Switch-off limit following error ON (Reaction Disable power stage immediately) |

If this object is written, the error reaction of error 17-0 is modified. If 0 is written, the error reaction **No action** is set. If a value greater than 0 is written, the error reaction **Disable power stage immediately** is set. If the object is read, the reaction **Disable power stage immediately** is reported as 1, all other error reactions as 0. See also section 3.18 *Error management* on page 104.

3.7.2.13 Object 2030_h: set_position_absolute

The object `set_position_absolute` can be used to move the readable actual position without changing the physical position. The drive does not carry out any movement. If an absolute encoder system is connected, the position displacement is stored in the encoder, if the encoder system allows this. In this case, the position offset is therefore retained after a reset. This storage operation runs in the background independently of this object. All parameters belonging to the encoder memory are also stored with their current values.

| | | | |
|-------|-----------------------|----|----------------------|
| Index | 2030 _h | | |
| Name | set_position_absolute | | |
| Info | position_unit | wo | PDO INT32 |
| Value | -- | -- | |

3.7.2.14 Object 607D_h: software_position_limit

The object array [software_position_limit](#) contains two sub-parameters that limit the maximum positioning range. If the drive leaves this range in [Profile Position Mode](#), error 40-0 (Negative SW limit switch reached) or 40-1 (Positive SW limit switch reached) is raised.

| | | | | |
|-----------|--------------------------------|----|-----|-----------------|
| Index | 607D_h | | | |
| Name | software_position_limit | | | |
| Type | ARRAY | | | 02 _h |
| Sub-Index | 01_h | | | |
| Name | min_position_limit | | | |
| Info | position_unit | rw | PDO | INT32 |
| Value | -- | -- | | |
| Sub-Index | 02_h | | | |
| Name | max_position_limit | | | |
| Info | position_unit | rw | PDO | INT32 |
| Value | -- | -- | | |

3.7.2.15 Object 607B_h: position_range_limit

The object array [position_range_limit](#) contains two sub-parameters that limit the numerical range of the position values. If one of these limits is exceeded, the actual position value automatically overflows to the other limit. This enables the parameterisation of so-called rotary axes. The limits that should physically correspond to the same position must be specified, for example 0° and 360°.

To make these limits effective, a rotary axis mode must be selected via [6510_h_20_h](#) ([position_range_limit_enable](#)).

| | | | | |
|-----------|---------------------------------|----|-----|-----------------|
| Index | 607B_h | | | |
| Name | position_range_limit | | | |
| Type | ARRAY | | | 02 _h |
| Sub-Index | 01_h | | | |
| Name | min_position_range_limit | | | |
| Info | position_unit | rw | PDO | INT32 |
| Value | -- | -- | | |
| Sub-Index | 02_h | | | |
| Name | max_position_range_limit | | | |
| Info | position_unit | rw | PDO | INT32 |
| Value | -- | -- | | |

3.7.2.16 Object 6510_h20_h: position_range_limit_enable

Via the object `position_range_limit_enable` the range limits defined by the object 607B_h can be activated. Different modes are possible:

If the mode "Shortest distance" is selected, positioning is always carried out on the physically shorter distance to the target. The drive itself adjusts the sign of the travel speed for this purpose. In the two modes with fixed direction of rotation, positioning is always carried out only in the direction specified in the mode.

| | | | | |
|-----------|-----------------------------|----|----------------|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 20 _h | | | |
| Name | position_range_limit_enable | | | |
| Info | -- | rw | PDO | UINT16 |
| Value | 0...5 | -- | | |

| Value | Description |
|-------|---|
| 0 | Off |
| 1 | Shortest distance (for compatibility reasons) |
| 2 | Shortest distance |
| 3 | Reserved |
| 4 | Direction always „positive“ |
| 5 | Direction always „negative“ |

3.8 Setpoint limitation

3.8.1 Object 2415_h: current_limitation

The **current_limitation** object record can be used to limit the maximum current for the motor in the **Profile Position Mode**, **Interpolated Position Mode**, **Cyclic Synchronous Position Mode**, **Homing Mode** and **Profile Velocity Mode**, thus allowing torque-limited speed operation, for example. The **limit_current_input_channel** object is used to specify the source of the limiting torque setpoint. Here you can choose between setting a direct setpoint (fixed value) or using an analogue input. The **limit_current** object is used to specify either the limiting torque (source = fixed value) or the scaling factor for the analogue inputs (source = AINx), depending on the selected source. In the first case, the current is directly limited to the torque-proportional fixed value in mA, in the second case the current in mA is specified, which should correspond to an applied voltage of 10V.

| | | | | |
|-----------|------------------------------------|----|-----|-----------------|
| Index | 2415_h | | | |
| Name | current_limitation | | | |
| Type | RECORD | | | 02 _h |
| Sub-Index | 01_h | | | |
| Name | limit_current_input_channel | | | |
| Info | -- | rw | PDO | INT8 |
| Value | 0...4 | 0 | | |
| Sub-Index | 02_h | | | |
| Name | limit_current | | | |
| Info | mA | rw | PDO | INT32 |
| Value | -- | -- | | |

| Value | Description |
|-------|--|
| 0 | No limit |
| 1 | AIN0 |
| 2 | AIN1 |
| 3 | AIN2 |
| 4 | Fixed value / fieldbus (fieldbus selector 2) |

3.8.2 Object 2416_h: speed_limitation

The **speed_limitation** object group can be used to limit the maximum speed of the motor in **Profile Torque Mode**, thus allowing speed-limited torque operation.

The **limit_speed_input_channel** object is used to specify the setpoint source of the limiting speed. Here you can choose between setting a direct setpoint (fixed value) or using an analogue input. The **limit_speed** object is used to specify either the limiting speed (source = fixed value) or the scaling factor for the analog inputs (source = AINx), depending on the selected source. In the first case, the speed is directly limited to the fixed value, in the second case the speed is specified, which should correspond to an applied voltage of 10V.

| | | | | |
|-----------|----------------------------------|----|----------------|-----------------|
| Index | 2416_h | | | |
| Name | speed_limitation | | | |
| Type | RECORD | | | 02 _h |
| Sub-Index | 01_h | | | |
| Name | limit_speed_input_channel | | | |
| Info | -- | rw | PBO | INT8 |
| Value | 0...4 | 0 | | |
| Sub-Index | 02_h | | | |
| Name | limit_speed | | | |
| Info | speed_unit | rw | PBO | INT32 |
| Value | -- | -- | | |

| Value | Description |
|-------|--|
| 0 | No limit |
| 1 | AIN0 |
| 2 | AIN1 |
| 3 | AIN2 |
| 4 | Fixed value / fieldbus (fieldbus selector 2) |

3.9 Encoder adaptation

3.9.1 Overview

This chapter describes the configuration of the angle encoder input X2A, X2B and the master frequency input (ARS 2000: X10, BL 4000-C: X1).

NOTICE Damage to property due to incorrect angle encoder settings

Incorrect angle encoder settings can cause the drive to rotate uncontrollably and possibly destroy parts of the machine.

3.9.2 Description of objects

3.9.2.1 Object 2024_h: encoder_x2a_data_field

The object record [encoder_x2a_data_field](#) contains parameters that are necessary for the operation of the angle encoder at connector X2A.

Since many encoder settings are only effective after a reset, the selection and setting of the encoders should be done via the Metronix ServoCommander®. The following settings can be read or changed via CANopen:

The object [encoder_x2a_resolution](#) specifies how many increments are generated by the encoder per revolution or length unit. Since only resolvers can be connected to input X2A, which are always evaluated with 16 bits, 65536 is always returned here. The objects [encoder_x2a_numerator](#) and [encoder_x2a_divisor](#) can be used to take into account a possible gear (also with sign) between motor shaft and encoder.

| | | | | |
|-----------|-----------------------------|----|----------------|-----------------|
| Index | 2024 _h | | | |
| Name | encoder_x2a_data_field | | | |
| Type | RECORD | | | 03 _h |
| Sub-Index | 01 _h | | | |
| Name | encoder_x2a_resolution | | | |
| Info | Increments (4 * line count) | ro | PDO | UINT32 |
| Value | -- | -- | | |
| Sub-Index | 02 _h | | | |
| Name | encoder_x2a_numerator | | | |
| Info | -- | rw | PDO | INT16 |
| Value | -32768...-1,1...32767 | 1 | | |
| Sub-Index | 03 _h | | | |
| Name | encoder_x2a_divisor | | | |
| Info | -- | rw | PDO | INT16 |
| Value | 1...32767 | 1 | | |

3.9.2.2 Object 2026_h: encoder_x2b_data_field

The object record [encoder_x2b_data_field](#) contains parameters that are necessary for the operation of the angle encoder at connector X2B.

The object [encoder_x2b_resolution](#) specifies how many increments are generated by the encoder per revolution (for incremental encoders this is four times the number of lines or periods per revolution) or length unit. The object [encoder_x2b_counter](#) returns the currently counted number of increments, i.e. values between 0 and [encoder_x2b_resolution](#)-1.

The objects [encoder_x2b_numerator](#) and [encoder_x2b_divisor](#) can be used to take into account a possible gear (also with sign) between motor shaft and encoder.

| | | | | |
|-----------|--|----|----------------|-----------------|
| Index | 2026 _h | | | |
| Name | encoder_x2b_data_field | | | |
| Type | RECORD | | | 16 _h |
| Sub-Index | 01 _h | | | |
| Name | encoder_x2b_resolution | | | |
| Info | Increments (4 * line count) | rw | PDO | UINT32 |
| Value | -- | -- | | |
| Sub-Index | 02 _h | | | |
| Name | encoder_x2b_numerator | | | |
| Info | -- | rw | PDO | INT16 |
| Value | -32768...-1,1...32767 | 1 | | |
| Sub-Index | 03 _h | | | |
| Name | encoder_x2b_divisor | | | |
| Info | -- | rw | PDO | INT16 |
| Value | 1...32767 | 1 | | |
| Sub-Index | 04 _h | | | |
| Name | encoder_x2b_counter | | | |
| Info | Increments (4 * line count) | ro | PDO | UINT32 |
| Value | 0 ... (encoder_x2b_resolution – 1) | -- | | |

3.9.2.3 Object 2025_h: encoder_x10_data_field

The object record [encoder_x10_data_field](#) contains parameters that are necessary for the operation of the master frequency input, which is located on connector X10 in the ARS 2000 devices series and on connector X1 in the BL 4000 devices series.

A digital incremental encoder or emulated incremental signals, for example from another servo drive (master frequency output), can be connected to the master frequency input. The signals of the master frequency input can optionally be used as setpoint or actual value.

The object [encoder_x10_resolution](#) specifies how many increments are generated by the encoder per revolution (for incremental encoders this is four times the number of

lines or periods per revolution) or length unit. The object `encoder_x10_counter` returns the currently counted number of increments, i.e. values between 0 and `encoder_x10_resolution-1`.

The objects `encoder_x10_numerator` and `encoder_x10_divisor` can be used to take into account a possible gear (also with sign) between motor shaft and encoder. When using the master frequency input as setpoint, this can be used to realise gear ratios between master and slave.

| | | | | |
|-----------|------------------------------------|----|----------------|-----------------|
| Index | 205_h | | | |
| Name | encoder_x10_data_field | | | |
| Type | RECORD | | | 05 _h |
| Sub-Index | 01_h | | | |
| Name | encoder_x10_resolution | | | |
| Info | Increments (4 * line count) | rw | PDO | UINT32 |
| Value | encoder dependent | -- | | |
| Sub-Index | 02_h | | | |
| Name | encoder_x10_numerator | | | |
| Info | -- | rw | PDO | INT16 |
| Value | -32768...-1, 1...32767 | 1 | | |
| Sub-Index | 03_h | | | |
| Name | encoder_x10_divisor | | | |
| Info | -- | rw | PDO | INT16 |
| Value | 1...32767 | 1 | | |
| Sub-Index | 04_h | | | |
| Name | encoder_x10_counter | | | |
| Info | Increments (4 * line count) | ro | PDO | UINT32 |
| Value | 0 ... (encoder_x10_resolution – 1) | -- | | |
| Sub-Index | 05_h | | | |
| Name | encoder_x10_position | | | |
| Info | -- | ro | PDO | INT32 |
| Value | -- | -- | | |

3.9.2.4 Object 202C_h: max_comm_enc_pos_enc_difference

The object `max_comm_enc_pos_enc_difference` returns the maximum difference between the commutation encoder and the actual position encoder.

| | | | | |
|-------|---------------------------------|----|-----|-------|
| Index | 202C _h | | | |
| Name | max_comm_enc_pos_enc_difference | | | |
| Info | position_unit | rw | PDO | INT32 |
| Value | -- | -- | | |

3.10 Master frequency output

3.10.1 Overview

This object group is used to parameterise the master frequency output (ARS 2000 FS: X11, BL 4000-C: X1). Thus, master-slave applications in which the master frequency output (incremental encoder emulation) of the master is connected to the master frequency input of the slave can be parameterised via CANopen.

3.10.2 Description of objects

3.10.2.1 Object 201A_h: encoder_emulation_data

The object record `encoder_emulation_data` contains all options for the master frequency output.

Using the object `encoder_emulation_resolution` the output number of increments (= four times the number of lines) can be set as a multiple of 4. In a master-slave application, this must correspond to the `encoder_X10_resolution` of the slave to achieve a ratio of 1:1.

With the object `encoder_emulation_offset` the position of the output zero pulse can be shifted in relation to the zero position of the actual value encoder.

| | | | |
|-----------|-------------------------------------|----|----------------------|
| Index | 201A_h | | |
| Name | encoder_emulation_data | | |
| Type | RECORD | | 02 _h |
| Sub-Index | 01_h | | |
| Name | encoder_emulation_resolution | | |
| Info | Increments (4 * line count) | rw | PDO INT32 |
| Value | 4 * (1...8192) | -- | |
| Sub-Index | 02_h | | |
| Name | encoder_emulation_offset | | |
| Info | 32767 = 180° | rw | PDO INT16 |
| Value | -32768...32767 | -- | |

3.10.2.2 Object 2028_h: encoder_emulation_resolution

The object `encoder_emulation_resolution` only exists for compatibility reasons. It corresponds to object 201A_h_01_h.

3.11 Setpoint / actual value selection

3.11.1 Overview

The following objects can be used to change the source for the setpoint and the actual value. By default, the servo drive uses the input for the motor encoder X2A or X2B as the actual value for the position controller. When using an external position encoder, e.g. behind a gearbox, the position value fed in via the master frequency input can be used as the actual value for the position controller. Furthermore, it is possible to use the master frequency input as an additional setpoint, which allows synchronous operating modes. For reasons of downward compatibility, the objects for parameterising the master frequency input are always designated "_X10_", even if the master frequency input is located on the connector [X1], as is the case with the BL 4000-C controller family.

3.11.2 Description of objects

3.11.2.1 Object 201F_h: `commutation_encoder_select`

The object `commutation_encoder_select` specifies the encoder input that is used as commutation encoder. Since this value only becomes effective after a reset, the commutation encoder should always be set via the Metronix ServoCommander®.

| | | | | |
|-------|--|----|-----|-------|
| Index | 201F_h | | | |
| Name | <code>commutation_encoder_select</code> | | | |
| Info | -- | rw | DDC | INT16 |
| Value | 0, 2 | -- | | |

| Value | Description |
|-------|-------------|
| 0 | X2A |
| 2 | X2B |

3.11.2.2 Object 2021_h: position_encoder_selection

The object [position_encoder_selection](#) specifies the encoder input that is used to determine the actual position (*actual position encoder*). This value can be changed in order to switch to "position control via an external encoder" (connected to the driven side). It is possible to switch between master frequency input and the encoder input that is selected as *commutation encoder* (X2A or X2B). If one of the encoder inputs X2A / X2B is selected as actual position encoder, the one used as *commutation encoder* must be used. If the respective other encoder is selected, the system automatically switches over to the *commutation encoder*.

| | | | | |
|-------|----------------------------|----|---------------|-------|
| Index | 2021 _h | | | |
| Name | position_encoder_selection | | | |
| Info | -- | rw | DD | INT16 |
| Value | 0...2 | -- | | |

| Value | Description |
|-------|------------------------|
| 0 | X2A |
| 1 | X2B |
| 2 | Master frequency input |

INFORMATION Permissible combinations

The following combinations are **permitted**:

Commutating encoder X2A, position encoder: master frequency input
 Commutating encoder X2B, position encoder: master frequency input

The following combinations are **not permitted**:

Commutating encoder X2A, position encoder: X2B
 Commutating encoder X2B, position encoder: X2A

3.11.2.3 Object 2022_h: synchronisation_encoder_selection

The object [synchronisation_encoder_selection](#) specifies the encoder input via which the synchronisation setpoint is fed in. Depending on the operating mode, this is equivalent to a position setpoint ([Profile Position Mode](#)) or a speed setpoint ([Profile Velocity Mode](#)). Only the master frequency input can be used as synchronisation input. Thus, it is possible to select between "Master frequency input" and "No encoder". Do not select the same input as used for the actual value encoder as the synchronisation setpoint.

| | | | | |
|-------|-----------------------------------|----|---------------|-------|
| Index | 2022 _h | | | |
| Name | synchronisation_encoder_selection | | | |
| Info | -- | rw | DD | INT16 |
| Value | -1, 2 | -- | | |

| Value | Description |
|-------|------------------------|
| -1 | No encoder / undefined |
| 2 | Master frequency input |

3.11.2.4 Object 202F_h: synchronisation_selector_data

The object [synchronisation_main](#) can be used to activate a synchronous setpoint. Bit 0 must be set so that the synchronous setpoint is calculated at all. Bit 1 enables the synchronous position to be switched on only after starting a position set (flying saw). Bit 8 can be used to specify that the homing run should be executed without switching on the synchronous position in order to be able to reference the master and slave separately.

| | | | |
|-----------|--------------------------------------|----|-----------------------|
| Index | 202F_h | | |
| Name | synchronisation_selector_data | | |
| Type | RECORD | | 07 _h |
| Sub-Index | 07_h | | |
| Name | synchronisation_main | | |
| Info | -- | rw | PBO UINT16 |
| Value | see Table | -- | |

| Bit | Value | Description |
|-----|-------------------|---|
| 0 | 0001 _h | 0: Synchronisation inactive 1: Synchronisation active |
| 1 | 0002 _h | 0: "Flying saw" inactive 1: "Flying saw" active |
| 8 | 0100 _h | 0: Synchronization during homing 1: No synchronization during homing |

3.11.2.5 Object 2023_h: synchronisation_filter_time

The object [synchronisation_filter_time](#) is used to define the filter time constant of a PT1 filter with which the synchronisation speed is smoothed. This may be necessary especially with low line numbers, since even small changes of the input value correspond to high speeds. On the other hand, the drive may no longer be able to follow a dynamic input signal fast enough at high filter times.

| | | | |
|-------|------------------------------------|----|-----------------------|
| Index | 2023_h | | |
| Name | synchronisation_filter_time | | |
| Info | µs | rw | PBO UINT32 |
| Value | 10...50000 | -- | |

3.12 Analogue inputs

3.12.1 Overview

The servo drives have analogue inputs, which may be used to provide setpoints to the servo drive, for example. For all these analogue inputs, the following objects offer the possibility of reading out the current input voltage ([analog_input_voltage](#)) and setting an offset ([analog_input_offset](#)). Depending on the servo drive series (BL 4000-M / BL 4000-D, BL 4000-C, ARS 2000 FS), there are different numbers of analogue inputs.

3.12.2 Description of objects

3.12.2.1 Object 2400_h: analog_input_voltage

The object group [analog_input_voltage](#) supplies the current input voltage of the respective channel in millivolts including the offset.

| | | | | |
|-----------|---------------------------|----|-----|-----------------|
| Index | 2400 _h | | | |
| Name | analog_input_voltage | | | |
| Type | ARRAY | | | 03 _h |
| Sub-Index | 01 _h | | | |
| Name | analog_input_voltage_ch_0 | | | |
| Info | mV | ro | PDO | INT16 |
| Value | -- | -- | | |
| Sub-Index | 02 _h | | | |
| Name | analog_input_voltage_ch_1 | | | |
| Info | mV | ro | PDO | INT16 |
| Value | -- | -- | | |
| Sub-Index | 03 _h | | | |
| Name | analog_input_voltage_ch_2 | | | |
| Info | mV | ro | PDO | INT16 |
| Value | -- | -- | | |

3.12.2.2 Object 2401_h: analog_input_offset

Via the object group [analog_input_offset](#) the offset voltage in millivolts can be set or read for the respective inputs. With the help of the offset, a possible applied DC voltage can be compensated. A positive offset compensates a positive input voltage.

| | | | | |
|-----------|--------------------------|----|---------------|-----------------|
| Index | 2401 _h | | | |
| Name | analog_input_offset | | | |
| Type | ARRAY | | | 03 _h |
| Sub-Index | 01 _h | | | |
| Name | analog_input_offset_ch_0 | | | |
| Info | mV | rw | DD | INT32 |
| Value | -10000...10000 | -- | | |
| Sub-Index | 02 _h | | | |
| Name | analog_input_offset_ch_1 | | | |
| Info | mV | rw | DD | INT32 |
| Value | -10000...10000 | -- | | |
| Sub-Index | 03 _h | | | |
| Name | analog_input_offset_ch_2 | | | |
| Info | mV | rw | DD | INT32 |
| Value | -10000...10000 | -- | | |

3.13 Digital inputs and outputs

3.13.1 Overview

All digital inputs of the servo drive can be read via the CAN bus and almost all digital outputs can be set as required. Furthermore, status messages can be assigned to the digital outputs of the servo drive. With the ARS 2000 FS, the optional EA88 technology module can also be parameterised in this way. Depending on the devices series, not all digital inputs/outputs described here may be available for every device.

3.13.2 Description of objects

3.13.2.1 Object 60FD_h: digital_inputs

Via the object 60FD_h the digital inputs may be read:

| | | | | |
|-------|-------------------|----|-----|--------|
| Index | 60FD _h | | | |
| Name | digital_inputs | | | |
| Info | -- | ro | PDO | UINT32 |
| Value | see Table | | -- | |

| Bit | Value | Digital input |
|---------|-----------------------|--|
| 0 | 00000001 _h | Negative limit switch |
| 1 | 00000002 _h | Positive limit switch |
| 2 | 00000004 _h | Reference switch |
| 3 | 00000008 _h | Interlock (Controller enable or Powerstage enable or STO missing) |
| 16...23 | 00FF0000 _h | Additional digital inputs of an EA88 module (EA88-0), if present |
| 24...27 | 0F000000 _h | DIN0...DIN3 |
| 28 | 10000000 _h | DIN8 |
| 29 | 20000000 _h | ARS 2000: DIN9, BL 4100-C: DIN4 |

3.13.2.2 Object 60FE_h: digital_outputs

Via object 60FE_h the digital outputs may be controlled. A set bit in object [digital_outputs_mask](#) specifies which digital output is to be controlled. Via the [digital_outputs_data](#) object the selected outputs can then be set as required. Please note that a delay of up to 10 ms can occur when controlling the digital outputs. When the outputs are actually set can be determined by reading back object 60FE_h.

| | | | |
|-------|-------------------|-----------------|--|
| Index | 60FE _h | | |
| Name | digital_outputs | | |
| Type | ARRAY | 02 _h | |

| | | | | |
|-----------|----------------------|----|-----|--------|
| Sub-Index | 01 _h | | | |
| Name | digital_outputs_data | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | -- | | |

| | | | | |
|-----------|----------------------|----|-----|--------|
| Sub-Index | 02 _h | | | |
| Name | digital_outputs_mask | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | -- | | |

| Bit | Value | Digital output |
|---------|-----------------------|---|
| 0 | 00000001 _h | 1 = Applying the brake |
| 16...23 | 00FF0000 _h | Additional digital outputs of an EA88 module (EA88-0), if present |
| 25...27 | 0E000000 _h | DOUT1...DOUT3 |

NOTICE Damage to property possible

If control of the brake is enabled via [digital_output_mask](#), the holding brake is released manually by clearing bit 0 in [digital_output_data](#)!

This can cause the axis to drop in the case of hanging axes.

3.13.2.3 Object 2420_h: digital_output_state_mapping

The object group [digital_outputs_state_mapping](#) can be used to issue various status messages of the servo drive via the digital outputs.

For the integrated digital outputs of the servo drive, there is a separate sub-index for each output. For the optionally available outputs of an EA88 module in technology slot 1, four outputs are always combined within a sub-index. This means that a byte is available for each output, in which the function number must be entered.

If such a function has been assigned to a digital output and the output is then switched on or off directly via [digital_outputs](#) (60FE_h), the [digital_outputs_state_mapping](#) object is also set to OFF (0) or ON (12).

| | | | | |
|-----------|-------------------------------|----|----------------|-----------------|
| Index | 2420 _h | | | |
| Name | digital_outputs_state_mapping | | | |
| Type | RECORD | | | 12 _h |
| Sub-Index | 01 _h | | | |
| Name | dig_out_state_mapp_dout_1 | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 0...16, see Table | -- | | |
| Sub-Index | 02 _h | | | |
| Name | dig_out_state_mapp_dout_2 | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 0...16, see Table | -- | | |

| | | | | |
|-----------|----------------------------------|----|----------------|-------|
| Sub-Index | 03_h | | | |
| Name | dig_out_state_mapp_dout_3 | | | |
| Info | -- | rw | PBO | UINT8 |
| Value | 0...16, see Table | -- | | |

| Value | Description | Value | Description |
|-------|---|-------|--------------------------------|
| 0 | Off (Output is low) | 9 | Undervoltage intermed. circuit |
| 1 | Position $X_{\text{set}} = X_{\text{dest}}$ | 10 | Brake unlocked |
| 2 | Position $X_{\text{act}} = X_{\text{dest}}$ | 11 | Power stage active |
| 3 | Reserved | 12 | On (Output is high) |
| 4 | Remaining distance | 13 | Reserved |
| 5 | Homing active | 14 | Reserved |
| 6 | Speed reached | 15 | Linear motor identified |
| 7 | I ² t monitoring active | 16 | Homing position valid |
| 8 | Following error | | |

| | | | | |
|-----------|--------------------------------------|----|----------------|--------|
| Sub-Index | 11_h | | | |
| Name | dig_out_state_mapp_ea88_0_low | | | |
| Info | -- | rw | PBO | UINT32 |
| Value | | -- | | |

| Bit | Mask | Name | Description |
|-----------|-----------------------|-----------------------|---------------------------|
| 0 ... 7 | 000000FF _h | EA88_0_dout_0_mapping | Function for EA88 0 DOUT1 |
| 8 ... 15 | 0000FF00 _h | EA88_0_dout_1_mapping | Function for EA88 0 DOUT2 |
| 16 ... 23 | 00FF0000 _h | EA88_0_dout_2_mapping | Function for EA88 0 DOUT3 |
| 23 ... 31 | FF000000 _h | EA88_0_dout_3_mapping | Function for EA88 0 DOUT4 |

| | | | | |
|-----------|---------------------------------------|----|----------------|--------|
| Sub-Index | 12_h | | | |
| Name | dig_out_state_mapp_ea88_0_high | | | |
| Info | -- | rw | PBO | UINT32 |
| Value | | -- | | |

| Bit | Mask | Name | Description |
|-----------|-----------------------|-----------------------|---------------------------|
| 0 ... 7 | 000000FF _h | EA88_0_dout_4_mapping | Function for EA88 0 DOUT5 |
| 8 ... 15 | 0000FF00 _h | EA88_0_dout_5_mapping | Function for EA88 0 DOUT6 |
| 16 ... 23 | 00FF0000 _h | EA88_0_dout_6_mapping | Function for EA88 0 DOUT7 |
| 23 ... 31 | FF000000 _h | EA88_0_dout_7_mapping | Function for EA88 0 DOUT8 |

3.14 Limit switch / Reference switch

3.14.1 Overview

For defining the reference position of the servo drive, either limit switches or homing switches can be used. More information about the possible homing methods can be found in section 5.2 *Homing Mode* on page 129.

3.14.2 Description of objects

3.14.2.1 Object 6510_h11_h: limit_switch_polarity

The polarity of the limit switches can be programmed by the object 6510_h11_h ([limit_switch_polarity](#)). A zero must be entered in this object for normally closed contacts, a one must be entered when using normally open contacts.

| | | | |
|-----------|-----------------------|----|----------------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | 11 _h | | |
| Name | limit_switch_polarity | | |
| Info | -- | rw | PBO INT16 |
| Value | 0, 1 | 1 | |

| Value | Description |
|-------|-------------------------|
| 0 | Normally closed contact |
| 1 | Normally open contact |

3.14.2.2 Object 6510_h_12_h: limit_switch_selector

Via object 6510_h_12_h ([limit_switch_selector](#)) the assignment of the limit switches (negative, positive) can be swapped without having to make changes to the cabling. To exchange the assignment of the limit switches, enter a one.

| | | | | |
|-----------|-----------------------|----|----------------|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 12 _h | | | |
| Name | limit_switch_selector | | | |
| Info | -- | rw | PDO | INT16 |
| Value | 0, 1 | 0 | | |

| Value | Description |
|-------|--|
| 0 | DIN6 = E0 (negative limit switch) DIN7 = E1 (positive limit switch) |
| 1 | DIN6 = E1 (positive limit switch) DIN7 = E0 (negative limit switch) |

3.14.2.3 Object 6510_h_15_h: limit_switch_deceleration

The [limit_switch_deceleration](#) object determines the deceleration used for braking when the limit switch is reached during normal operation (limit switch emergency ramp).

| | | | | |
|-----------|----------------------------------|----|----------------|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | 15 _h | | | |
| Name | limit_switch_deceleration | | | |
| Info | acceleration_unit | rw | PDO | INT32 |
| Value | 0...3000000 min ⁻¹ /s | -- | | |

3.14.2.4 Object 6510_h_14_h: homing_switch_polarity

The polarity of the reference switch can be configured by object 6510_h_14_h ([homing_switch_polarity](#)). For an opening reference switch, a zero must be entered in this object, for the use of closing contacts a one must be entered.

| | | | | | |
|-----------|------------------------|----|---------------|-------|-----------------|
| Index | 6510 _h | | | | |
| Name | drive_data | | | | |
| Type | RECORD | | | | F0 _h |
| Sub-Index | 14 _h | | | | |
| Name | homing_switch_polarity | | | | |
| Info | -- | rw | DD | INT16 | |
| Value | 0, 1 | 1 | | | |

| Value | Description |
|-------|-------------------------|
| 0 | Normally closed contact |
| 1 | Normally open contact |

3.14.2.5 Object 6510_h_13_h: homing_switch_selector

Object 6510_h_13_h ([homing_switch_selector](#)) determines whether DIN8 or DIN9 should be used as input for the reference switch.

| | | | | | |
|-----------|------------------------|----|---------------|-------|-----------------|
| Index | 6510 _h | | | | |
| Name | drive_data | | | | |
| Type | RECORD | | | | F0 _h |
| Sub-Index | 13 _h | | | | |
| Name | homing_switch_selector | | | | |
| Info | -- | rw | DD | INT16 | |
| Value | 0, 1 | 0 | | | |

| Value | Description |
|-------|-------------|
| 0 | DIN9 |
| 1 | DIN8 |

3.15 Position capturing (Sampling)

3.15.1 Overview

The servo drives offer the possibility of capturing the actual position value on the rising or falling edge of a digital input (e.g. a measuring probe). This position value can then be read out, e.g. for calculation within a control system.

All necessary objects are summarised in the record `sample_data`: The object `sample_mode` determines the type of sampling: Should only a single sample event be recorded or should sampling be continuous. Using the object `sample_status`, the controller can query whether a sample event has occurred. This is indicated by a set bit, which can also be displayed in the `statusword` if the object `sample_status_mask` is set accordingly.

The object `sample_control` is used to control the release of the sample event and the sampled positions can be read out via the objects `sample_position_rising_edge` and `sample_position_falling_edge`.

Which digital input is used can be defined with the Metronix ServoCommander® under [Parameters / IOs / Digital Inputs / Sample Input](#).

3.15.2 Description of objects

3.15.2.1 Object 204A_h: sample_data

| | | | |
|-------|-------------------|--|-----------------|
| Index | 204A _h | | |
| Name | sample_data | | |
| Type | RECORD | | 06 _h |

The following object can be used to select whether the position is to be determined on each occurrence of a sample event (continuous sampling) or whether sampling is to be disabled after a sample event until sampling is enabled again. Please note that even a bouncing input can trigger both edges.

| Sub-Index | 01 _h | | |
|-----------|---------------------|----|-----------------------|
| Name | sample_mode | | |
| Info | -- | rw | PDO UINT16 |
| Value | 0...1 | -- | |
| Value | Description | | |
| 0 | Continuous sampling | | |
| 1 | Autolock sampling | | |

The following object indicates a new sample event.

| | | | | |
|-----------|-----------------------|----|-----|-------|
| Sub-Index | 02_h | | | |
| Name | sample_status | | | |
| Info | -- | ro | PDO | UINT8 |
| Value | 0...3 | -- | | |

| Bit | Value | Name | Description |
|-----|-----------------|-----------------------|--------------------------------------|
| 0 | 01 _h | falling_edge_occurred | = 1: Position sampled (falling edge) |
| 1 | 02 _h | rising_edge_occurred | = 1: Position sampled (rising edge) |

The following object can be used to specify those bits of the [sample_status](#) object that should also lead to the setting of bit 15 of the statusword. This means that the information "Sample event occurred" is available in the statusword, which is usually transferred anyway. Only if "Sample event occurred" is displayed there, the controller must read the [sample_status](#) object to determine which edge has occurred.

| | | | | |
|-----------|---------------------------|----|-----|-------|
| Sub-Index | 03_h | | | |
| Name | sample_status_mask | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 0...3 | -- | | |

| Bit | Value | Name | Description |
|-----|-----------------|----------------------|---|
| 0 | 01 _h | falling_edge_visible | If falling_edge_occured = 1 Bit 15 is set in the statusword |
| 1 | 02 _h | rising_edge_visible | If rising_edge_occured = 1 Bit 15 is set in the statusword |

Setting the respective bit in [sample_control](#) resets the corresponding status bit in [sample_status](#) and, in case of "Autolock" sampling, enables sampling again.

| | | | | |
|-----------|-----------------------|----|-----|-------|
| Sub-Index | 04_h | | | |
| Name | sample_control | | | |
| Info | -- | wo | PDO | UINT8 |
| Value | 0...3 | 0 | | |

| Bit | Value | Name | Description |
|-----|-----------------|---------------------|--------------------------|
| 0 | 01 _h | falling_edge_enable | Sampling on falling edge |
| 1 | 02 _h | rising_edge_enable | Sampling on rising edge |

The following objects contain the sampled positions.

| | | | | |
|-----------|-----------------------------|----|-----|-------|
| Sub-Index | 05 _h | | | |
| Name | sample_position_rising_edge | | | |
| Info | position_unit | ro | PDO | INT32 |
| Value | -- | -- | | |

| | | | | |
|-----------|------------------------------|----|-----|-------|
| Sub-Index | 06 _h | | | |
| Name | sample_position_falling_edge | | | |
| Info | position_unit | ro | PDO | INT32 |
| Value | -- | -- | | |

3.16 Brake control

3.16.1 Overview

The following objects can be used to parameterise how the servo drive controls a holding brake that may be integrated in the motor. The holding brake is always enabled as soon as the servo drive enable is switched on. For holding brakes with high mechanical inertia, a delay time t_A can be parameterised so that the holding brake is engaged before the power stage is switched off (sagging of vertical axes). Similarly, the control of the motor is delayed (t_F) until the holding brake is completely released. Both delays are parameterised simultaneously by the object `brake_delay_time` ($t_A = t_F$).




Figure 8: Function of brake delay (for speed control / positioning)

3.16.2 Description of objects

3.16.2.1 Object 6510_h_18_h: `brake_delay_time`

The braking delay time can be parameterised via the object `brake_delay_time`.

| | | | |
|-----------|-------------------|----|---------------------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | 18 _h | | |
| Name | brake_delay_time | | |
| Info | ms | rw | PBO PBO UINT16 |
| Value | 0...32000 | -- | |

3.17 Device information

Numerous CAN objects can be used to read a wide variety of information from the device, such as servo drive type, firmware used, etc.

3.17.1 Description of objects

3.17.1.1 Object 1000_h: device_type

The [device_type](#) object indicates in the lower 16 bits that device profile 402 is supported and in the upper 16 bits that it is a servo drive (bit 17).

| | | | | |
|-------|-------------------|----|-----------------------|--------|
| Index | 1000 _h | | | |
| Name | device_type | | | |
| Info | -- | ro | DD | UINT32 |
| Value | -- | | 00020192 _h | |

3.17.1.2 Object 1008_h: manufacturer_device_name

Via the object [manufacturer_device_name](#) the name of the device series can be read in plain text.

| | | | | |
|-------|--------------------------|----|----|--------|
| Index | 1008 _h | | | |
| Name | manufacturer_device_name | | | |
| Info | -- | ro | DD | VISSTR |
| Value | -- | | -- | |

3.17.1.3 Object 1009_h: manufacturer_hardware_version

The [manufacturer_hardware_version](#) object can be used to read the hardware revision of the device. This is also displayed in the Metronix ServoCommander® under [Help / Info Tab Firmware / Hardware](#).

| | | | | |
|-------|-------------------------------|----|----|--------|
| Index | 1009 _h | | | |
| Name | manufacturer_hardware_version | | | |
| Info | MMM.SSS | ro | DD | VISSTR |
| Value | -- | | -- | |

| Value | Description |
|-------|--------------|
| M | main version |
| S | sub version |

3.17.1.4 Object 100A_h: manufacturer_software_version

The `manufacturer_software_version` object can be used to read the firmware version in plain text. The individual parts of the version number are formatted as ASCII characters without leading zeros and are separated by dots, e.g. "1.0.0.1.2".

| | | | | |
|-------|-------------------------------|----|-----|--------|
| Index | 100A _h | | | |
| Name | manufacturer_software_version | | | |
| Info | M.S.C.K.k | ro | PDO | VISSTR |
| Value | -- | | -- | |

| Value | Description |
|-------|--|
| M | Corresponds to MMMM of Object 6510h_A9h: firmware_main_version |
| S | Corresponds to SSSS of Object 6510h_A9h: firmware_main_version |
| C | Corresponds to Object 6510h_AAh: firmware_custom_version |
| K | Corresponds to MMMM of Object 6510h_ADh: km_release |
| k | Corresponds to SSSS of Object 6510h_ADh: km_release |

3.17.1.5 Object 1018_h: identity_object

The servo drive can be uniquely identified in a CANopen network via the `identity_object` defined in DS301. For this purpose, the vendor code (`vendor_id`), a unique product code (`product_code`), the revision number of the CANopen implementation (`revision_number`) and the serial number (`serial_number`) can be read out.

| | | | | |
|-----------|-------------------|-----------------------|-----|-----------------|
| Index | 1018 _h | | | |
| Name | identity_object | | | |
| Type | RECORD | | | 04 _h |
| Sub-Index | 01 _h | | | |
| Name | vendor_id | | | |
| Info | -- | ro | PDO | UINT32 |
| Value | -- | 000000E4 _h | | |

| | | | | |
|-----------|-----------------|----|-----|--------|
| Sub-Index | 02 _h | | | |
| Name | product_code | | | |
| Info | -- | ro | PDO | UINT32 |
| Value | -- | -- | | |

| Value | Description | Value | Description |
|-------------------|-------------|-------------------|-------------|
| 2005 _h | ARS 2102 | 2086 _h | ARS 2105 SE |
| 2006 _h | ARS 2105 | 208B _h | ARS 2310 SE |
| 2009 _h | ARS 2302 | 2090 _h | ARS 2108 SE |
| 200A _h | ARS 2305 | 2089 _h | ARS 2302 SE |

| Value | Description | Value | Description |
|-------------------|--------------|-------------------|---------------|
| 200B _h | ARS 2310 | 208A _h | ARS 2305 SE |
| 200C _h | ARS 2320 | 8202 _h | BL 4102-C |
| 2008 _h | ARS 2320W | 8203 _h | BL 4104-C |
| 200D _h | ARS 2340 | 8208 _h | BL 4304-C |
| 200E _h | ARS 2360W | 8209 _h | BL 4308-C |
| 2045 _h | ARS 2102 FS | 8212 _h | BL 4312-C |
| 2046 _h | ARS 2105 FS | 820A _h | BL 4104-M ETH |
| 2050 _h | ARS 2108 FS | 820C _h | BL 4104-D ETH |
| 2049 _h | ARS 2302 FS | 820D _h | BL 4840-M ETH |
| 204A _h | ARS 2305 FS | 820F _h | BL 4840-D ETH |
| 204B _h | ARS 2310 FS | 820B _h | BL 4104-M CAN |
| 204C _h | ARS 2320 FS | 8210 _h | BL 4104-D CAN |
| 204D _h | ARS 2340 FS | 820E _h | BL 4840-M CAN |
| 204E _h | ARS 2360W FS | 8211 _h | BL 4840-D CAN |
| 2085 _h | ARS 2102 SE | | |

| | | | | |
|-----------|-----------------|-----------------------|-----|--------|
| Sub-Index | 03 _h | | | |
| Name | revision_number | | | |
| Info | -- | ro | PDO | UINT32 |
| Value | -- | 00040002 _h | | |

| | | | | |
|-----------|-----------------|----|-----|--------|
| Sub-Index | 04 _h | | | |
| Name | serial_number | | | |
| Info | -- | ro | PDO | UINT32 |
| Value | -- | -- | | |

3.17.1.6 Object 6510_h_A0_h: drive_serial_number

The object `drive_serial_number` returns the serial number of the servo drive . This object is used to ensure compatibility with earlier versions.

| | | | | |
|-------|-------------------|--|--|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |

| | | | | |
|-----------|---------------------|----|-----|--------|
| Sub-Index | A0 _h | | | |
| Name | drive_serial_number | | | |
| Info | -- | ro | PDO | UINT32 |
| Value | -- | -- | | |

3.17.1.7 Object 6510_h_A1_h: drive_type

The **drive_type** object can be used to read the product code of the servo drive. This object is used to ensure compatibility with earlier versions.

| | | | | |
|-----------|---|----|-----|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | A1 _h | | | |
| Name | drive_type | | | |
| Info | see 1018 _h _02 _h (product code) | ro | DDC | UINT32 |
| Value | see 1018 _h _02 _h (product code) | -- | | |

3.17.1.8 Object 6510_h_A9_h: firmware_main_version

The **firmware_main_version** object can be used to read the main version number of the firmware (product step).

| | | | | |
|-----------|-----------------------|----|-----|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | A9 _h | | | |
| Name | firmware_main_version | | | |
| Info | MMMMSSSS _h | ro | DDC | UINT32 |
| Value | -- | -- | | |

| Value | Description |
|-------|--------------|
| M | main version |
| S | sub version |

3.17.1.9 Object 6510_h_AA_h: firmware_custom_version

The object **firmware_custom_version** can be used to read the version number of the customer-specific variant of the firmware.

| | | | | |
|-----------|-------------------------|----|-----|-----------------|
| Index | 6510 _h | | | |
| Name | drive_data | | | |
| Type | RECORD | | | F0 _h |
| Sub-Index | AA _h | | | |
| Name | firmware_custom_version | | | |
| Info | -- | ro | DDC | UINT32 |
| Value | -- | -- | | |

3.17.1.10 Object 6510_hAD_h: km_release

The version number of the **km_release** can be used to differentiate between firmware versions of the same product level.

| | | | |
|-----------|-----------------------|----|-----------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | AD _h | | |
| Name | km_release | | |
| Info | MMMMSSSS _h | ro | DDC, UINT32 |
| Value | -- | -- | |

| Value | Description |
|-------|--------------|
| M | main version |
| S | sub version |

3.17.1.11 Object 6510_hAC_h: firmware_type

The **firmware_type** object can be used to read out the devices series and encoder type for which the loaded firmware is suitable. Since the encoder interface has no longer been pluggable as of the ARS 2000 series, all bits in the parameter G are always set (F_h).

| | | | |
|-----------|-----------------------|----|-----------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | AC _h | | |
| Name | firmware_type | | |
| Info | 000000GX _h | ro | DDC, UINT32 |
| Value | F2 _h | -- | |

| Value (X) | Description |
|----------------|--|
| 0 _h | IMD-F |
| 1 _h | ARS |
| 2 _h | ARS 2000, ARS 2000 FS, ARS 2000 SE and BL 4000-C |

3.17.1.12 Object 6510_h_B0_h: cycletime_current_controller

The object `cycletime_current_controller` returns the cycle time of the current controller in microseconds.

| | | | |
|-----------|------------------------------|----|-----------------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | B0 _h | | |
| Name | cycletime_current_controller | | |
| Info | μs | ro | PDO UINT32 |
| Value | -- | -- | |

3.17.1.13 Object 6510_h_B1_h: cycletime_velocity_controller

The object `cycletime_velocity_controller` returns the cycle time of the speed controller in microseconds.

| | | | |
|-----------|-------------------------------|----|-----------------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | B1 _h | | |
| Name | cycletime_velocity_controller | | |
| Info | μs | ro | PDO UINT32 |
| Value | -- | -- | |

3.17.1.14 Object 6510_h_B2_h: cycletime_position_controller

The object `cycletime_position_controller` returns the cycle time of the position controller in microseconds.

| | | | |
|-----------|-------------------------------|----|-----------------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | B2 _h | | |
| Name | cycletime_position_controller | | |
| Info | μs | ro | PDO UINT32 |
| Value | -- | -- | |

3.17.1.15 Object 6510_h_B3_h: cycletime_trajectory_generator

The object `cycletime_trajectory_generator` returns the cycle time of the trajectory generator in microseconds.

| | | | |
|-----------|--------------------------------|----|-----------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | B3 _h | | |
| Name | cycletime_trajectory_generator | | |
| Info | μs | ro | DDC, UINT32 |
| Value | -- | -- | |

3.17.1.16 Object 6510_h_C0_h: commissioning_state

NOTICE Unsuitable parameterisation possible

This object does not contain any information about whether the servo drive has been parameterised correctly according to the motor and the application, but only whether the points mentioned were parameterised at least once after delivery.

INFORMATION „A“ on the 7-segment display

Note that at least one bit must be set in the `commissioning_state` object to suppress the "A" on the display of your servo drive.

| | | | |
|-----------|---------------------|----|----------------------|
| Index | 6510 _h | | |
| Name | drive_data | | |
| Type | RECORD | | F0 _h |
| Sub-Index | C0 _h | | |
| Name | commissioning_state | | |
| Info | -- | rw | DD UINT32 |
| Value | -- | -- | |

| Bit | Description | Bit | Description |
|-----|--|---------|-----------------------------|
| 0 | Nominal current valid | 9 | Reserved |
| 1 | Maximum current valid | 10 | Physical units valid |
| 2 | Number of poles of motor valid | 11 | Speed controller valid |
| 3 | Offset angle / direction of rotation valid | 12 | Position controller valid |
| 4 | Reserved | 13 | Monitoring parameter valid |
| 5 | Offset angle / direction of rotation Hall sensor valid | 14 | Reserved |
| 6 | Reserved | 15 | Limit switch polarity valid |
| 7 | Absolute position encoder system valid | 16...31 | Reserved |
| 8 | Current controller parameters valid | | |

3.17.1.17 Object 20FD_h: user_device_name

The `user_device_name` object can be used to read and write the user-definable name of the drive (e.g. "X-axis").

| | | | |
|-------|-------------------|----|----------------------|
| Index | 20FD _h | | |
| Name | user_device_name | | |
| Info | -- | rw | DD VISSTR |
| Value | -- | -- | |

3.18 Error management

3.18.1 Overview

The servo drives offer the possibility to change the error reaction of individual events, such as the occurrence of a following error. As a result, the servo drive reacts differently when a particular event occurs: Depending on the setting, the servo drive will decelerate, the power stage will be switched off immediately or only a warning will be shown on the display.

A fixed minimum reaction is provided for each event, which must not be fallen below. This means that "critical" errors such as "06-0 short-circuit of the power stage" cannot be reparameterised, as in this case an immediate switch-off is necessary to protect the servo drive from being destroyed.

If a lower error response than permitted for the respective error is entered, the value is limited to the lowest permitted error response. A list of all error numbers can be found in the "Software Manual Servo Positioning Controller ARS 2000" or the "Product Manual smartServo BL 4000".

3.18.2 Description of objects

3.18.2.1 Object 2100_h: error_management

| | | | |
|-------|-------------------|--|-----------------|
| Index | 2100 _h | | |
| Name | error_management | | |
| Type | RECORD | | 02 _h |

In the object `error_number` the main error number is specified whose reaction should be changed. The main error number is the one usually given before the hyphen (for example, error 08-2, main error number 8).

| | | | |
|-----------|-----------------|----|---------------------|
| Sub-Index | 01 _h | | |
| Name | error_number | | |
| Info | -- | rw | DD UINT8 |
| Value | 1...96 | -- | |

The reaction of the error can be changed in the object `error_reaction_code`. If the response is less than the manufacturer's minimum response, the system limits the error to this. The actual reaction set can be determined by reading it back.

| | | | | |
|-----------|----------------------------|----|----------------|-------|
| Sub-Index | 02_h | | | |
| Name | error_reaction_code | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 0, 1, 3, 5, 7, 8 | -- | | |

| Value | Description |
|-------|----------------------------------|
| 0 | No action |
| 1 | Entry into buffer |
| 3 | Warning on the 7-segment display |
| 5 | Disable servo drive |
| 7 | Stop at maximum current |
| 8 | Disable power stage immediately |

3.18.2.2 Object 200F_h: last_warning_code

Warnings are remarkable events of the drive (e.g. a following error), which, in contrast to an error, should not lead to a shutdown of the drive. Warnings are shown on the 7-segment display of the servo drive and are then automatically reset.

The last occurred warning can be read out via the following object: Thereby bit 15 indicates whether the warning is currently still active.

| | | | | |
|-------|--------------------------|----|-----|--------|
| Index | 200F_h | | | |
| Name | last_warning_code | | | |
| Info | -- | ro | PDO | UINT16 |
| Value | -- | -- | | |

| Bit | Value | Description |
|--------|-------------------|---------------------|
| 0... 3 | 000F _h | Warning sub-number |
| 4...11 | 0FF0 _h | Warning main number |
| 15 | 8000 _h | Warning is active |

4 Device Control

4.1 Overview

The following chapter describes how the servo drive is controlled under CANopen, i.e. how the power stage is switched on or an error is acknowledged.

Under CANopen, the entire control of the servo drive can be realised via two objects: The host can operate the servo drive via the [controlword](#), while the status of the servo drive can be read back in the [statusword](#). The following terms are used to explain servo drive control:

| Keyword | Explanation |
|------------------|---|
| State | The servocontroller is in different states depending on whether the power stage is switched on or an error has occurred. The states defined under CANopen are presented in the following chapter. Example: OPERATION_ENABLE |
| State Transition | Like the states, CANopen also defines how to go from one state to another (e.g. to acknowledge an error). State transitions are triggered by the host by setting bits in the controlword or internally by the servocontroller if it detects an error, for example |
| Command | To trigger state transitions, certain combinations of bits must be set in the controlword. Such a combination is called a command. Example: Enable Operation |
| State Machine | The states and state transitions together form the State Machine diagram, i.e. the overview of all states and possible transitions. |

4.2 State Machine

The status diagram can be roughly divided into three areas: "Power Disabled" means that the power stage is switched off and "Power Enabled" means that the power stage is switched on. The "Fault" area summarises the states necessary for error handling.





Figure 9: State diagram of the servo drive

After switching on, the servo drive initialises itself and finally reaches the SWITCH_ON_DISABLED state. In this state, the CAN communication is fully functional and the servo drive can be parameterised (e.g. the operating mode "speed control" can be set). The output stage is switched off and the motor shaft can therefore rotate freely. By means of the state transitions 2, 3, 4 - which in principle corresponds to the CAN servo drive enable - the OPERATION_ENABLE state is reached. In this state, the power stage is switched on and the motor is controlled according to the set operating mode. Therefore, before doing so, make absolutely sure that the drive is correctly parameterised and a corresponding setpoint value is zero. State transition 9 corresponds to disabling the drive, i.e. a motor still running would coast down uncontrolled. If an error occurs, the drive (regardless of its current state) ultimately switches to the FAULT state. Depending on the severity of the fault, certain actions, such as emergency braking, can be carried out beforehand (FAULT_REACTION_ACTIVE).

To execute the mentioned state transitions certain bit combinations must be set in the [controlword](#) (see below). The lower 4 bits of the controlword are evaluated together to trigger a state transition. In the following only the most important state transitions 2, 3, 4, 9 and 15 are explained. A table of all possible states and state transitions can be found at the end of this chapter.

➤ Important state transitions

The following table contains in the 1st column the desired state transition and in the 2nd column the necessary prerequisites for it (usually a command by the host, shown here with a frame). How this command is generated, i.e. which bits are to be set in the **controlword**, can be seen in the 3rd column (x = not relevant).

| No. | Is carried out if | Bit combination (controlword) | | | | | Action |
|-----|--|-------------------------------|--|---|---|---|--|
| | | Bit | 3 | 2 | 1 | 0 | |
| 2 | Power stage and Controller enable + Shutdown | Shutdown | x | 1 | 1 | 0 | No action |
| 3 | Switch On | Switch On | x | 1 | 1 | 1 | Switching on the power stage |
| 4 | Enable Operation | Enable Operation | 1 | 1 | 1 | 1 | Control according to set operating mode |
| 9 | Disable Voltage | Disable Voltage | x | x | 0 | x | Power stage will be disabled. Motor shaft is freely rotatable. |
| 15 | Cause of the error eliminated + Fault Reset | Fault Reset | Bit 7 =  | | | | Error acknowledgement |

EXAMPLE

After the servo drive has been parameterised, the drive should be enabled, i.e. the power stage should be switched on:

1. The servocontroller is in SWITCH_ON_DISABLED state
2. The controller should be set to the OPERATION_ENABLED state
3. The state transitions 2, 3 and 4 must be executed.
4. From the previous table follows:

| Transition | controlword | New state |
|------------|-------------------|--------------------|
| 2 | 0006 _h | READY_TO_SWITCH_ON |
| 3 | 0007 _h | SWITCHED_ON |
| 4 | 000F _h | OPERATION_ENABLE |

Remarks:

- To illustrate the principle, no further bits are set in the **controlword**.
- The transitions 3 and 4 can be combined by writing 000F_h, because the set bit 3 is not relevant for transition 3.
- In each case, it is necessary to wait until the controller has reached this state. This is explained in more detail in the following section.

4.2.1 State diagram: States

In the following table all states and their meaning are listed:

| Name | Description |
|---------------------------------------|--|
| NOT_READY_TO_SWITCH_ON | The servo drive performs a self-test. The CAN communication is not yet working. |
| SWITCH_ON_DISABLED | The servo drive has completed its self-test. CAN communication is possible. |
| READY_TO_SWITCH_ON | The servo drive waits until the digital inputs "Power stage enable" and "Controller enable" are connected to 24 V. (Enable logic "Digital input and CAN"). |
| SWITCHED_ON * ¹⁾ | The power stage is switched on. |
| OPERATION_ENABLE * ¹⁾ | The motor is supplied with voltage and is controlled according to the current operating mode. |
| QUICKSTOP_ACTIVE * ¹⁾ | The Quick Stop Function is executed (see: quick_stop_option_code). The motor is connected to voltage and is controlled according to the Quick Stop Function. |
| FAULT_REACTION_ACTIVE * ¹⁾ | An error has occurred. In the case of critical errors, the device immediately switches to the status Fault. Otherwise, the action specified in the fault_reaction_option_code is executed. The motor is connected to voltage and is controlled according to the Fault Reaction Function. |
| FAULT | An error has occurred. The motor is voltage-free. |

*¹⁾ The power stage is switched on

4.2.2 State diagram: State transitions

⚠ DANGER ⚠ Danger to life due to electric shock!

Power stage disabled means that the power semiconductors are no longer driven. If this state is entered when the motor is rotating, it coasts down unbraked. A mechanical motor brake, if present, is automatically applied.

The signal does not guarantee that the motor is in fact voltage-free.

⚠ CAUTION Uncontrolled behaviour

Power stage enabled means that the motor is controlled according to the selected operating mode. A mechanical motor brake, if present, is automatically released.

In the event of a defect or incorrect parameterisation (motor current, number of poles, resolver offset angle, etc.), the drive may behave in an uncontrolled manner.

The following table lists all state transitions and their meaning:

| No. | Will be executed if | Bit combination (controlword) | | | | | Action |
|-----|--|-------------------------------|---|---|---|---|--|
| | | Bit | 3 | 2 | 1 | 0 | |
| 0 | Switched on or reset | Internal transition | | | | | Perform self-test |
| 1 | Self-test succesful | Internal transition | | | | | Activation of CAN communication |
| 2 | Dig. inputs Power stage enable and Controller enable active + Shutdown | Shutdown | x | 1 | 1 | 0 | - |
| 3 | Switch On | Switch On | x | 1 | 1 | 1 | Power stage switched on |
| 4 | Enable Operation | Enable Operation | 1 | 1 | 1 | 1 | Control according to set operating mode |
| 5 | Disable Operation | Disable Operation | 0 | 1 | 1 | 1 | Power stage is disabled. Motor shaft is freely rotatable. |
| 6 | Shutdown | Shutdown | x | 1 | 1 | 0 | Power stage is disabled. Motor shaft is freely rotatable. |
| 7 | Quick Stop | Quick Stop | x | 0 | 1 | x | - |
| 8 | Shutdown | Shutdown | x | 1 | 1 | 0 | Power stage is disabled. Motor shaft is freely rotatable. |

| No. | Will be executed if | Bit combination (controlword) | | | | | Action |
|-----|---|---------------------------------|---|---|---|---|--|
| | | Bit | 3 | 2 | 1 | 0 | |
| 9 | Disable Voltage | Disable Voltage | x | x | 0 | x | Power stage is disabled. Motor shaft is freely rotatable. |
| 10 | Disable Voltage | Disable Voltage | x | x | 0 | x | Power stage is disabled. Motor shaft is freely rotatable. |
| 11 | Quick Stop | Quick Stop | x | 0 | 1 | x | Braking according to quick_stop_option_code . |
| 12 | Braking finished or Disable Voltage | Disable Voltage | x | x | 0 | x | Power stage is disabled. Motor shaft is freely rotatable. |
| 13 | Error occurred | Internal transition | | | | | For non-critical errors, reaction according to fault_reaction_option_code . For critical errors, transition 14 follows |
| 14 | Error handling is finished | Internal transition | | | | | Power stage is disabled. Motor shaft is freely rotatable. |
| 15 | Cause of error eliminated + Command Fault Reset | Fault Reset | Bit 7 =  | | | | Error acknowledgement (on rising edge) |

4.3 controlword

Object 6040_h: controlword


The **controlword** can be used to change the current state of the servo drive or directly trigger a specific action (e.g. start homing). The function of bits 4, 5, 6 and 8 depends on the current operating mode ([modes_of_operation](#)) of the servo drive, which is explained after this chapter.

| | | | | |
|-------|-------------------|----|-----|--------|
| Index | 6040 _h | | | |
| Name | controlword | | | |
| Info | -- | rw | PDO | UINT16 |
| Value | -- | | | |

| Bit | Value | Function |
|-----|-------------------|--|
| 0 | 0001 _h | Control of the state transitions. (These bits are evaluated together) |
| 1 | 0002 _h | |
| 2 | 0004 _h | |
| 3 | 0008 _h | |
| 4 | 0010 _h | new_set_point / start_homing_operation / enable_ip_mode |
| 5 | 0020 _h | change_set_immediatly |
| 6 | 0040 _h | absolute / relative |
| 7 | 0080 _h | reset_fault |
| 8 | 0100 _h | halt |
| 9 | 0200 _h | Reserved, write 0. |
| 10 | 0400 _h | Reserved, write 0. |
| 11 | 0800 _h | Reserved, write 0. |
| 12 | 1000 _h | Reserved, write 0. |
| 13 | 2000 _h | Reserved, write 0. |
| 14 | 4000 _h | Reserved, write 0. |
| 15 | 8000 _h | Reserved, write 0. |

› Description of the commands (Bits 0...3, Bit 7)

As already extensively described, state transitions can be executed with bits 0...3. The commands required for this are shown here once again in an overview. The [Fault Reset](#) command is generated by a rising edge (from 0 to 1) of bit 7.

| Commands: | Bit 7 | Bit 3 | Bit 2 | Bit 1 | Bit 0 |
|-----------------------------------|---|-------------------|-------------------|-------------------|-------------------|
| | 0080 _h | 0008 _h | 0004 _h | 0002 _h | 0001 _h |
| Shutdown | x | x | 1 | 1 | 0 |
| Switch On | x | x | 1 | 1 | 1 |
| Disable Voltage | x | x | x | 0 | x |
| Quick Stop | x | x | 0 | 1 | x |
| Disable Operation | x | 0 | 1 | 1 | 1 |
| Enable Operation | x | 1 | 1 | 1 | 1 |
| Fault Reset |  | x | x | x | x |

INFORMATION State changes

Since some status changes take a certain amount of time, all status changes triggered by the `controlword` must be read back via the `statusword`. Only when the requested status can also be read in the `statusword` is it permitted to write another command into the `controlword`.

› Description of the other bits

The remaining bits of the `controlword` are explained below. Some of the bits have different meanings depending on the operation mode ([modes_of_operation](#)), i.e. whether the servo drive is speed- or torque-controlled, for example:

| Bit 4 | Depends on <i>modes_of_operation</i> : |
|-------------------------------------|--|
| <code>new_set_point</code> | In Profile Position Mode : A rising edge signals the servocontroller that a new positioning job should be accepted. See also section 5.3 <i>Profile Position Mode</i> on page 139. |
| <code>start_homing_operation</code> | In Homing Mode : A rising edge causes the parameterised homing run to be started. A falling edge terminates an active homing run. |
| <code>enable_ip_mode</code> | In Interpolated Position Mode : This bit must be set to enable the interpolation data sets to be evaluated. It is acknowledged by the bit <code>ip_mode_active</code> in the <code>statusword</code> . For more information see section 5.4 <i>Interpolated Position Mode</i> on page 144 |

| Bit 5 | |
|-----------------------|--|
| change_set_immediatly | Only in Profile Position Mode : If this bit is not set, a possibly running positioning job is processed first and then the new one is started. If this bit is set, a running positioning is immediately aborted and replaced by the new positioning job. It is essential that you also refer to section 5.3 <i>Profile Position Mode</i> on page 139. |
| Bit 6 | |
| relative | Only in Profile Position Mode : When this bit is set, the servocontroller adds the target position (target_position) of the current positioning job to the set position (position_demand_value) of the position controller. |
| Bit 7 | |
| reset_fault | On a rising edge the servocontroller attempts to acknowledge the existing errors. This is only successful if the cause of the error has been eliminated. |
| Bit 8 | Depends on <i>modes_of_operation</i> : |
| halt | In Profile Position Mode : If the bit will be set, the current positioning is aborted. Braking is done with the profile_deceleration . When the process is complete, the bit target_reached is set in the statusword. Clearing the bit has no effect. |
| halt | In Profile Velocity Mode : When the bit will be set, the speed is reduced to zero. Braking is done with the profile_deceleration . Clearing the bit causes the servocontroller to accelerate again. |
| halt | In Profile Torque Mode : When the bit will be set, the torque is reduced to zero. This is done with the torque_slope . Clearing the bit causes the servocontroller to accelerate again. |
| halt | In Homing Mode : When the bit will be set, the current homing run is aborted. Clearing the bit has no effect. |

4.4 Reading the servo drive status

In the same way as various state transitions can be triggered by combining several bits of the [controlword](#), the status of the servocontroller can be read out by combining different bits of the [statusword](#). The following table lists the possible states of the state diagram and the corresponding bit combination with which they are displayed in the [statusword](#).

| State | Bit 6 | Bit 5 | Bit 3 | Bit 2 | Bit 1 | Bit 0 | Mask | Value |
|------------------------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|
| | 0040 _h | 0020 _h | 0008 _h | 0004 _h | 0002 _h | 0001 _h | | |
| Not_Ready_To_Switch_On | 0 | x | 0 | 0 | 0 | 0 | 004F _h | 0000 _h |
| Switch_On_Disabled | 1 | x | 0 | 0 | 0 | 0 | 004F _h | 0040 _h |
| Ready_to_Switch_On | 0 | 1 | 0 | 0 | 0 | 1 | 006F _h | 0021 _h |
| Switched_On | 0 | 1 | 0 | 0 | 1 | 1 | 006F _h | 0023 _h |
| Operation_Enable | 0 | 1 | 0 | 1 | 1 | 1 | 006F _h | 0027 _h |
| Quick_Stop_Active | 0 | 0 | 0 | 1 | 1 | 1 | 006F _h | 0007 _h |
| Fault_Reaction_Active | 0 | x | 1 | 1 | 1 | 1 | 004F _h | 000F _h |
| Fault | 0 | x | 1 | 1 | 1 | 1 | 004F _h | 000F _h |
| Fault (as per DS402) ¹⁾ | 0 | x | 1 | 0 | 0 | 0 | 004F _h | 0008 _h |

INFORMATION FAULT state not implemented according to DS402

¹⁾ In earlier CANopen implementations the FAULT state is not indicated according to DS 402. To get the state indicated according to DS 402, this must be selected in the [compatibility_control](#) (see section 3.2 *Compatibility settings* on page 43). For compatibility to earlier firmware versions, no changes need to be made.

EXAMPLE

The example on page 108 shows which bits must be set in the [controlword](#) to enable the servo drive. In this example, we will explain how the current status of the servo drive is then read from the [statusword](#).

| Transition | controlword | New state | Wait until |
|------------|-------------------|--------------------|--|
| 2 | 0006 _h | READY_TO_SWITCH_ON | (statusword & 006F _h) = 0021 _h |
| 3+4 | 000F _h | OPERATION_ENABLE | (statusword & 006F _h) = 0027 _h |

Remarks:

- To clarify the principle, no further bits are set in the controlword.
- To determine the controller status unambiguously, even bits that are not set must be checked in the [statusword](#). The [statusword](#) must therefore be masked accordingly.

4.5 Statuswords

4.5.1 Object 6041_h: statusword

| | | | | |
|-------|-------------------|----|-----|--------|
| Index | 6041 _h | | | |
| Name | statusword | | | |
| Info | -- | ro | PDO | UINT16 |
| Value | -- | | | |

| Bit | Value | Name |
|-----|-------------------|---|
| 0 | 0001 _h | Status of the servo drive, see section 4.4 <i>Reading the servo drive status</i> on page 115. These bits must be evaluated together. |
| 1 | 0002 _h | |
| 2 | 0004 _h | |
| 3 | 0008 _h | |
| 5 | 0020 _h | |
| 6 | 0040 _h | |
| 4 | 0010 _h | voltage_enabled |
| 7 | 0080 _h | warning |
| 8 | 0100 _h | drive_is_moving |
| 9 | 0200 _h | remote |
| 10 | 0400 _h | target_reached |
| 11 | 0800 _h | internal_limit_active |
| 12 | 1000 _h | set_point_acknowledge / speed_0 / homing_attained / ip_mode_active |
| 13 | 2000 _h | following_error / homing_error |
| 14 | 4000 _h | manufacturer_statusbit |
| 15 | 8000 _h | trigger_result |

All bits of the statusword are not buffered. They represent the current device status.

In addition to the servo drive status, various events are displayed in the [statusword](#), whereby each bit is assigned a specific event, such as a following error. The individual bits have the following meaning:

| Bit 4 | |
|-----------------|--|
| voltage_enabled | <p>This bit is set when the power stage transistors are switched off.</p> <p>In earlier CANopen implementations, contrary to the specification in DS 402, bit 4 (voltage_enabled) is returned inverted. For compatibility reasons, this has been retained. However, it is possible to select the behaviour according to DS402 via the object compatibility_control (see section 3.2 <i>Compatibility settings</i> on page 43).</p> <p>If bit 7 is set in object 6510h_F0h (compatibility_control), the following applies: This bit is set if the power stage transistors are switched on. No changes need to be made for compatibility with earlier firmware versions.</p> |
| Bit 5 | |
| quick_stop | If the bit is cleared, the drive executes a Quick Stop according to quick_stop_option_code . |
| Bit 7 | |
| warning | The meaning of this bit is configurable: It can be set when any bit in manufacturer_warnings_1 is set. See also section 4.5.5 <i>Object 2001h: manufacturer_warnings</i> on page 123. |
| Bit 8 | manufacturer specific |
| drive_is_moving | This bit is set - independently of the modes_of_operation - if the actual speed (velocity_actual_value) of the drive is outside the associated tolerance window (velocity_threshold). |
| Bit 9 | |
| remote | This bit indicates that the power stage of the servocontroller can be enabled via the CAN network. It is set if the controller enable logic is set accordingly via the enable_logic object. |

| Bit 10 | Depends on <i>modes_of_operation</i> : |
|-----------------------|--|
| target_reached | <p>In Profile Position Mode:</p> <p>This bit is set when the target position is reached and the actual position (position_actual_value) is in the parameterised position window (position_window). It is also set when the drive comes to a standstill after the Halt bit has been set. It is deleted as soon as a new positioning is started.</p> |
| target_reached | <p>In Profile Velocity Mode:</p> <p>The bit is set when the speed (velocity_actual_value) of the drive is within the tolerance window (velocity_window, velocity_window_time).</p> |
| Bit 11 | |
| internal_limit_active | This bit indicates that the I ² t limitation is active. |
| Bit 12 | Depends on <i>modes_of_operation</i> : |
| set_point_acknowledge | <p>In Profile Position Mode:</p> <p>This bit is set when the servocontroller has recognised the set bit new_set_point in the controlword. It is cleared again after the new_set_point bit in the controlword has been set to zero. For more information see section 5.3 <i>Profile Position Mode</i> on page 139.</p> |
| speed_0 | <p>In Profile Velocity Mode:</p> <p>This bit is set when the actual speed (velocity_actual_value) of the drive is within the associated tolerance window (velocity_threshold).</p> |
| homing_attained | <p>In Homing Mode:</p> <p>This bit is set if the homing run was completed without errors.</p> |
| ip_mode_active | <p>In Interpolated Position Mode:</p> <p>This bit indicates that the interpolation is active and the interpolation data sets are being evaluated. It is set if this was requested by the bit enable_ip_mode in the controlword. For more information see section 5.4 <i>Interpolated Position Mode</i> on page 144.</p> |

| Bit 13 | Depends on <i>modes_of_operation</i> : |
|------------------------|---|
| following_error | In Profile Position Mode : This bit is set if the actual position (position_actual_value) differs from the target position (position_demand_value) so much that the difference lies outside the parameterised tolerance window (following_error_window , following_error_time_out). |
| homing_error | In Homing Mode : This bit is set if the homing run is interrupted (Halt bit), both limit switches are activated simultaneously or the distance already travelled during the limit switch search is greater than the specified positioning range (min_position_limit , max_position_limit). |
| Bit 14 | manufacturer specific |
| manufacturer_statusbit | The meaning of this bit is configurable: It can be set when any bit of the manufacturer_statusword_1 is set or reset. See also section 4.5.2 <i>Object 2000h: manufacturer_statuswords</i> on page 120. |
| Bit 15 | manufacturer specific |
| trigger_result | The meaning of this bit is configurable: It is set when a sample event has occurred and the sample mask is set accordingly. See also section 3.15 <i>Position capturing (Sampling)</i> on page 92. |

4.5.2 Object 2000_h: manufacturer_statuswords

The object group `manufacturer_statuswords` displays additional manufacturer-specific states of the servocontroller.


| | | | |
|-----------|---------------------------|----|-----------------|
| Index | 2000 _h | | |
| Name | manufacturer_statuswords | | |
| Type | RECORD | | 01 _h |
| Sub-Index | 01 _h | | |
| Name | manufacturer_statusword_1 | | |
| Info | -- | ro | PDO UINT32 |
| Value | -- | -- | |

| Bit | Value | Name |
|-----|-----------------------|-------------------|
| 0 | 00000001 _h | is_referenced |
| 1 | 00000002 _h | commutation_valid |
| 2 | 00000004 _h | ready_for_enable |
| 3 | 00000008 _h | ipo_in_target |
| ... | | |
| 8 | 00000100 _h | safe_standstill |

| Bit 0 | |
|-------------------|--|
| is_referenced | The bit is set when the servocontroller is referenced. This is the case if either a homing run has been successfully performed or no homing run is necessary due to the connected encoder system (e.g. in the case of an absolute encoder). |
| Bit 1 | |
| commutation_valid | The bit is set if the commutation information is valid. It is especially helpful for encoder systems without commutation information (e.g. linear motors), as the automatic commutation finding can take some time there. If this bit is monitored a timeout of the control can be prevented when enabling the servo drive. |
| Bit 2 | |
| ready_for_enab | <p>The bit is set when all conditions are present to enable the servo drive and only the controller enable itself is missing. The following conditions must be fulfilled:</p> <ul style="list-style-type: none"> • The drive is error-free • The DC link is loaded • The angle encoder evaluation is ready. No processes (e.g. serial transmission) are active that prevent an enable. • No blocking process is active (e.g. automatic motor parameter identification) |

| | |
|-----------------|--|
| Bit 3 | |
| ipo_in_target | The bit is set when the trajectory generator has completed the positioning. In contrast to target_reached, no additional check is made whether the actual position also corresponds to the target position. |
| Bit 8 | |
| safe_standstill | The bit is set when the controller has entered the safe state "Safe Torque Off" (STO). See also the relevant section in the product manual, e.g. section STO (<i>Safe Torque Off</i>) in the BL 4000-C product manual. |

With the help of the objects `manufacturer_status_masks` and `manufacturer_status_invert` one or more bits of the `manufacturer_statuswords` can be mapped into bit 14 (`manufacturer_statusbit`) of the `statusword` (6041_h). All bits of the `manufacturer_statusword_1` can be inverted via the corresponding bit in `manufacturer_status_invert_1`. Thus, bits can also be monitored for the "reset" status. After the inversion the bits are masked, i.e. only if the corresponding bit in `manufacturer_status_mask_1` is set, the bit is further evaluated. If at least one bit is still set after masking, bit 14 of the `statusword` is also set. The following figure illustrates this as an example:



EXAMPLE

Bit 14 of the statusword should be set if the drive is referenced:

| Object | Value | |
|---|------------|---------------|
| <code>manufacturer_status_invert_1</code> | 0x00000000 | Invert no bit |
| <code>manufacturer_status_mask_1</code> | 0x00000001 | Show bit 0 |

Bit 14 of the statusword should be set if the drive has **no** valid commutation position:

| Object | Value | |
|---|------------|--------------|
| <code>manufacturer_status_invert_1</code> | 0x00000002 | Invert bit 1 |
| <code>manufacturer_status_mask_1</code> | 0x00000002 | Show bit 1 |

Bit 14 of the statusword should be set if the drive is not ready for enable OR referenced:

| Object | Value | |
|---|------------|----------------------|
| <code>manufacturer_status_invert_1</code> | 0x00000004 | Invert bit 2 |
| <code>manufacturer_status_mask_1</code> | 0x00000005 | Show bit 0 and bit 2 |

4.5.3 Object 2005_h: manufacturer_status_masks

This object group is used to specify which set bits of the `manufacturer_statuswords` are mapped into the `statusword`.

| | | | | |
|-----------|----------------------------|----|-----|-----------------|
| Index | 2005 _h | | | |
| Name | manufacturer_status_masks | | | |
| Type | RECORD | | | 01 _h |
| Sub-Index | 01 _h | | | |
| Name | manufacturer_status_mask_1 | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | 0 | | |

4.5.4 Object 200A_h: manufacturer_status_invert

This object group determines which bits of the `manufacturer_statuswords` are inverted before masking.

| | | | | |
|-----------|------------------------------|----|-----|-----------------|
| Index | 200A _h | | | |
| Name | manufacturer_status_invert | | | |
| Type | RECORD | | | 01 _h |
| Sub-Index | 01 _h | | | |
| Name | manufacturer_status_invert_1 | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | 0 | | |

4.5.5 Object 2001_h: manufacturer_warnings

The manufacturer-specific object group `manufacturer_warnings` shows further states of the servo drive.

| | | | | |
|-----------|-------------------------|----|-----|-----------------|
| Index | 2001 _h | | | |
| Name | manufacturer_warnings | | | |
| Type | RECORD | | | 01 _h |
| Sub-Index | 01 _h | | | |
| Name | manufacturer_warnings_1 | | | |
| Info | -- | ro | PDO | UINT32 |
| Value | -- | -- | | |

| Bit | Value | Name |
|-----|-----------------------|-------------------|
| 0 | 00000001 _h | l_lim_switch_lock |
| 1 | 00000002 _h | r_lim_switch_lock |
| 2 | 00000004 _h | warning_active |

| | |
|--------------------------------|--|
| Bit 0 | |
| <code>l_lim_switch_lock</code> | This bit indicates that the direction is locked because the left limit switch has been triggered. The setpoint lock is reset when an error acknowledgement is performed (See controlword , fault_reset). |
| Bit 1 | |
| <code>r_lim_switch_lock</code> | This bit indicates that the direction is locked because the right limit switch has been triggered. The setpoint lock is reset when an error acknowledgement is performed (See controlword , fault_reset). |
| Bit 2 | |
| <code>warning_active</code> | This bit indicates that a warning is active in the servo drive, see the corresponding section in the product manual, e.g. section <i>Fault messages</i> in the BL 4000 Product manual. |

With the help of the [manufacturer_warning_masks](#) object, one or more bits of the [manufacturer_warnings](#) can be mapped into bit 7 (warning) of the [statusword](#) (6041_h). Only if the corresponding bit in [manufacturer_warning_mask_1](#) is set, the bit is further evaluated. If at least one bit is still set after masking, bit 7 of the [statusword](#) is also set.

4.5.6 Object 2006_h: [manufacturer_warning_masks](#)

This object group determines which set bits of the [manufacturer_warnings](#) object are mapped into the [statusword](#).

| | | | | |
|-----------|---|----|-----|-----------------|
| Index | 2006 _h | | | |
| Name | manufacturer_warning_masks | | | |
| Type | RECORD | | | 01 _h |
| Sub-Index | 01 _h | | | |
| Name | manufacturer_warning_mask_1 | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | 0 | | |

4.6 Description of further objects

4.6.1 Object 605B_h: shutdown_option_code

The `shutdown_option_code` is used to specify how the servocontroller behaves during state transition 8 (from OPERATION_ENABLE to READY_TO_SWITCH_ON). The object indicates the unchangeable behavior of the servocontroller.

| | | | | |
|-------|----------------------|----|---------------|-------|
| Index | 605B _h | | | |
| Name | shutdown_option_code | | | |
| Info | -- | rw | DD | INT16 |
| Value | 0 | -- | | |

| Value | Name |
|-------|--|
| 0 | Output stage will be switched off, motor can rotate freely |

4.6.2 Object 605C_h: disable_operation_option_code

The `disable_operation_option_code` object is used to specify how the servocontroller behaves during state transition 5 (from OPERATION_ENABLE to SWITCHED_ON). The object indicates the unchangeable behavior of the servocontroller.

| | | | | |
|-------|-------------------------------|----|---------------|-------|
| Index | 605C _h | | | |
| Name | disable_operation_option_code | | | |
| Info | -- | rw | DD | INT16 |
| Value | -1 | -- | | |

| Value | Name |
|-------|---|
| -1 | Decelerate with <code>quickstop_deceleration</code> |

4.6.3 Object 605A_h: quick_stop_option_code

The Parameter `quick_stop_option_code` is used to specify how the servocontroller behaves in the event of a [Quick Stop](#). The object indicates the unchangeable behavior of the servocontroller.

| | | | | |
|-------|------------------------|----|----------------|-------|
| Index | 605A _h | | | |
| Name | quick_stop_option_code | | | |
| Info | -- | rw | PBO | INT16 |
| Value | 2 | -- | | |

| Value | Name |
|-------|---|
| 2 | Decelerate with <code>quickstop_deceleration</code> |

4.6.4 Object 605E_h: fault_reaction_option_code

The `fault_reaction_option_code` object is used to specify how the servo drive behaves in the event of a fault. Since with Metronix servocontrollers the error reaction depends on the respective error, this object cannot be parameterised and always returns 0. To change the error reaction of the individual errors see section 3.18 *Error management* on page 104.

| | | | | |
|-------|----------------------------|----|----------------|-------|
| Index | 605E _h | | | |
| Name | fault_reaction_option_code | | | |
| Info | -- | rw | PBO | INT16 |
| Value | 0 | -- | | |

5 Operating modes

5.1 Setting the operating mode

5.1.1 Overview

The servocontroller can be set to a variety of operating modes. Only a few are specified in detail under CANopen:

- torque-controlled operation (profile torque mode)
- speed-controlled operation (profile velocity mode)
- homing mode
- positioning mode (profile position mode)
- synchronous position mode (CANopen: interpolated position mode, Ethercat: cyclic synchronous position mode)

5.1.2 Description of objects

5.1.2.1 Object 6060_h: modes_of_operation

The [modes_of_operation](#) object is used to set the operating mode of the servocontroller.

| | | | | |
|-------|--------------------|----|-----|------|
| Index | 6060 _h | | | |
| Name | modes_of_operation | | | |
| Info | -- | rw | PDO | INT8 |
| Value | 1, 3, 4, 6, 7, 8 | | -- | |

| Value | Action |
|-------|--|
| 1 | Profile Position Mode (Position control with positioning mode) |
| 3 | Profile Velocity Mode (Speed control with setpoint ramp) |
| 4 | Profile Torque Mode (Torque control with setpoint ramp) |
| 6 | Homing Mode (Reference run) |
| 7 | Interpolated Position Mode |
| 8 | Cyclic Synchronous Position Mode |

INFORMATION Current operating mode

The current operating mode can only be read from the object [modes_of_operation_display](#). Since changing the operating mode can take some time, you must wait until the newly selected mode appears in the object [modes_of_operation_display](#).

5.1.2.2 Object 6061h: modes_of_operation_display

The current operating mode of the servocontroller can be read with object [modes_of_operation_display](#).

| | | | | |
|-------|-------------------------------------|----|-----|------|
| Index | 6061_h | | | |
| Name | modes_of_operation_display | | | |
| Info | -- | ro | PDO | INT8 |
| Value | -14, -13, -11, -1, 1, 3, 4, 6, 7, 8 | | -- | |

If an operating mode is set via object [6060_h](#), in addition to setting the actual operating mode, the setpoint selector is also modified as follows to ensure operation of the servocontroller under CANopen:

| Selector | Profile Velocity Mode | Profile Torque Mode |
|----------|------------------------------------|------------------------------|
| A | Speed setpoint (Fieldbus 1) | Torque setpoint (Fieldbus 1) |
| B | Torque limitation, if applicable | inactive |
| C | Speed setpoint (synchronous speed) | inactive |

In addition, the setpoint ramp will always be switched on. Only if these settings are made in the mentioned way, one of the CANopen operating modes is displayed. If these settings are changed e.g. with the Metronix ServoCommander®, the appropriate "User" mode is displayed to indicate that the selectors have been changed.

| Value | Mode |
|-------|--|
| -1 | Unknown operating mode / operating mode change |
| -11 | User Position Mode |
| -13 | User Velocity Mode |
| -14 | User Torque Mode |
| 1 | Profile Position Mode |
| 3 | Profile Velocity Mode |
| 4 | Torque Profile Mode |
| 6 | Homing Mode |
| 7 | Interpolated Position Mode |
| 8 | Cyclic Synchronous Position Mode |

INFORMATION Setting the operating mode

The operating mode can only be set via object [modes_of_operation](#). Since changing the operating mode can take some time, you have to wait until the newly selected mode appears in object [modes_of_operation_display](#). During this period, "invalid operating mode" (-1) may be displayed briefly.

5.2 Homing Mode

5.2.1 Overview

This chapter describes how the servo drive searches for the initial position (also called reference point or zero point). There are different methods to determine this position, either the limit switches at the end of the positioning range can be used or a reference switch (zero point switch) within the possible positioning range. In order to achieve the greatest possible reproducibility, the zero pulse of the angle encoder used (resolver, incremental encoder, etc.) can be included in some methods.




Figure 10: Homing

The user can determine the speed, acceleration and type of homing. The `home_offset` object can be used to move the zero position of the servo drive to any position. There are two homing speeds. The higher search speed (`speed_during_search_for_switch`) is used to find the limit switch or the reference switch. In order to subsequently be able to determine the position of the relevant switching edge exactly, the crawling speed (`speed_during_search_for_zero`) will be used. The maximum distance searched for switches is calculated from the difference of objects `607Dh01h` and `607Dh02h` (see section 3.7.2.14 *Object 607D_h: software_position_limit* on page 72). If no switch is found within this distance, error 11-6 (Homing: end of search distance reached) is triggered.

INFORMATION Homing behaviour can be parameterised

The following homing behaviour can be modified:

- If the reference run is started via the `controlword`, the servo drive does not necessarily move to the zero position after the reference run. If the servo drive knows all the required values (e.g. because it already knows the position of the zero pulse), no physical movement is carried out.
- The maximum search distance is determined by object `607Dh`.

If bit 6 of the object `6510hF0h` (`compatibility_control`) is set, the settings defined in the Metronix ServoCommander® are used instead (siehe section 3.2 *Compatibility settings* on page 43).

If the drive should not be referenced, but only the position should be set to a certain value, object `2030h` (`set_position_absolute`) can be used. For this see section 3.7.2.13 *Object 2030_h: set_position_absolute* on page 71.

5.2.2 Description of objects

5.2.2.1 Important objects in other sections

| Index | Name | Section | Page |
|-------------------|-------------|----------------|------|
| 6040 _h | controlword | Device Control | 106 |
| 6041 _h | statusword | | |

5.2.2.2 Object 607C_h: home_offset

The [home_offset](#) object specifies the offset of the zero position with respect to the determined reference position. The effect of this object can be customised. See also section 3.2.2.1 *Object 6510_h_F0_h: compatibility_control* on page 43.

| | | | | |
|-------|-------------------|----|-----|-------|
| Index | 607C _h | | | |
| Name | home_offset | | | |
| Info | position_unit | rw | PDO | INT32 |
| Value | -- | | -- | |

5.2.2.3 Object 6098_h: homing_method

A number of different methods are provided for a homing run. The variant required for the application can be selected via the [homing_method](#) object. There are four possible homing signals: the negative and positive limit switches, the reference switch and the (periodic) zero pulse of the angle encoder.

In addition, the servo drive can reference to the negative or positive stop without any additional signal at all. If a method for referencing is set via the object [homing_method](#), the following settings are determined with this:

- The reference source (neg./pos. limit switch, the reference switch, neg. / pos. stop).
- The direction and the sequence of the homing
- The method of evaluation of the zero pulse from the used angle encoder

| | | | | |
|-------|---|----|-----|------|
| Index | 6098 _h | | | |
| Name | homing_method | | | |
| Info | -- | rw | PDO | INT8 |
| Value | -18, -17, -2, -1, 1, 2, 7, 11, 17, 18, 23, 27, 32, 33, 34, 35 | | -- | |

| | Direction | Target | Reference point for zero | DS402 |
|-----|-----------|------------------|--------------------------|-------|
| -18 | positive | Stop | Stop | -18 |
| -17 | negative | Stop | Stop | -17 |
| -2 | positive | Stop | Zero pulse | -2 |
| -1 | negative | Stop | Zero pulse | -1 |
| 1 | negative | Limit switch | Zero pulse | 1 |
| 2 | positive | Limit switch | Zero pulse | 2 |
| 7 | positive | Reference switch | Zero pulse | 7 |
| 11 | negative | Reference switch | Zero pulse | 11 |
| 17 | negative | Limit switch | Limit switch | 17 |
| 18 | positive | Limit switch | Limit switch | 18 |
| 23 | positive | Reference switch | Reference switch | 23 |
| 27 | negative | Reference switch | Reference switch | 27 |
| 32 | negative | Zero pulse | Zero pulse | 33 |
| 33 | positive | Zero pulse | Zero pulse | 34 |
| 34 | | No movement | Current actual position | 35 |

INFORMATION Homing methods not assigned according to DS402

In previous CANopen implementations the homing methods 32, 33, 34 and 35 are not assigned according to DS402. Therefore, it is possible to select the assignment according to DS402 via object [compatibility_control](#) (siehe section 3.2 *Compatibility settings* on page 43). In this case, the method numbers in the column "DS402" must be used.

For compatibility with previous versions, no changes need to be made and the previous numbers can be used.

The [homing_method](#) can only be changed if homing is not active. Otherwise the error message 08 00 00 22h is returned. The sequence of the individual methods is explained in detail in section 5.2.3 *Homing sequences* on page 133.

5.2.2.4 Object 6099_h: homing_speeds

This object determines the speeds used during homing.

| | | | | |
|-----------|--------------------------------|----|-----|-----------------|
| Index | 6099 _h | | | |
| Name | homing_speeds | | | |
| Type | ARRAY | | | 02 _h |
| Sub-Index | 01 _h | | | |
| Name | speed_during_search_for_switch | | | |
| Info | speed_unit | rw | PDO | UINT32 |
| Value | -- | -- | | |

| | | | | |
|-----------|-------------------------------------|----|-----|--------|
| Sub-Index | 02_h | | | |
| Name | speed_during_search_for_zero | | | |
| Info | speed_unit | rw | PDO | UINT32 |
| Value | -- | -- | | |

INFORMATION Setting bit 6 in the object compatibility_control

If bit 6 in object [compatibility_control](#), (siehe section 3.2 *Compatibility settings* on page 43) is set, a movement to zero can be carried out after the homing, for example.

If this bit is set and object [speed_during_search_for_switch](#) is written, the speed for searching the switch as well as the speed for moving to zero are written together.

5.2.2.5 Object 609A_h: homing_acceleration

This object specifies the acceleration used for all acceleration and deceleration processes during the homing run.

| | | | | |
|-------|----------------------------|----|-----|--------|
| Index | 609A_h | | | |
| Name | homing_acceleration | | | |
| Info | acceleration_unit | rw | PDO | UINT32 |
| Value | -- | -- | | |

5.2.2.6 Object 2045_h: homing_timeout

The homing run can be monitored for its maximum execution time. For this purpose, the maximum execution time can be specified with the [homing_timeout](#) object. If this time is exceeded without the homing run being completed, error 11-3 is triggered. If 0 is written to the object, monitoring is deactivated.

| | | | | |
|-------|-------------------------|----|----------------|--------|
| Index | 2045_h | | | |
| Name | homing_timeout | | | |
| Info | ms | rw | PDO | UINT16 |
| Value | 0, 1 ... 65535 | -- | | |

5.2.3 Homing sequences

5.2.3.1 Methods -17 and -18: Stop

If this method is used, the drive moves in the positive direction (-18) or negative direction (-17) until it reaches the stop. Normally, a 50% increase of the i^2t value is used as the criterion for detecting the stop. Alternatively, a comparison torque value at which the stop will be considered as detected can be specified (see section *Tab: Torques* in the respective product manual). The mechanical design of the stop must be such that it cannot be damaged with the parameterised maximum current. The home position refers directly to the stop. Since, in this case, the home position would be located directly at the stop, the parameter **Offset start position** should be used to shift the home position in a suitable manner.




Figure 11: Homing run to the stop




Figure 12: Use of "Offset start position"

5.2.3.2 Methods -1 and -2: stop with index pulse evaluation

These methods correspond to the methods -17 and -18. However, the home position also refers to the first index pulse of the angle encoder in the negative (-2) or positive (-1) direction as seen from the stop.




Figure 13: Homing run to the stop with index pulse evaluation

5.2.3.3 Methods 17 and 18: positive and negative limit switch

If these methods are used, the drive moves in the positive direction (18) or negative direction (17) at search speed until it reaches the limit switch. Then, the drive moves back at crawl speed and tries to find the exact position of the limit switch. The home position refers to the falling edge of the limit switch.




Figure 14: Homing run to the limit switch

5.2.3.4 Methods 1 and 2: positive and negative limit switch with index pulse evaluation

Like in the case of the previous method, the system tries to find the limit switch. However, in this case, the home position refers to the first index pulse of the angle encoder in the negative (1) or positive (2) direction as seen from the limit switch.




Figure 15: Homing run to the limit switch with index pulse evaluation

5.2.3.5 Methods 23 and 27: reference switch

These two methods use a reference switch which is active only over a certain part of the distance. This method is particularly suitable for rotary axis applications in which the reference switch is activated once during every rotation. If this method is used, the drive moves in the positive direction (23) or negative direction (27) at search speed until it reaches the reference switch. Then, the drive moves back at crawl speed and tries to find the exact position of the reference switch. The home position refers to the falling edge of the reference switch. If, at the beginning, the drive moves away from the reference switch, the associated limit switch causes a reversal of the direction of rotation so that the reference switch will be found.




Figure 16: Homing run to the reference switch

5.2.3.6 Methods 7 and 11: reference switch and index pulse evaluation

Like methods 23 and 27, methods 7 and 11 use the reference switch. In addition, however, the home position refers to the first index pulse in the negative or positive direction as seen from the reference switch.




Figure 17: Homing run to the reference switch with index pulse evaluation

5.2.3.7 Methods -23 and -27: homing run (positive/negative) to the reference switch

These methods are similar to the methods 23 and 27. However, in this case, the system tries to locate the end of the range of movement, e.g. the stop or a limit switch, in a first step. It is only then that the system searches for the reference switch. As a result, several switches can be connected to the same input for the reference switch. During the homing run, the "last" switch in the search direction will be used as the reference switch. In the case of method -23, the drive moves in the positive direction first, and in the case of method -27, it moves in the negative direction first. The home position refers to the falling edge of the reference switch.




Figure 18: Reference switch with an initial movement in the positive and negative direction

5.2.3.8 Methods 32 and 33: homing to the index pulse

In the case of method 32 and method 33, the direction of the homing run is negative or positive. The home position refers to the first index pulse of the angle encoder in the search direction.




Figure 19: Index pulse with a negative (32) and positive (33) initial movement

5.2.3.9 Method 34: homing to the current position

In the case of method 34, the home position refers to the current position, i.e. the current position of the drive is set to zero.

5.2.4 Homing control

The reference run is controlled and monitored by the `controlword` / `statusword`. Starting is done by setting bit 4 in the `controlword`.

| Bit 4 | Description |
|-------|----------------------|
| 0 | Homing is not active |
| 0 ► 1 | Start homing |
| 1 | Homing is active |
| 1 ◄ 0 | Interrupt homing |

Successful completion of the homing is indicated by a set bit 12 in the `statusword`. A set bit 13 in the `statusword` indicates that an error occurred during the reference run. The cause of the error can be determined via the `error_register` and `pre_defined_error_field` objects.

| Bit 13 | Bit 12 | Description |
|--------|--------|--|
| 0 | 0 | Reference run is not yet ready |
| 0 | 1 | Reference run carried out successfully |
| 1 | 0 | Reference run not carried out successfully |
| 1 | 1 | Illegal state |

5.3 Profile Position Mode

5.3.1 Overview

The structure of this operating mode can be seen in *Figure 20: Trajectory generator and position controller*:

The `target_position` is transferred to the trajectory generator. This generates a position setpoint (`position_demand_value`) for the position controller, which is described in the Position Controller section (see section 3.7 *Position Controller* on page 65). These two function blocks can be set independently of each other.




Figure 20: Trajectory generator and position controller

5.3.2 Functional description

There are two ways to transfer a target position to the servo drive:

› Single driving task

When the servo drive has reached a target position, it signals this to the host with the `target_reached` bit (bit 10 in the `statusword` object). In this operating mode, the servo drive stops when it has reached the target.

› Sequence of driving tasks

After the servo drive has reached a target, it immediately starts moving to the next target. This transition can be carried out smoothly without the servo drive coming to a standstill in between.

These two methods are controlled by the `new_set_point` and `change_set_immediatly` bits in the `controlword` object and `set_point_acknowledge` in the `statusword` object. These bits are in a question-answer relationship to each other. This makes it possible to prepare one motion task while another is still running.




Figure 21: Driving task transfer from a host

The figure above shows how the host and the servo drive communicate with each other via the CAN bus:

First, the positioning data (target position, profile velocity, end velocity and the acceleration) are transmitted to the servo drive. When the positioning data set is completely written (1), the host can start the positioning by setting the bit `new_set_point` in the `controlword` to "1" (2). After the servo drive has recognised the new data and accepted it into its buffer, it reports this to the host by setting the bit `set_point_acknowledge` in the `statusword` (3).

The host can then start writing a new positioning data set into the servo drive (4) and clear the `new_set_point` bit again (5). Only when the servo drive can accept a new motion task (6), it signals this by a "0" in the `set_point_acknowledge` bit. Before that, no new positioning may be started by the host (7).

On the left side of the following figure, a new positioning is started only after the previous one has been completed. The host evaluates the `target_reached` bit in the `statusword` object for this purpose.




Figure 22: Single driving task (left) and sequence of driving tasks (right)

On the right side, a new positioning is already started while the previous one is still being processed. The host transfers the subsequent target to the servo drive as soon as it signals that it has read the buffer and started the associated positioning by clearing the `set_point_acknowledge` bit. In this way, the positioning operations are linked together seamlessly. To prevent the servo drive from briefly decelerating to zero each time between the individual positionings, the object `end_velocity` should be written with the same value as the object `profile_velocity` for this operating mode.

If the bit `change_set_immediately` is set to "1" in the `controlword` in addition to the bit `new_set_point`, the host thereby instructs the servo drive to start the new motion task immediately. A motion task that is already being processed is canceled in this case.

5.3.3 Description of objects

5.3.3.1 Important objects in other sections

| Index | Name | Section | Page |
|-------------------|-------------------------|-------------------------|------|
| 6040 _h | controlword | 4 <i>Device Control</i> | 106 |
| 6041 _h | statusword | | |
| 605A _h | quick_stop_option_code | | |
| 607E _h | polarity | 3.3 <i>Factor Group</i> | 45 |
| 6093 _h | position_factor | | |
| 6094 _h | velocity_encoder_factor | | |
| 6097 _h | acceleration_factor | | |

5.3.3.2 Object 607A_h: target_position

The object [target_position](#) determines to which position the servo drive should move. The current setting of the speed, acceleration, deceleration and the type of motion profile ([motion_profile_type](#)) must be taken into account. The target position ([target_position](#)) is interpreted either as an absolute or relative value ([controlword](#), Bit 6).

| | | | | |
|-------|-------------------------|----|-----|-------|
| Index | 607A_h | | | |
| Name | target_position | | | |
| Info | position_unit | rw | PDO | INT32 |
| Value | -- | | -- | |

5.3.3.3 Object 6081_h: profile_velocity

The [profile_velocity](#) object specifies the velocity that is normally reached during a positioning at the end of the acceleration ramp. The [profile_velocity](#) object is specified in speed_unit.

| | | | | |
|-------|-------------------------|----|-----|--------|
| Index | 6081_h | | | |
| Name | profile_velocity | | | |
| Info | speed_unit | rw | PDO | UINT32 |
| Value | -- | | -- | |

5.3.3.4 Object 6082_h: end_velocity

The **end_velocity** object defines the velocity that the drive must have when it reaches the **target_position**. Normally this object is to be set to zero so that the servo drive stops when it reaches the target position. For gapless positioning, a velocity other than zero can be specified. The **end_velocity** object is specified in the same unit as the **profile_velocity** object.

| | | | | |
|-------|-------------------------|----|-----|--------|
| Index | 6082_h | | | |
| Name | end_velocity | | | |
| Info | speed_unit | rw | PDO | UINT32 |
| Value | -- | -- | | |

5.3.3.5 Object 6083_h: profile_acceleration

The **profile_acceleration** object specifies the acceleration used to accelerate to the setpoint. It is specified in user-defined unit (acceleration_unit).

| | | | | |
|-------|-----------------------------|----|-----|--------|
| Index | 6083_h | | | |
| Name | profile_acceleration | | | |
| Info | acceleration_unit | rw | PDO | UINT32 |
| Value | -- | -- | | |

5.3.3.6 Object 6084_h: profile_deceleration

The **profile_deceleration** object specifies the acceleration with which braking is performed. It is specified in user-defined unit (acceleration_unit).

| | | | | |
|-------|-----------------------------|----|-----|--------|
| Index | 6084_h | | | |
| Name | profile_deceleration | | | |
| Info | acceleration_unit | rw | PDO | UINT32 |
| Value | -- | -- | | |

5.3.3.7 Object 6085_h: quick_stop_deceleration

The **quick_stop_deceleration** object specifies the deceleration with which the motor stops when a quick stop is executed (see section 4.2.2 *State diagram: State transitions* on page 110). The **quick_stop_deceleration** object is specified in the same unit as the **profile_deceleration** object.

| | | | | |
|-------|--------------------------------|----|-----|--------|
| Index | 6085_h | | | |
| Name | quick_stop_deceleration | | | |
| Info | acceleration_unit | rw | PDO | UINT32 |
| Value | -- | -- | | |

5.3.3.8 Object 6086_h: motion_profile_type

The `motion_profile_type` object is used to select the type of positioning profile.

| | | | | |
|-------|---------------------|----|-----|-------|
| Index | 6086 _h | | | |
| Name | motion_profile_type | | | |
| Info | -- | rw | PDO | INT16 |
| Value | 0, 2 | -- | | |

| Value | Profile |
|-------|------------------|
| 0 | Linear profile |
| 2 | Jerkfree profile |

5.4 Interpolated Position Mode

5.4.1 Overview

In Interpolated Position Mode (IP), the servo drive follows cyclical position setpoints, e.g. in a multi-axis application of the servo drive. For this purpose, synchronization telegrams (SYNC) and position setpoints are given by a superordinate control in a fixed time grid (synchronization interval, t_p). Since the interval is usually greater than one position control cycle (t_x), the servo drive interpolates the data values between two specified position values, as outlined in the following graphic.




Figure 23: Linear interpolation between two data values

In the following, the objects required for the Interpolated Position Mode are described first. In a subsequent functional description, the activation and the sequence of the parameterization are dealt with comprehensively.

5.4.2 Functional description

Before the servo drive can be switched to [Interpolated Position Mode](#), various settings must be made: These include the setting of the interpolation interval ([interpolation_time_period](#)), i.e. the time between two SYNC telegrams, the interpolation type ([interpolation_submode_select](#)) and the type of synchronization ([interpolation_sync_definition](#)). In addition, access to the position buffer must be enabled via the object [buffer_clear](#). To change the interpolation interval (cycle time), the parameter set must be saved once and the servo drive restarted. Whether the correct interval is set can be read out via the object [synchronous_window_length](#) (1006_h). If the correct interval is already set, the first four steps in the following example can be omitted.

EXAMPLE

The example shows which steps are necessary to prepare the servo drive for interpolation operation:

| Task | Action |
|-----------------------------|---|
| Set time unit (1/10 ms) | 60C2 _h 02 _h (interpolation_time_index) = -4 |
| Set time interval (2 ms) | 60C2 _h 01 _h (interpolation_time_units) = 20 |
| Save parameters | 1010 _h 01 _h (save_all_parameters) = 65766173 _h |
| Execute reset | see 6.6 <i>Network Management (NMT service)</i> |
| Wait for reboot | see 6.7 <i>Startup</i> |
| Set type of interpolation | 60C0 _h (interpolation_submode_select) = -2 |
| Release buffer | 60C4 _h 06 _h (buffer_clear) = 1 |
| Start sending SYNC messages | see 6.5 <i>SYNC message</i> |

The further steps are described in the following sections.

The **Interpolated Position Mode** is activated via the object **modes_of_operation** (6060_h). From this point on, the servo drive attempts to synchronise itself to the external time grid, which is specified by the SYNC telegrams. If the servo drive was able to synchronise successfully, it reports the **Interpolated Position Mode** in the object **modes_of_operation_display** (6061_h). During synchronization, the servo drive returns "Invalid operation mode". If the SYNC telegrams are not sent in the correct interval after the synchronization has been completed, the servo drive reports "Invalid operating mode" again.

If the change of the operating mode is completed, the transmission of position data to the drive can start. For this purpose, the superordinate control first reads the current actual position from the servo drive and writes it cyclically as the new setpoint (**interpolation_data_record**) to the servo drive. The handshake bits of the **controlword** and the **statusword** are used to activate the acceptance of the data by the servo drive. By setting the bit **enable_ip_mode** in the **controlword** the host indicates that the evaluation of the position data is to be started. The data sets are not evaluated until the servo drive acknowledges this via the **ip_mode_active** status bit in the **statusword**. In detail therefore the following sequence results:




Figure 24: Start of synchronization and data enabling

EXAMPLE

The example shows which steps are necessary to start the interpolation:

| Taks | Action |
|---|---|
| Send SYNC messages | see 6.5 |
| Request operating mode | 6060 _h (modes_of_operation) = 7 |
| Wait until operating mode is accepted | 6061 _h (modes_of_operation_display) = 7 |
| Read current actual position | 6064 _h (position_actual_value) |
| Set read actual position as setpoint | 60C1 _h _01 _h (ip_data_position) |
| Enable interpolation | 6040 _h (controlword), set enable_ip_mode |
| Wait for acknowledgement by servo drive | 6041 _h (statusword), query ip_mode_active |
| Move interpolated | |

After completion of the synchronous movement, further evaluation of position values can be prevented by clearing the enable_ip_mode bit. If necessary, you can then switch to another operating mode.

If a running interpolation (ip_mode_active set) is interrupted by the occurrence of a servo drive error, the drive initially behaves as specified for the respective error (e.g. disabling the servo drive and change to SWICTH_ON_DISABLED state). Interpolation can then only be continued by resynchronization, since the servo drive must be returned to the OPERATION_ENABLE state, which clears the ip_mode_active bit.

5.4.3 Description of objects

5.4.3.1 Important objects in other sections

| Index | Name | Section | Page |
|-------------------|-------------------------|-------------------------|------|
| 6040 _h | controlword | 4 <i>Device Control</i> | 106 |
| 6041 _h | statusword | | |
| 6093 _h | position_factor | 3.3 <i>Factor Group</i> | 45 |
| 6094 _h | velocity_encoder_factor | | |
| 6097 _h | acceleration_factor | | |

5.4.3.2 Object 60C0_h: interpolation_submode_select

The type of interpolation is defined via the [interpolation_submode_select](#) object. Currently, only the manufacturer-specific variant "Linear interpolation without buffer" is available.

| | | | | |
|-------|------------------------------|----|-----|-------|
| Index | 60C0 _h | | | |
| Name | interpolation_submode_select | | | |
| Info | -- | rw | PDO | INT16 |
| Value | -2 | -- | | |

| Value | Type of interpolation |
|-------|-------------------------------------|
| -2 | Linear interpolation without buffer |

5.4.3.3 Object 60C1_h: interpolation_data_record

The [interpolation_data_record](#) object represents the actual data set. It consists of an entry for the position value ([ip_data_position](#)) and a control word ([ip_data_controlword](#)), which specifies whether the position value is to be interpreted absolutely or relatively. The control word can be provided optionally. If it is not provided, the position value is interpreted as absolute. If the control word is also to be specified, subindex 2 ([ip_data_controlword](#)) must be written first and then subindex 1 ([ip_data_position](#)) for reasons of data consistency, since internally the data transfer is triggered with write access to [ip_data_position](#).

| | | | | |
|-----------|---------------------------|----|-----|-----------------|
| Index | 60C1 _h | | | |
| Name | interpolation_data_record | | | |
| Type | RECORD | | | 02 _h |
| Sub-Index | 01 _h | | | |
| Name | ip_data_position | | | |
| Info | position_unit | rw | PDO | INT32 |
| Value | -- | -- | | |
| Sub-Index | 02 _h | | | |
| Name | ip_data_controlword | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 0, 1 | 0 | | |

| Value | ip_data_position is |
|-------|---------------------|
| 0 | Absolute |
| 1 | Relative |

INFORMATION Internal data transfer

The internal data transfer takes place with write access to sub-index 1. If sub-index 2 is also to be used, it must be written before sub-index 1.

5.4.3.4 Object 60C2_h: interpolation_time_period

The synchronisation interval can be set via the [interpolation_time_period](#) object. The unit (ms or 1/10 ms) of the interval is defined via [ip_time_unit](#) and then set via [ip_time_index](#). In Interpolated Position Mode the entire controller cascade (current, speed and position controller) is synchronised to the external clock. The change of the synchronisation interval therefore only becomes effective after a reset. If the interpolation interval is to be changed via the CAN bus, the parameter set must be saved (see section 3.1 *Loading and saving parameter sets* on page 40) and a reset must be executed (see section 6.6 *Network Management (NMT service)* on page 182) so that the new synchronisation interval takes effect. The synchronisation interval must be met exactly.

| | | | | | |
|-----------|---|----|-----|-------|-----------------|
| Index | 60C2 _h | | | | |
| Name | interpolation_time_period | | | | |
| Type | RECORD | | | | 02 _h |
| Sub-Index | 01 _h | | | | |
| Name | ip_time_units | | | | |
| Info | according to ip_time_index | rw | PDO | UINT8 | |
| Value | ip_time_index = -3: 1, 2,..., 10 ip_time_index = -4: 10, 20,..., 100 | -- | | | |
| Sub-Index | 02 _h | | | | |
| Name | ip_time_index | | | | |
| Info | -- | rw | PDO | INT8 | |
| Value | -3, -4 | -- | | | |
| Value | ip_time_index is given in | | | | |
| -3 | 10 ⁻³ seconds (ms) | | | | |
| -4 | 10 ⁻⁴ seconds (0.1 ms) | | | | |

INFORMATION Changing the synchronisation interval

Changing the interpolation cycle time only takes effect after a reset. If the interpolation cycle time is to be changed via the CAN bus, the parameter set must be saved and a reset must be executed.

5.4.3.5 Object 60C3_h: interpolation_sync_definition

Via the object **interpolation_sync_definition** the type (**synchronize_on_group**) and the number (**ip_sync_every_n_event**) of synchronisation telegrams per synchronisation interval is specified. For Metronix servo drives only the standard SYNC telegram and 1 SYNC per interval can be set.

| | | | | | |
|-----------|-------------------------------|----|-----|-------|-----------------|
| Index | 60C3 _h | | | | |
| Name | interpolation_sync_definition | | | | |
| Type | ARRAY | | | | 02 _h |
| Sub-Index | 01 _h | | | | |
| Name | synchronize_on_group | | | | |
| Info | -- | rw | PDO | UINT8 | |
| Value | 0 | 0 | | | |
| Value | Description | | | | |
| 0 | Use standard SYNC telegram | | | | |

| | | | | |
|-----------|------------------------------|----|-----|-------|
| Sub-Index | 02_h | | | |
| Name | ip_sync_every_n_event | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 1 | 1 | | |

5.4.3.6 Object 60C4_h: interpolation_data_configuration

The object record [interpolation_data_configuration](#) is intended for the configuration of an intermediate buffer. With the only available interpolation type "Linear interpolation without buffer" most entries have no meaning. However, even with this type of interpolation, access to object 60C1_h must be enabled via object [buffer_clear](#)!

| | | | | |
|--------------|---|----|-----|-----------------|
| Index | 60C4_h | | | |
| Name | interpolation_data_configuration | | | |
| Type | RECORD | | | 06 _h |
| Sub-Index | 01_h | | | |
| Name | max_buffer_size | | | |
| Info | -- | ro | PDO | UINT32 |
| Value | 0 | 0 | | |
| Sub-Index | 02_h | | | |
| Name | actual_size | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | 0 | 0 | | |
| Sub-Index | 03_h | | | |
| Name | buffer_organisation | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 0 | 0 | | |
| Value | Description | | | |
| 0 | FIFO | | | |

| | | | | |
|-----------|----------------------------|----|-----|--------|
| Sub-Index | 04_h | | | |
| Name | buffer_position | | | |
| Info | -- | rw | PDO | UINT16 |
| Value | 0 | 0 | | |
| Sub-Index | 05_h | | | |
| Name | size_of_data_record | | | |
| Info | -- | wo | PDO | UINT8 |
| Value | 2 | 2 | | |

| | | | | |
|-----------|-----------------------|----|-----|-------|
| Sub-Index | 06_h | | | |
| Name | buffer_clear | | | |
| Info | -- | wo | PDO | UINT8 |
| Value | 0, 1 | 0 | | |

| Value | Description |
|-------|---|
| 0 | Delete Buffer / Access to 60C1 _h not allowed |
| 1 | Access to 60C1 _h released |

5.4.3.7 Object 1006_h: communication_cycle_period

The set interpolation interval (=bus cycle time) can be read out via object 1006_h (**communication_cycle_period**). It is equal to the time t_P described in the section *Control circuit cycle times* in the Product manual BL 4000.

| | | | | |
|-------|-----------------------------------|-----------------------|----------------|--------|
| Index | 1006_h | | | |
| Name | communication_cycle_period | | | |
| Info | μs | rw | PDO | UINT32 |
| Value | -- | 00000000 _h | | |

5.5 Cyclic Synchronous Position Mode

5.5.1 Overview

Just as in [Interpolated Position Mode \(IP\)](#), in [Cyclic Synchronous Position Mode \(CSP\)](#) the servo drive follows cyclic position setpoints in a multi-axis application of the servo drive.

The main differences are:

- The setpoint is specified via the [target_position \(607A_h\)](#)
- The setpoints are evaluated directly after changing to [Cyclic Synchronous Position Mode](#). It is not necessary to set the bit `enable_ip_mode` in the controlword and also the object [buffer_clear \(60C4_h_06_h\)](#) must not be written.

5.5.2 Description of objects

5.5.2.1 Important objects in other sections

| Index | Name | Section | Page |
|-------------------|---------------------------|--|------|
| 607A _h | target_position | 5.3.3.2 <i>Object 607Ah: target_position</i> | 141 |
| 60C2 _h | interpolation_time_period | 5.4 <i>Interpolated Position Mode</i> | 106 |
| 6040 _h | controlword | 4 <i>Device Control</i> | 106 |
| 6041 _h | statusword | | |
| 6093 _h | position_factor | 3.3 <i>Factor Group</i> | 45 |
| 6094 _h | velocity_encoder_factor | | |
| 6097 _h | acceleration_factor | | |

The [Cyclic Synchronous Position Mode](#) does not define its own objects.

5.6 Profile Velocity Mode


5.6.1 Overview

The speed-controlled mode (Profile Velocity Mode) includes the following sub-functions:

- Setpoint generation by the ramp generator
- Speed control with suitable input and output signals
- Limitation of the torque setpoint ([torque_demand_value](#))
- Monitoring of the actual velocity ([velocity_actual_value](#)) with the window function/threshold

The meaning of the following parameters is described in section 5.3

Profile Position Mode on page 139: [profile_acceleration](#), [profile_deceleration](#), [quick_stop_deceleration](#).






Figure 25: Structure of speed-controlled operation (Profile Velocity Mode)

5.6.2 Description of objects

5.6.2.1 Important objects in other sections

| Index | Name | Sections | Page |
|-------------------|-------------------------|----------------------------------|------|
| 6040 _h | controlword | 4 <i>Device Control</i> | 106 |
| 6041 _h | statusword | | |
| 6064 _h | position_actual_value | 3.7 <i>Position Controller</i> | 65 |
| 6071 _h | target_torque | 5.7 <i>Profile Torque Mode</i> | 161 |
| 6072 _h | max_torque_value | | |
| 6083 _h | profile_acceleration | 5.3 <i>Profile Position Mode</i> | 139 |
| 6084 _h | profile_deceleration | | |
| 6085 _h | quick_stop_deceleration | | |
| 6094 _h | velocity_encoder_factor | | |

5.6.2.2 Object 6069_h: velocity_sensor_actual_value

With the [object velocity_sensor_actual_value](#) the value of a possible velocity encoder can be read out in internal units. With Metronix servo drives no separate speed sensor can be connected. Therefore, object 606C_h should always be used to determine the actual speed value.

| | | | | |
|-------|------------------------------|----|-----|-------|
| Index | 6069 _h | | | |
| Name | velocity_sensor_actual_value | | | |
| Info | rev / 4096 min | ro | PDO | INT32 |
| Value | -- | | -- | |

5.6.2.3 Object 606A_h: sensor_selection_code

The speed sensor can be selected with this object. Currently, no separate speed sensor is provided. Therefore, only the standard angle encoder can be selected.

| | | | | |
|-------|-----------------------|----|-----|-------|
| Index | 606A _h | | | |
| Name | sensor_selection_code | | | |
| Info | -- | rw | PDO | INT16 |
| Value | 0 | | 0 | |

5.6.2.4 Object 606B_h: velocity_demand_value

This object can be used to read out the current speed setpoint of the speed controller, which is generated by the ramp generator or the trajectory generator. If the position controller is activated, its correction speed is also added.

| | | | | |
|-------|-----------------------|----|-----|-------|
| Index | 606B _h | | | |
| Name | velocity_demand_value | | | |
| Info | speed_unit | ro | PDO | INT32 |
| Value | -- | | -- | |

5.6.2.5 Object 202E_h: velocity_demand_sync_value

The setpoint speed of the synchronisation encoder can be read out via this object. This is defined by object 2022_h [synchronization_encoder_select](#) (section 3.11 *Setpoint / actual value selection* on page 81).

| | | | | |
|-------|----------------------------|----|-----|-------|
| Index | 202E _h | | | |
| Name | velocity_demand_sync_value | | | |
| Info | speed_unit | ro | PDO | INT32 |
| Value | -- | | -- | |

5.6.2.6 Object 606C_h: velocity_actual_value

The actual speed value can be read out via this object.

| | | | | |
|-------|-----------------------|----|-----|-------|
| Index | 606C _h | | | |
| Name | velocity_actual_value | | | |
| Info | speed_unit | ro | PDO | INT32 |
| Value | -- | -- | | |

5.6.2.7 Object 2074_h: velocity_actual_value_filtered

The **velocity_actual_value_filtered** object can be used to read out a filtered **actual velocity value** that should only be used for display purposes. In contrast to **velocity_actual_value**, **velocity_actual_value_filtered** is not used in the velocity control loop, but is used to protect the servo drive against overspeed. The filter time constant can be set via Object 2073_h (**velocity_display_filter_time**). See section 3.6.2.2 *Object 2073h: velocity_display_filter_time* on page 64

| | | | | |
|-------|--------------------------------|----|-----|-------|
| Index | 2074 _h | | | |
| Name | velocity_actual_value_filtered | | | |
| Info | speed_unit | ro | PDO | INT32 |
| Value | -- | | | |




Figure 26: Determining velocity_actual_value and velocity_actual_value_filtered

5.6.2.8 Object 606D_h: velocity_window

The [velocity_window_time](#) and [velocity_window](#) objects are used to set the window comparator for comparing the actual speed value with the [target velocity](#) (object 60FF_h). To set bit 10 target_reached in the [statusword](#) object, the speed must be within [velocity_window](#) for the time specified in [velocity_window_time](#).

| | | | | |
|-------|-------------------|----|-----|--------|
| Index | 606D _h | | | |
| Name | velocity_window | | | |
| Info | speed_unit | rw | PDO | UINT16 |
| Value | -- | | -- | |

5.6.2.9 Object 606E_h: velocity_window_time

The [velocity_window_time](#) and [velocity_window](#) objects are used to set the window comparator for comparing the actual speed value with the [target velocity](#) (object 60FF_h). To set bit 10 target_reached in the [statusword](#) object, the speed must be within [velocity_window](#) for the time specified in [velocity_window_time](#).

| | | | | |
|-------|----------------------|----|-----|--------|
| Index | 606E _h | | | |
| Name | velocity_window_time | | | |
| Info | ms | rw | PDO | UINT16 |
| Value | 0...4999 | | 0 | |

5.6.2.10 Object 606F_h: velocity_threshold

The [velocity_threshold](#) and [velocity_threshold_time](#) objects specify the actual speed value at which the drive is considered to be standing still. If the drive exceeds the speed specified under [velocity_threshold](#) for [velocity_threshold_time](#), bit 12 (velocity = 0) is deleted in the [statusword](#).

| | | | | |
|-------|--------------------|----|-----|--------|
| Index | 606F _h | | | |
| Name | velocity_threshold | | | |
| Info | speed_unit | rw | PDO | UINT16 |
| Value | -- | | -- | |

5.6.2.11 Object 6070_h: velocity_threshold_time

The [velocity_threshold](#) and [velocity_threshold_time](#) objects specify the actual speed value at which the drive is considered to be standing still. If the drive exceeds the speed specified under [velocity_threshold](#) for [velocity_threshold_time](#), bit 12 (velocity = 0) is deleted in the [statusword](#).

| | | | | |
|-------|-------------------------|----|-----|--------|
| Index | 6070 _h | | | |
| Name | velocity_threshold_time | | | |
| Info | ms | rw | PDO | UINT16 |
| Value | 0...4999 | 0 | | |

5.6.2.12 Object 6080_h: max_motor_speed

The [max_motor_speed](#) object gives the highest permitted speed for the motor in min⁻¹. The object is used to protect the motor and can be taken from the motor data sheet. The speed setpoint is limited to this value.

| | | | | |
|-------|-------------------|----|-----|--------|
| Index | 6080 _h | | | |
| Name | max_motor_speed | | | |
| Info | min ⁻¹ | rw | PDO | UINT16 |
| Value | 0...32767 | -- | | |

5.6.2.13 Object 60FF_h: target_velocity

The [target_velocity](#) object is the setpoint for the ramp generator.

| | | | | |
|-------|-------------------|----|-----|-------|
| Index | 60FF _h | | | |
| Name | target_velocity | | | |
| Info | speed_unit | rw | PDO | INT32 |
| Value | -- | -- | | |

5.6.2.14 Speed ramps

If Profile Velocity Mode is selected as `modes_of_operation`, the setpoint ramp is also activated. Thus it is possible to limit a step-shaped setpoint change to a certain velocity change per time via the `profile_acceleration` and `profile_deceleration` objects. The servo drive not only offers the possibility to use different values for deceleration and acceleration, but also to set different accelerations for positive and negative speed. The following figure illustrates this behavior:




Figure 27: Speed ramps

To be able to parameterise these 4 accelerations individually, the `velocity_ramps` object group is available. It should be noted that the `profile_acceleration` and `profile_deceleration` objects change the same internal accelerations as the `velocity_ramps`. If the `profile_acceleration` is written, `velocity_acceleration_pos` and `velocity_acceleration_neg` are changed together, if the `profile_deceleration` is written, `velocity_deceleration_pos` and `velocity_deceleration_neg` are changed together.

If a 1 is written to the `velocity_ramps_enable` object, the setpoints are passed through the ramp generator.

| | | | | |
|-----------|----------------------------------|----|----------------|-----------------|
| Index | 2090_h | | | |
| Name | velocity_ramps | | | |
| Type | RECORD | | | 05 _h |
| Sub-Index | 01_h | | | |
| Name | velocity_rampe_enable | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 0, 1 | -- | | |
| Sub-Index | 02_h | | | |
| Name | velocity_acceleration_pos | | | |
| Info | acceleration_unit | rw | PDO | INT32 |
| Value | -- | -- | | |
| Sub-Index | 03_h | | | |
| Name | velocity_deceleration_pos | | | |
| Info | acceleration_unit | rw | PDO | INT32 |
| Value | -- | -- | | |

| | | | | |
|-----------|---------------------------|----|----------------|-------|
| Sub-Index | 04 _h | | | |
| Name | velocity_acceleration_neg | | | |
| Info | acceleration_unit | rw | PDO | INT32 |
| Value | -- | -- | | |

| | | | | |
|-----------|---------------------------|----|----------------|-------|
| Sub-Index | 05 _h | | | |
| Name | velocity_deceleration_neg | | | |
| Info | acceleration_unit | rw | PDO | INT32 |
| Value | -- | -- | | |

5.7 Profile Torque Mode

5.7.1 Overview

This chapter describes the torque controlled operation. This operating mode allows the servo drive to use an external torque setpoint (**target_torque**), which can be smoothed by the integrated ramp generator. Thus it is possible to use the servo drive in applications where both the position controller and the speed controller are shifted to a superordinate control.




Figure 28: Structure of the torque-controlled operation mode

The **torqueSlope** and **torqueProfileType** parameters must be specified for the ramp generator. If bit 8 **halt** is set in the **controlword**, the ramp generator reduces the torque to zero. Accordingly, it increases it again to the **target_torque**, if bit 8 is deleted again. In both cases the ramp generator considers the **torqueSlope** and the **torqueProfileType**. All definitions within this chapter refer to rotary motors. If linear motors are used, all "torque" objects must refer to a "force" instead. For simplicity, the objects are not duplicated and their names should not be changed. The operating modes **Profile Position Mode** and **Profile Velocity Mode** require the torque controller for their function. Therefore, it is always necessary to parameterise it.

5.7.2 Description of objects

5.7.2.1 Important objects from other sections

| Index | Name | Section | Page |
|-------------------|-------------------|--|------|
| 6040 _h | controlword | 4 <i>Device Control</i> | 95 |
| 60F9 _h | motor_parameters | 3.5 <i>Current controller and motor adaption</i> | 56 |
| 6075 _h | motorRatedCurrent | | |
| 6073 _h | maxCurrent | | |

5.7.2.2 Object 6071_h: target_torque

This parameter is the input value for the torque controller in torque-controlled mode (section 5.7 *Profile Torque Mode* on page 161). It is specified in thousandths of the nominal torque (object 6076_h).

| | | | | | |
|-------|-------------------------------|----|-----|-------|--|
| Index | 6071 _h | | | | |
| Name | target_torque | | | | |
| Info | ‰ (1000 = motor Rated torque) | rw | PDO | INT16 | |
| Value | -- | | -- | | |

5.7.2.3 Object 6072_h: max_torque

This value represents the maximum permissible torque of the motor. It is specified in thousandths of the nominal torque (object 6076_h). If, for example, a twofold overload of the motor is permissible for a short time, the value 2000 must be entered here.

INFORMATION Object 6072_h and Object 6073_h are dependent on each other

Object 6072_h (max_torque) and object 6073_h (maxCurrent) are dependent on each other and may only be written if object 6075_h (motorRatedCurrent) has been written with a valid value beforehand.

| | | | | | |
|-------|-------------------------------|----|-----|--------|--|
| Index | 6072 _h | | | | |
| Name | max_torque | | | | |
| Info | ‰ (1000 = motor Rated torque) | rw | PDO | UINT16 | |
| Value | 1000...65535 | | -- | | |

5.7.2.4 Object 6074_h: torque_demand_value

This object can be used to read out the current torque setpoint in thousandths of the nominal torque (6076_h). The internal limitations of the servo drive (current limits and I²t-monitoring) are taken into account here.

| | | | | |
|-------|-------------------------------|----|-----|-------|
| Index | 6074_h | | | |
| Name | torque_demand_value | | | |
| Info | ‰ (1000 = motor Rated torque) | ro | PDO | INT16 |
| Value | -- | | -- | |

5.7.2.5 Object 6076_h: motor Rated torque

This object indicates the nominal torque of the motor. This can be taken from the type plate of the motor. It must be entered in the unit 0.001 Nm.

| | | | | |
|-------|---------------------------|----|-----|--------|
| Index | 6076_h | | | |
| Name | motor Rated torque | | | |
| Info | 0.001 Nm | rw | PDO | UINT32 |
| Value | -- | | -- | |

5.7.2.6 Object 6077_h: torque_actual_value

This object can be used to read out the actual torque value of the motor in thousandths of the nominal torque (object 6076_h).

| | | | | |
|-------|-------------------------------|----|-----|-------|
| Index | 6077_h | | | |
| Name | torque_actual_value | | | |
| Info | ‰ (1000 = motor Rated torque) | ro | PDO | INT16 |
| Value | -- | | -- | |

5.7.2.7 Object 6078_h: current_actual_value

This object can be used to read out the actual current value of the motor in thousandths of the rated current (object 6075_h).

| | | | | |
|-------|--------------------------------|----|-----|-------|
| Index | 6078_h | | | |
| Name | current_actual_value | | | |
| Info | ‰ (1000 = motor Rated current) | ro | PDO | INT16 |
| Value | -- | | -- | |

5.7.2.8 Object 6079_h: dc_link_circuit_voltage

The DC link voltage of the servo drive can be read out via this object. The voltage is specified in the unit millivolts.

| | | | | |
|-------|-------------------------|----|-----|--------|
| Index | 6079 _h | | | |
| Name | dc_link_circuit_voltage | | | |
| Info | mV | ro | PDO | UINT32 |
| Value | -- | | -- | |

5.7.2.9 Object 6087_h: torque_slope

This parameter describes the rate of change of the setpoint ramp. This is to be specified in thousandths of the nominal torque per second. For example, the torque setpoint [target_torque](#) is increased from 0 Nm to the value [motorRatedTorque](#). If the output value of the torque ramp should reach this value in one second, then the value 1000 must be written into this object.

| | | | | |
|-------|---------------------------|----|-----|--------|
| Index | 6087 _h | | | |
| Name | torque_slope | | | |
| Info | motorRatedTorque / 1000 s | rw | PDO | UINT32 |
| Value | -- | | -- | |

5.7.2.10 Object 6088_h: torque_profile_type

The [torque_profile_type](#) object is used to specify the waveform with which a setpoint step is executed. At present, only the linear ramp is implemented in this servo drive, so that this object can only be written with the value 0.

| | | | | |
|-------|---------------------|----|-----|-------|
| Index | 6088 _h | | | |
| Name | torque_profile_type | | | |
| Info | -- | rw | PDO | INT16 |
| Value | 0 | | 0 | |

| Value | Description |
|-------|-------------|
| 0 | Linear ramp |

6 Detailed description of the CANopen protocol


6.1 Introduction

CANopen provides a simple and standardised way to access the parameters of the servo drive (e.g. the maximum motor current). For this purpose, each parameter (CAN object) is assigned a unique number (index and subindex). The totality of all parameters is called the object dictionary. Two main methods are available for accessing the CAN objects via the CAN bus: A confirmed access method, in which the servo drive acknowledges each parameter access (via SDOs) and an unconfirmed access method, in which no acknowledgement is made (via PDOs). As a rule, the servo drive is parameterised via SDOs, while the cyclic process data is exchanged via PDOs.

The following communication objects are defined in total:

| | | |
|--------------|-------------------------|--|
| SDO | Service Data Object | Are used for normal parameterization of the servo drive |
| PDO | Process Data Object | Fast exchange of process data (e.g. actual speed) possible |
| SYNC | Synchronization Message | Synchronization of multiple CAN nodes |
| EMCY | Emergency Message | Transfer of error messages |
| NMT | Network Management | Network service: For example, all CAN nodes can be acted upon simultaneously |
| BOOTUP | Error Control Protocol | Bootup message |
| HEARTBEAT | Error Control Protocol | Monitoring of communication participants through periodic messages |
| NODEGUARDING | Error Control Protocol | Monitoring of communication participants through periodic messages |

Each message sent on the CAN bus contains a type of address which can be used to determine for which bus station the message is intended. This number is called identifier. The lower the identifier, the higher the priority of the message. Identifiers are defined for each of the communication objects mentioned above. The following figure shows the basic structure of a CANopen message:




6.2 Access via SDO

The object dictionary of the servo drive can be accessed via the **service data objects** (SDO). SDO accesses always originate from the superordinate control (host). The host sends either a write command to the servo drive to change a parameter of the object dictionary or a read command to read out a parameter. For each command, the host receives a response that either contains the read value or - in the case of a write command - serves as an acknowledgement. To allow the servo drive to recognise that the command is intended for it, the host must send the command with a specific identifier. **This identifier consists of the base 600h + node number of the servo drive concerned. The servo drive responds accordingly with the identifier 580h + node number.** The structure of the commands or the responses depends on the data type of the object to be read or written, since either 1, 2 or 4 data bytes must be sent or received. The following data types are supported:

| | | |
|--------|-----------------------|--------------------------------|
| UINT8 | 8-bit value unsigned | 0 ... 255 |
| INT8 | 8-bit value signed | -128 ... 127 |
| UINT16 | 16-bit value unsigned | 0 ... 65536 |
| INT16 | 16-bit value signed | -32768 ... 32767 |
| UINT32 | 32-bit value unsigned | 0 ... $(2^{32} - 1)$ |
| INT32 | 32-bit value signed | $-(2^{31})$... $(2^{31} - 1)$ |
| VISSTR | Visible string | --- |

6.2.1 SDO sequences for reading and writing

In order to read or write objects of these number types, the sequences listed below are to be used. The commands for writing a value to the servo drive start with a different identifier depending on the data type. The response identifier, however, is always the same. Read commands always start with the same identifier and the servo drive responds differently depending on the data type returned. All numbers are in hexadecimal notation.



EXAMPLE


| | |
|---|---|
| UINT8 / INT8 Reading object 6061 _h -00 _h Return data: 01 _h Command: 40 _h 61 _h 60 _h 00 _h Response: 4F _h 61 _h 60 _h 00 _h 01 _h | Writing object 1401 _h -02 _h Data: EF _h Command: 2F _h 01 _h 14 _h 02 _h EF _h Response: 60 _h 01 _h 14 _h 02 _h |
| UINT16 / INT16 Reading object 6041 _h -00 _h Return data: 1234 _h Command: 40 _h 41 _h 60 _h 00 _h Response: 4B _h 41 _h 60 _h 00 _h 34 _h 12 _h | Writing object 6040 _h -00 _h Data: 03E8 _h Command: 2B _h 40 _h 60 _h 00 _h E8 _h 03 _h Response: 60 _h 40 _h 60 _h 00 _h |
| UINT32 / INT32 Reading object 6093 _h -01 _h Return data: 12345678 _h Command: 40 _h 93 _h 60 _h 01 _h Response: 43 _h 93 _h 60 _h 01 _h 78 _h 56 _h 34 _h 12 _h | Writing object 6093 _h -01 _h Data: 12345678 _h Command: 23 _h 93 _h 60 _h 01 _h 78 _h 56 _h 34 _h 12 _h Response: 60 _h 93 _h 60 _h 01 _h |

INFORMATION Wait for the acknowledgement from the servo drive!

Only when the servo drive has acknowledged the request further requests may be sent.

6.2.2 SDO error response (abort codes)

In case of an error during reading or writing (e.g. because the written value is too large), the servo drive responds with an error code instead of acknowledging:



| Error code F3 F2 F1 F0 | Meaning |
|---------------------------|---|
| 05 03 00 00 _h | Toggle bit not alternated |
| 05 04 00 01 _h | Client/server command specifier not valid or unknown |
| 06 01 00 00 _h | Unsupported access to an object |
| 06 01 00 01 _h | Attempt to read a write only object |
| 06 01 00 02 _h | Attempt to write a read only object |
| 06 02 00 00 _h | Object does not exist in the object dictionary |
| 06 04 00 41 _h | Object cannot be mapped to the PDO (e.g. a ro-object in an RPDO) |
| 06 04 00 42 _h | The number and length of the objects to be mapped would exceed PDO length |
| 06 04 00 43 _h | General parameter incompatibility reason |
| 06 04 00 47 _h | General internal incompatibility in the device |
| 06 06 00 00 _h | Access failed due to an hardware error *1) |
| 06 07 00 10 _h | Data type does not match, length of service parameter does not match |
| 06 07 00 12 _h | Data type does not match, length of service parameter too high |
| 06 07 00 13 _h | Data type does not match, length of service parameter too low |
| 06 09 00 11 _h | Sub-index does not exist |
| 06 09 00 30 _h | Value range of parameter exceeded (only for write access) |
| 06 09 00 31 _h | Value of parameter written too high |
| 06 09 00 32 _h | Value of parameter written too low |
| 06 09 00 36 _h | Maximum value is less than minimum value |
| 08 00 00 20 _h | Data cannot be transferred or stored to the application *1) |
| 08 00 00 21 _h | Data cannot be transferred or stored to the application because of local control |
| 08 00 00 22 _h | Data cannot be transferred or stored to the application because of the present device state *3) |
| 08 00 00 23 _h | Object dictionary dynamic generation fails or no object dictionary is present *2) |

*1) Returned according to DS301 if [store_parameters](#) / [restore_parameters](#) are accessed incorrectly.

*2) This error is returned e.g. if another bus system controls the servo drive or parameter access is not allowed.

*3) "Device state" is to be understood generally here: It can be the wrong operating mode, as well as a non-existent technology module or similar.

6.3 Access via PDO


Process data objects (PDOs) can be used to transfer data in an event-controlled manner. The PDO only transfers payload data. Which parameters are transferred is defined in advance between host and servo. In contrast to an SDO, there is no acknowledgement when a PDO is transmitted. The following types of PDOs are distinguished:

| | | |
|---------------------|-------------|---|
| Transmit-PDO (TPDO) | Servo→ Host | Servo drive sends PDO on occurrence of a specific event |
| Receive-PDO (RPDO) | Host→ Servo | Servo drive evaluates PDO on occurrence of a specific event |

The servo drive has four transmit and four receive PDOs.

Almost all objects of the object dictionary can be mapped into the PDOs, for example the actual speed value, the actual position value or similar.

In the example below, the position actual value would be transmitted in data bytes 0...3 of the PDO and the speed actual value in bytes 4...7.



In this way almost any data telegrams can be defined. The following chapters describe the settings required for this.

6.3.1 Description of objects

› Identifier of the PDO

COB_ID_used_by_PDO

The identifier on which the respective PDO is to be sent or received must be entered in the object [COB_ID_used_by_PDO](#). If bit 31 is set, the respective PDO is deactivated. This is the default setting for all PDOs. The COB-ID may only be changed if the PDO is deactivated, i.e. bit 31 is set. An identifier other than currently set in the servo drive may therefore only be written if bit 31 is set at the same time. The set bit 30 when reading the identifier indicates that the object cannot be queried by a remote frame. This bit is ignored on writing and is always set on reading.

› Number of objects to be transferred

number_of_mapped_objects

This object specifies how many objects are to be mapped into the corresponding PDO. The following restrictions must be observed:

- A maximum of 4 objects can be mapped per PDO
- A PDO may have a maximum of 64 bits (8 bytes)

› Objects to be transferred

first_mapped_object ... fourth_mapped_object

For each object to be contained in the PDO, the servo drive must be given the corresponding index, subindex and length. The length specification must match the length specification in the Object Dictionary. Parts of an object cannot be mapped.

The mapping entry is composed as follows:

Index (16 Bit), Subindex (8 Bit), Length (8 Bit)

To simplify the mapping, the following procedure is prescribed:

1. The number of mapped objects must be set to 0.
2. The parameters [first_mapped_object...fourth_mapped_object](#) may be written (The total length of all objects is not relevant at this time).
3. The number of mapped objects is set to a value between 1...4. The length of all these objects must not exceed 64 bits now.

› Transmission type

transmission_type and inhibit_time

For each PDO it can be defined which event causes the transmission (Transmit-PDO) or the evaluation (Receive-PDO) of a message:

| Value | Meaning | allowed with |
|----------------------------------|--|------------------|
| 01 _h –F0 _h | SYNC message The numerical value indicates how many SYNC messages must have arrived before the PDO is <ul style="list-style-type: none"> • sent (T-PDO) or • evaluated (R-PDO) | TPDOs RPDOs |
| FE _h | Cyclic The Transmit PDO is updated and sent cyclically by the servo drive. The time period is defined by the object inhibit_time in 100µs steps. In contrast, receive PDOs are evaluated immediately after receipt. | TPDOs (RPDOs) |
| FF _h | Change The Transmit PDO is sent when at least 1 bit has changed in the data of the PDO. This transmission_type is also permitted for Receive-PDOs. In addition, the inhibit_time can be used to define the minimum interval between the transmission of two PDOs in 100µs steps. | TPDOs |

› Masking

transmit_mask_high and transmit_mask_low

If "Change" is selected as [transmission_type](#), the TPDO is always sent if at least 1 bit of the TPDO changes. But often it is needed that the TPDO is only sent if certain bits have changed. Therefore the TPDO can be provided with a mask: Only the bits of the TPDO that are set to "1" in the mask are used to evaluate whether the PDO has changed. Since this function is manufacturer specific, all bits of the masks are set by default.

EXAMPLE

The following objects are to be transmitted together in one PDO:

| Index_Subindex | Length | Object name |
|-----------------------------------|-----------------|----------------------------|
| 6041 _h 00 _h | 10 _h | statusword |
| 6061 _h 00 _h | 08 _h | modes_of_operation_display |
| 60FD _h 00 _h | 20 _h | digital_inputs |

The first Transmit PDO (TPDO 1) is to be used, which is to be sent whenever one of the digital inputs changes, but at most every 10 ms. 187h is to be used as identifier for this PDO.

- Deactivate PDO** cob_id_used_by_pdo = C0000187h
 If the PDO is active, it must first be deactivated, i.e. the identifier must be written with bit 31 set:
- Delete number of objects** number_of_mapped_objects = 0
 To allow changing the object mapping, the number of mapped objects must be set to zero.
- Configuring objects** first_mapped_object = 60410010_h
 Index and subindex of the objects listed above must each be combined to a 32 bit value. second_mapped_object = 60610008_h
third_mapped_object = 60FD0020_h
- Set number of objects** number_of_mapped_objects = 3
 Three objects are to be transmitted in the PDO.
- Set transmission type** transmission_type = FF_h
 The PDO should be sent on change of the digital inputs. To ensure that only the change of the digital inputs leads to sending, the PDO is masked. The PDO should be sent at most every 10 ms (100x100µs). transmit_mask_low = 000000FF_h
transmit_mask_high = FFFFFFF0_h
inhibit_time = 64_h
- Set identifier** cob_id_used_by_pdo = 40000187h
 The PDO is to be sent with identifier 187h: Writing of the identifier with deleted bit 31:

INFORMATION Changing the PDO settings

Note that the PDO configuration may generally only be changed if the network status (NMT) is not [Operational](#). See also section 6.6 *Network Management (NMT service)* on page 182.

6.3.2 Objects for PDO configuration

The individual objects for configuring the PDOs are the same for all 4 TPDOs and all 4 RPDOs. Therefore only the parameter description of the first TPDO is explicitly listed below. It is to be used analogously also for the other PDOs, which are listed tabularly in the following:

| | | | | |
|-----------|---|-------------------|-----------------------|-----------------|
| Index | 1800 _h | | | |
| Name | transmit_pdo_parameter_tpdo1 | | | |
| Type | RECORD | | | 03 _h |
| Sub-Index | 01 _h | | | |
| Name | cob_id_used_by_pdo_tpdo1 | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | 181 _h ...1FF _h , Bit 30 and 31 may be set | | C0000181 _h | |
| Sub-Index | 02 _h | | | |
| Name | transmission_type_tpdo1 | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 0...8C _h , FE _h , FF _h | | FF _h | |
| Sub-Index | 03 _h | | | |
| Name | inhibit_time_tpdo1 | | | |
| Info | 100μs (10 = 1ms) | rw | PDO | UINT16 |
| Value | -- | 0000 _h | | |

| | | | | |
|-----------|--------------------------------|-----------|----------------|-----------------|
| Index | 1A00 _h | | | |
| Name | transmit_pdo_mapping_tpdo1 | | | |
| Type | RECORD | | | 20 _h |
| Sub-Index | 00 _h | | | |
| Name | number_of_mapped_objects_tpdo1 | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 0...4 | see Table | | |
| Sub-Index | 01 _h | | | |
| Name | first_mapped_object_tpdo1 | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | see Table | | |
| Sub-Index | 02 _h | | | |
| Name | second_mapped_object_tpdo1 | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | see Table | | |
| Sub-Index | 03 _h | | | |
| Name | third_mapped_object_tpdo1 | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | see Table | | |

| | | | | |
|-----------|----------------------------|-----------|----------------|--------|
| Sub-Index | 04 _h | | | |
| Name | fourth_mapped_object_tpdo1 | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | -- | see Table | | |

INFORMATION PDO must be deactivated before configuring.

Note that the object groups `transmit_pdo_parameter_xxx` and `transmit_pdo_mapping_xxx` can only be written if the PDO is deactivated (Bit 31 in `cob_id_used_by_pdo_xxx` set).

1. Transmit PDO

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|--------------------------|--------|------|-----------------------|
| 1800 _h 00 _h | number of entries | UINT8 | ro | 03 _h |
| 1800 _h 01 _h | COB-ID used by PDO | UINT32 | rw | C0000181 _h |
| 1800 _h 02 _h | transmission type | UINT8 | rw | FF _h |
| 1800 _h 03 _h | inhibit time (100 µs) | UINT16 | rw | 0000 _h |
| 1A00 _h 00 _h | number of mapped objects | UINT8 | rw | 01 _h |
| 1A00 _h 01 _h | first mapped object | UINT32 | rw | 60410010 _h |
| 1A00 _h 02 _h | second mapped object | UINT32 | rw | 00000000 _h |
| 1A00 _h 04 _h | fourth mapped object | UINT32 | rw | 00000000 _h |

tpdo_1_transmit_mask

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|---------------------------|--------|------|-----------------------|
| 2014 _h 00 _h | number of entries | UINT8 | ro | 02 _h |
| 2014 _h 01 _h | tpdo_1_transmit_mask_low | UINT32 | rw | FFFFFFFF _h |
| 2014 _h 02 _h | tpdo_1_transmit_mask_high | UINT32 | rw | FFFFFFFF _h |

2. Transmit PDO

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|--------------------------|--------|------|-----------------------|
| 1801 _h 00 _h | number of entries | UINT8 | ro | 03 _h |
| 1801 _h 01 _h | COB-ID used by PDO | UINT32 | rw | C0000281 _h |
| 1801 _h 02 _h | transmission type | UINT8 | rw | FF _h |
| 1801 _h 03 _h | inhibit time (100 µs) | UINT16 | rw | 0000 _h |
| 1A01 _h 00 _h | number of mapped objects | UINT8 | rw | 02 _h |
| 1A01 _h 01 _h | first mapped object | UINT32 | rw | 60410010 _h |
| 1A01 _h 02 _h | second mapped object | UINT32 | rw | 60610008 _h |
| 1A01 _h 03 _h | third mapped object | UINT32 | rw | 00000000 _h |
| 1A01 _h 04 _h | fourth mapped object | UINT32 | rw | 00000000 _h |

tpdo_2_transmit_mask

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|---------------------------|--------|------|-----------------------|
| 2015 _h 00 _h | number of entries | UINT8 | ro | 02 _h |
| 2015 _h 01 _h | tpdo_2_transmit_mask_low | UINT32 | rw | FFFFFFFF _h |
| 2015 _h 02 _h | tpdo_2_transmit_mask_high | UINT32 | rw | FFFFFFFF _h |

3. Transmit PDO

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|--------------------------|--------|------|-----------------------|
| 1802 _h 00 _h | number of entries | UINT8 | ro | 03 _h |
| 1802 _h 01 _h | COB-ID used by PDO | UINT32 | rw | C0000381 _h |
| 1802 _h 02 _h | transmission type | UINT8 | rw | FF _h |
| 1802 _h 03 _h | inhibit time (100 µs) | UINT16 | rw | 0000 _h |
| 1A02 _h 00 _h | number of mapped objects | UINT8 | rw | 02 _h |
| 1A02 _h 01 _h | first mapped object | UINT32 | rw | 60410010 _h |
| 1A02 _h 02 _h | second mapped object | UINT32 | rw | 60640020 _h |
| 1A02 _h 03 _h | third mapped object | UINT32 | rw | 00000000 _h |
| 1A02 _h 04 _h | fourth mapped object | UINT32 | rw | 00000000 _h |

tpdo_3_transmit_mask

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|---------------------------|--------|------|-----------------------|
| 2016 _h 00 _h | number of entries | UINT8 | ro | 02 _h |
| 2016 _h 01 _h | tpdo_3_transmit_mask_low | UINT32 | rw | FFFFFFFF _h |
| 2016 _h 02 _h | tpdo_3_transmit_mask_high | UINT32 | rw | FFFFFFFF _h |

4. Transmit PDO

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|--------------------------|--------|------|-----------------------|
| 1803 _h 00 _h | number of entries | UINT8 | ro | 03 _h |
| 1803 _h 01 _h | COB-ID used by PDO | UINT32 | rw | C0000481 _h |
| 1803 _h 02 _h | transmission type | UINT8 | rw | FF _h |
| 1803 _h 03 _h | inhibit time (100 µs) | UINT16 | rw | 0000 _h |
| 1A03 _h 00 _h | number of mapped objects | UINT8 | rw | 02 _h |
| 1A03 _h 01 _h | first mapped object | UINT32 | rw | 60410010 _h |
| 1A03 _h 02 _h | second mapped object | UINT32 | rw | 606C0020 _h |
| 1A03 _h 03 _h | third mapped object | UINT32 | rw | 00000000 _h |
| 1A03 _h 04 _h | fourth mapped object | UINT32 | rw | 00000000 _h |

tpdo_4_transmit_mask

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|---------------------------|--------|------|-----------------------|
| 2017 _h 00 _h | number of entries | UINT8 | ro | 02 _h |
| 2017 _h 01 _h | tpdo_4_transmit_mask_low | UINT32 | rw | FFFFFFFF _h |
| 2017 _h 02 _h | tpdo_4_transmit_mask_high | UINT32 | rw | FFFFFFFF _h |

1. Receive PDO

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|--------------------------|--------|------|-----------------------|
| 1400 _h 00 _h | number of entries | UINT8 | ro | 02 _h |
| 1400 _h 01 _h | COB-ID used by PDO | UINT32 | rw | C0000201 _h |
| 1400 _h 02 _h | transmission type | UINT8 | rw | FF _h |
| 1600 _h 00 _h | number of mapped objects | UINT8 | rw | 01 _h |
| 1600 _h 01 _h | first mapped object | UINT32 | rw | 60400010 _h |
| 1600 _h 02 _h | second mapped object | UINT32 | rw | 00000000 _h |
| 1600 _h 03 _h | third mapped object | UINT32 | rw | 00000000 _h |
| 1600 _h 04 _h | fourth mapped object | UINT32 | rw | 00000000 _h |

2. Receive PDO

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|--------------------------|--------|------|-----------------------|
| 1401 _h 00 _h | number of entries | UINT8 | ro | 02 _h |
| 1401 _h 01 _h | COB-ID used by PDO | UINT32 | rw | C0000301 _h |
| 1401 _h 02 _h | transmission type | UINT8 | rw | FF _h |
| 1601 _h 00 _h | number of mapped objects | UINT8 | rw | 02 _h |
| 1601 _h 01 _h | first mapped object | UINT32 | rw | 60400010 _h |
| 1601 _h 02 _h | second mapped object | UINT32 | rw | 60600008 _h |
| 1601 _h 03 _h | third mapped object | UINT32 | rw | 00000000 _h |
| 1601 _h 04 _h | fourth mapped object | UINT32 | rw | 00000000 _h |

3. Receive PDO

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|--------------------------|--------|------|-----------------------|
| 1402 _h 00 _h | number of entries | UINT8 | ro | 02 _h |
| 1402 _h 01 _h | COB-ID used by PDO | UINT32 | rw | C0000401 _h |
| 1402 _h 02 _h | transmission type | UINT8 | rw | FF _h |
| 1602 _h 00 _h | number of mapped objects | UINT8 | rw | 02 _h |
| 1602 _h 01 _h | first mapped object | UINT32 | rw | 60400010 _h |
| 1602 _h 02 _h | second mapped object | UINT32 | rw | 607A0020 _h |
| 1602 _h 03 _h | third mapped object | UINT32 | rw | 00000000 _h |
| 1602 _h 04 _h | fourth mapped object | UINT32 | rw | 00000000 _h |

4. Receive PDO

| Index | Comment | Type | Acc. | Default Value |
|-----------------------------------|--------------------------|--------|------|-----------------------|
| 1403 _h 00 _h | number of entries | UINT8 | ro | 02 _h |
| 1403 _h 01 _h | COB-ID used by PDO | UINT32 | rw | C0000501 _h |
| 1403 _h 02 _h | transmission type | UINT8 | rw | FF _h |
| 1603 _h 00 _h | number of mapped objects | UINT8 | rw | 02 _h |
| 1603 _h 01 _h | first mapped object | UINT32 | rw | 60400010 _h |
| 1603 _h 02 _h | second mapped object | UINT32 | rw | 60FF0020 _h |
| 1603 _h 03 _h | third mapped object | UINT32 | rw | 00000000 _h |
| 1603 _h 04 _h | fourth mapped object | UINT32 | rw | 00000000 _h |

6.3.3 Activation of PDOs

The following points must be fulfilled for the servo drive to **send** or **evaluate** PDOs:

- The object [number_of_mapped_objects](#) must be non-zero.
- Bit 31 in the [cob_id_used_for_pdos](#) object must be cleared.
- The communication status of the servo drive must be [Operational](#) (see section 6.6 *Network Management (NMT service)* on page 182)


The communication status of the servo drive must not be [Operational](#) so that PDOs can be **configured**.

6.4 EMERGENCY message

The servo drive monitors the function of its main assemblies. These include the power supply, the power stage, the angle encoder evaluation and the technology slots available on some servo drives. In addition, the motor (temperature, angle encoder) and the limit switches are continuously monitored. Incorrect parameterizations can also lead to error messages (division by zero, etc.).

6.4.1 Overview

The servo drive sends an EMERGENCY message when an error occurs or when an error is acknowledged. The identifier of this message is composed of the identifier 80h and the node number of the servo drive concerned.




After a reset, the servo drive is in the Error free state (which it may leave again immediately if an error has been present from the start). The following state transitions are possible:

| Nr. | Cause | Description |
|-----|--------------------------|--|
| 0 | Initialization completed | |
| 1 | Error occurs | There was no error and an error occurs. An EMERGENCY telegram with the error code of the occurred error is sent |
| 2 | Error acknowledgement | An error acknowledgement (see section 4.3 <i>controlword</i> on page 112) is attempted, but not all causes are resolved. |
| 3 | Error occurs | There is already an error and another error occurs. An EMERGENCY telegram with the error code of the new error is sent. |
| 4 | Error acknowledgement | An error acknowledgement is attempted and all causes are eliminated. An EMERGENCY telegram with error code 0000 is sent. |

6.4.2 Structure of the EMERGENCY message

The EMERGENCY message consists of eight data bytes, where the first two bytes contain an **error_code**. The third byte contains another error code (Object **1001_h**), which, does not contain any relevant information for Metronix servo drives. The remaining five bytes contain zeros.



An overview of all error codes that may occur can be found in section 7.3 *Error codes of the EMERGENCY message* on page 191

6.4.3 Description of objects

Object **1003_h**: **pre_defined_error_field**


The respective **error_code** of the error messages is additionally stored in a four-level error memory. This is structured like a shift register so that the last error that occurred is always stored in object **1003_h01_h** (**standard_error_field_0**). By a read access to the object **1003_h00_h** (**pre_defined_error_field**) it can be determined how many error messages are currently stored in the error memory. The error memory is cleared by writing the value 0 into the object **1003_h00_h** (**pre_defined_error_field**). In order to be able to reactivate the output stage of the servo drive after an error, an error acknowledgement (**reset_fault**, see section 4.3 *controlword* on page 112) must also be performed.

| | | | |
|-----------|--------------------------------|----|-----------------------|
| Index | 1003_h | | |
| Name | pre_defined_error_field | | |
| Type | ARRAY | | 04 _h |
| Sub-Index | 01_h | | |
| Name | standard_error_field_0 | | |
| Info | -- | ro | PDO UINT32 |
| Value | -- | | 00000000 _h |
| Sub-Index | 02_h | | |
| Name | standard_error_field_1 | | |
| Info | -- | ro | PDO UINT32 |
| Value | -- | | 00000000 _h |

| | | | | |
|-----------|------------------------|-----------------------|----------------|--------|
| Sub-Index | 03 _h | | | |
| Name | standard_error_field_2 | | | |
| Info | -- | ro | PDO | UINT32 |
| Value | -- | 00000000 _h | | |
| | | | | |
| Sub-Index | 04 _h | | | |
| Name | standard_error_field_3 | | | |
| Info | -- | ro | PDO | UINT32 |
| Value | -- | 00000000 _h | | |

6.5 SYNC message

Several devices of a plant can be synchronised with each other. For this purpose, one of the devices (usually the superordinate control) periodically sends out synchronization messages. All connected servo drives receive these messages and use them to handle the PDOs (siehe section 6.3 *Access via PDO* on page 170).




The identifier on which the servo drive receives the SYNC message is fixed at 80_h. The identifier can be read out via the object [cob_id_sync](#).

| | | | | |
|-------|-------------------------|-----------------|----------------|--------|
| Index | 1005_h | | | |
| Name | cob_id_sync | | | |
| Info | -- | rw | PDO | UINT32 |
| Value | 80 _h | 80 _h | | |

6.6 Network Management (NMT service)

All CANopen devices can be controlled via the network management. The identifier with the highest priority (000h) is reserved for this purpose. Commands can be sent to one or all servo drives via NMT. Each command consists of two bytes, whereby the first byte contains the command code (**command specifier**, CS) and the second byte the node address (**node id**, NI) of the addressed servo drive. If zero is specified as node address, all nodes in the network will be addressed (broadcast). This makes it possible, for example, to trigger a reset in all devices at the same time. The servo drives do not acknowledge the NMT commands. It can only be concluded indirectly (e.g. by the Bootup message after a reset) that the reset was carried out successfully.

Structure of the NMT message:



States are defined in a state diagram for the NMT status of the CANopen node. State changes can be triggered via the CS byte in the NMT message. These are essentially oriented on the target state.




Figure 29: NMT-State machine

| Transition | Name | CS | Target state | NMT state |
|------------|-----------------------|-----------------|-----------------|-----------------|
| 1 | Power on | | | |
| 2 | Bootup | | Pre-Operational | 7F _h |
| 3 | Start Remote Node | 01 _h | Operational | 05 _h |
| 4 | Enter Pre-Operational | 80 _h | Pre-Operational | 7F _h |
| 5 | Stop Remote Node | 02 _h | Stopped | 04 _h |
| 6 | Start Remote Node | 01 _h | Operational | 05 _h |
| 7 | Enter Pre-Operational | 80 _h | Pre-Operational | 7F _h |
| 8 | Stop Remote Node | 02 _h | Stopped | 04 _h |
| 9 | Reset Communication | 82 _h | Pre-Operational | 7F _h |
| 10 | Reset Communication | 82 _h | Pre-Operational | 7F _h |
| 11 | Reset Communication | 82 _h | Pre-Operational | 7F _h |
| 12 | Reset Application | 81 _h | Pre-Operational | 7F _h |
| 13 | Reset Application | 81 _h | Pre-Operational | 7F _h |
| 14 | Reset Application | 81 _h | Pre-Operational | 7F _h |

State transitions 2, 15 and 16 are executed automatically by the servo drive when initialization is complete.

Depending on the NMT status, certain communication objects cannot be used: For example, it is absolutely necessary to set the NMT status to **Operational** so that the servo drive sends PDOs.

| State | Description | SDO | PDO | NMT |
|---------------------|--|-----|-----|-----|
| Reset Application | No communication. All CAN objects are reset to their reset values (application parameter set). | - | - | - |
| Reset Communication | No communication. The CAN controller is reinitialised. | - | - | - |
| Initialising | State after hardware reset. Resetting the CAN node, sending the bootup message. | - | - | - |
| Pre-Operational | Communication via SDOs possible. PDOs not active (No sending / evaluation). | X | - | X |
| Operational | Communication via SDOs possible. All PDOs active (sending / evaluating). | X | X | X |
| Stopped | No communication except heartbeating. | - | - | X |

INFORMATION Note the following instructions

- NMT telegrams must not be sent in a burst (one immediately after the other).
- There must be at least twice the position controller cycle time between two successive NMT telegrams on the bus (even for different nodes!) so that the servo drive can process the NMT telegrams correctly.
- The NMT command "Reset Application" is delayed, if necessary, until a running save operation is completed, as otherwise the save operation would remain incomplete (Defective parameter set). The delay can be in the range of a few seconds.
- The communication status must be set to **Operational** for the servocontroller to send and receive PDOs.


6.7 Bootup

6.7.1 Overview

After switching on the power supply or after a reset, the servo drive reports via a bootup message that the initialization phase has been completed. The servo drive then has the NMT status [Pre-Operational](#).

6.7.2 Structure of the Bootup message

The bootup message is structured almost identically to the following heartbeat message. Only a zero is sent instead of the NMT status.




6.8 Heartbeat (Error Control Protocol)

6.8.1 Overview

To monitor the communication between slave (drive) and master, the so-called heartbeat protocol can be activated: The drive sends cyclic messages to the master. The master can check the cyclic occurrence of these messages and initiate appropriate measures if they fail to appear. Since both heartbeat and nodeguarding telegrams (see section 6.9 *Nodeguarding (Error Control Protocol)* on page 187) are sent with the identifier **700_h + node number**, both protocols cannot be active at the same time. If both protocols are activated at the same time, only the heartbeat protocol is active.

6.8.2 Structure of the Heartbeat message

The heartbeat telegram is sent with the identifier **700_h + node number**. It contains only 1 byte of user data, the NMT status of the servo drive (see section 6.6 *Network Management (NMT service)* on page 182).



6.8.3 Description of objects

Object 1017_h: producer_heartbeat_time

To activate the heartbeat functionality, the time between two heartbeat telegrams can be defined via the object [producer_heartbeat_time](#).

| | | | | |
|-------|-------------------------|----|-----|--------|
| Index | 1017 _h | | | |
| Name | producer_heartbeat_time | | | |
| Info | ms | rw | PDO | UINT16 |
| Value | 0...65536 | | 0 | |

The [producer_heartbeat_time](#) can be stored in the parameter set. If the servo drive starts with a [producer_heartbeat_time](#) not equal to zero, the bootup message is considered the first heartbeat. The servo drive can only be used as a heartbeat producer. Object 1016_h ([consumer_heartbeat_time](#)) is therefore only implemented for compatibility reasons and always returns 0.


6.9 Nodeguarding (Error Control Protocol)

6.9.1 Overview


The nodeguarding protocol can also be used to monitor the communication between slave (drive) and master. In contrast to the heartbeat protocol, with nodeguarding the master and slave monitor each other: The master cyclically asks the drive for its NMT status. A certain bit is toggled in each response from the servo drive. If these answers are missing or if the servo drive always answers with the same toggle bit, the master can react accordingly. Similarly, the drive monitors the regular arrival of nodeguarding requests from the master: if the messages remain missing for a certain period of time, the servo drive triggers error 12-4. Since both heartbeat and nodeguarding telegrams (see section 6.9 *Nodeguarding (Error Control Protocol)* on page 187) are sent with the identifier **700_h + node number**, both protocols cannot be active at the same time. If both protocols are activated at the same time, only the heartbeat protocol is active.

6.9.2 Structure of the Nodeguarding messages

The request of the master must be sent as remote frame with the identifier **700_h + node number**. With a remote frame a special bit is additionally set in the telegram, the remote bit. Remote frames have in principle no data.



The servo drive response is structured in the same way as the heartbeat message. It contains only 1 byte of user data, the togglebit and the NMT status of the servo drive.



| Bit | Value | Name | Description |
|-------|-----------------|------------|---|
| 7 | 80 _h | toggle_bit | Changes with every telegram |
| 0...6 | 7F _h | nmt_state | section 6.6 <i>Network Management (NMT service)</i> on page 182 |

The monitoring time for requests from the master can be parameterised. The monitoring starts with the first received remote request of the master. From this point on, the remote requests must arrive before the set monitoring time has elapsed, otherwise error 12-4 is triggered. The togglebit is reset by the NMT command [Reset Communication](#). It is therefore deleted in the first response of the servo drive.

6.9.3 Description of objects

6.9.3.1 Object 100C_h: guard_time

To activate the node guarding monitoring, the maximum time between two remote queries of the master is parameterised. This time is determined in the servo drive from the product of [guard_time](#) (100C_h) and [life_time_factor](#) (100D_h). It is therefore recommended to describe the [life_time_factor](#) with 1 and then to specify the time directly via the [guard_time](#) in milliseconds.

| | | | | |
|-------|-------------------|----|----------------|--------|
| Index | 100C _h | | | |
| Name | guard_time | | | |
| Info | ms | rw | PDO | UINT16 |
| Value | 0...65536 | | 0 | |

6.9.3.2 Object 100D_h: life_time_factor

The [life_time_factor](#) should be set to 1 to specify the [guard_time](#) directly.

| | | | | |
|-------|-------------------|----|----------------|-------|
| Index | 100D _h | | | |
| Name | life_time_factor | | | |
| Info | -- | rw | PDO | UINT8 |
| Value | 0...1 | | 0 | |

6.10 Table of identifiers

The following table gives an overview of the identifiers used:

| Object type | Identifier (hexadecimal) | Remark |
|---------------------|---|--|
| SDO (Host to Servo) | 600 _h + Node number | |
| SDO (Servo to Host) | 580 _h + Node number | |
| TPDO1 | 181 _h / 180 _h + Node number | These are the default values. The node number can be added automatically if the corresponding option is set (see section 2.1.5 <i>Activate CANopen</i> on page 18). |
| TPDO2 | 281 _h / 280 _h + Node number | |
| TPDO3 | 381 _h / 380 _h + Node number | |
| TPDO4 | 481 _h / 480 _h + Node number | |
| RPDO1 | 201 _h / 200 _h + Node number | |
| RPDO2 | 301 _h / 300 _h + Node number | |
| RPDO3 | 401 _h / 400 _h + Node number | |
| RPDO4 | 501 _h / 500 _h + Node number | |
| SYNC | 080 _h | |
| EMCY | 080 _h + Node number | |
| HEARTBEAT | 700 _h + Node number | |
| NODEGUARDING | 700 _h + Node number | |
| BOOTUP | 700 _h + Node number | |
| NMT | 000 _h | |

7 Appendix

7.1 CANopen

CANopen is a standard developed by the association "CAN in Automation". A large number of device manufacturers are organised in this association. This standard has now replaced all manufacturer-specific CAN protocols.

The elements of the object dictionary required for the Metronix servo drive families and the associated access methods are described in this CANopen manual.

CAN in Automation (CiA)
Kontumazgarten 3
DE-90429 Nürnberg
Tel.: +49-911-928819-0
Fax: +49-911-928819-79
[headquarters\(at\)can-cia.org](mailto:headquarters(at)can-cia.org)
www.can-cia.de

The CANopen implementation of the servo drive is based on the following standards:

- CiA Draft Standard 301, Version 4.02, 13. Februar 2002
- CiA Draft Standard Proposal 402, Version 2.0, 26. Juli 2002

7.2 Characteristics of the CAN interface

The CAN interface has the following characteristics:

- CAN specification V2.0 Part A (Part B passive, i.e. messages of this type are tolerated but not processed)
- Physical layer: ISO 11898

7.3 Error codes of the EMERGENCY message

| CAN code | Error number | Description |
|-------------------|--------------|---|
| 2300 _h | 31-x | Group 31: I ² t |
| 2311 _h | 31-1 | I ² t servo drive |
| 2312 _h | 31-0 | I ² t motor |
| 2313 _h | 31-2 | I ² t PFC |
| 2314 _h | 31-3 | I ² t braking resistor |
| 2320 _h | 6-x | Group 6: Short circuit in the power output stage |
| 3200 _h | 32-x | Group 32: PFC |
| 3210 _h | 7-x | Group 7: Overvoltage |
| 3220 _h | 2-x | Group 2: Undervoltage |
| 3280 _h | 32-0 | DC bus circuit charging time exceeded |
| 3281 _h | 32-1 | Undervoltage for active PFC |
| 3282 _h | 32-5 | Brake chopper overload. DC bus circuit could not be discharged. |
| 3283 _h | 32-6 | Discharging period DC bus circuit exceeded |
| 3284 _h | 32-7 | Supply voltage missing for enabling |
| 3285 _h | 32-8 | Supply voltage breakdown while servo drive enabled |
| 3286 _h | 32-9 | Phase failure |
| 4200 _h | 4-x | Group 4: Overtemperature |
| 4210 _h | 4-0 | Overtemperature power output stage |
| 4280 _h | 4-1 | Overtemperature DC bus circuit |
| 4310 _h | 3-x | Group 3: Overtemperature motor |
| 5080 _h | 90-x | Group 90: HW initialisation |
| 5110 _h | 5-x | Group 5: Internal voltage supply |
| 5114 _h | 5-0 | Failure of internal voltage 1 |
| 5115 _h | 5-1 | Failure of internal voltage 2 |
| 5116 _h | 5-2 | Driver supply failure |
| 5200 _h | 21-x | Group 21: Current measurement |
| 5220 _h | 16-4 | Unexpected hardware error |
| 5280 _h | 21-0 | Error 1 current measurement U |
| 5281 _h | 21-1 | Error 1 current measurement V |
| 5282 _h | 21-2 | Error 2 current measurement U |
| 5283 _h | 21-3 | Error 2 current measurement V |
| 5410 _h | 5-3 | Undervoltage digital I/Os |
| 5410 _h | 5-4 | Overcurrent digital I/Os |
| 5430 _h | 24-x | Group 24: Analogue input monitoring |

| CAN code | Error number | Description |
|-------------------|--------------|--|
| 5500 _h | 26-x | Group 26: Flash |
| 5580 _h | 26-0 | No user parameter set |
| 5581 _h | 26-1 | Checksum error |
| 5582 _h | 26-2 | Flash: write error |
| 5583 _h | 26-3 | Flash: erase error |
| 5584 _h | 26-4 | Flash: error in internal flash |
| 5585 _h | 26-5 | No calibration data |
| 5586 _h | 26-6 | No user position data sets |
| 6000 _h | 25-x | Group 25: Invalid device type |
| 6000 _h | 91-x | Group 91: SW initialisation |
| 6080 _h | 25-0 | Invalid device type |
| 6081 _h | 25-1 | Device type not supported |
| 6082 _h | 25-2 | Hardware revision not supported |
| 6083 _h | 25-3 | Device functionality restricted |
| 6100 _h | 16-x | Group 16: Program execution |
| 6180 _h | 1-x | Group 1: Stack overflow |
| 6181 _h | 16-0 | Incorrect program execution |
| 6182 _h | 16-1 | Illegal interrupt |
| 6183 _h | 16-3 | Unexpected state |
| 6184 _h | 15-x | Group 15: Mathematics |
| 6185 _h | 15-0 | Division by zero |
| 6186 _h | 15-1 | Out of range error |
| 6187 _h | 16-2 | Initialisation error |
| 6188 _h | 82-x | Group 82: Internal sequence control |
| 6320 _h | 36-x | Group 36: Parameters |
| 6380 _h | 30-x | Group 30: Internal calculations |
| 7122 _h | 14-x | Group 14: Motor and resolver identification |
| 7300 _h | 8-x | Group 8: Angle encoder |
| 7380 _h | 8-0 | Resolver/Hall angle encoder error |
| 7382 _h | 8-2 | Incremental encoder: Z0 track signals error |
| 7383 _h | 8-3 | Incremental encoder: Z1 track signals error |
| 7384 _h | 8-4 | Digital incremental encoder: track signals error |
| 7385 _h | 8-5 | Incremental encoder: hall signals error |
| 7386 _h | 8-6 | Angle encoder communication error |
| 7387 _h | 8-7 | Master frequency input: Incorrect signal amplitude incremental track |
| 7388 _h | 8-8 | Internal angle encoder error |

| CAN code | Error number | Description |
|-------------------|--------------|--|
| 7389 _h | 8-9 | Encoder at [X2B/X6] not supported |
| 73A0 _h | 9-x | Group 9: Encoder parameter set |
| 73A1 _h | 9-0 | Encoder parameter set: out-of-date format |
| 73A2 _h | 9-1 | Encoder parameter set cannot be decoded |
| 73A3 _h | 9-2 | Encoder parameter set: unknown version |
| 73A4 _h | 9-3 | Encoder parameter set: corrupted data structure |
| 73A5 _h | 9-7 | Encoder EEPROM is write protected |
| 73A6 _h | 9-9 | Too small memory size of encoder EEPROM |
| 7580 _h | 60-x | Group 60: Ethernet |
| 7581 _h | 61-x | Group 61: Ethernet |
| 8000 _h | 45-x | Group 45: IGBT driver supply |
| 8080 _h | 43-x | Group 43: HW limit switches |
| 8081 _h | 43-0 | Limit switch: negative setpoint inhibited |
| 8082 _h | 43-1 | Limit switch: positive setpoint inhibited |
| 8083 _h | 43-2 | Limit switch: positioning suppressed |
| 8084 _h | 45-0 | Driver supply cannot be switched off |
| 8085 _h | 45-1 | Driver supply cannot be switched on |
| 8086 _h | 45-2 | Driver supply has been activated |
| 8090 _h | 51-x | Group 51: FSM 2.0 |
| 8091 _h | 51-0 | No / unknown FSM module or driver supply faulty |
| 8093 _h | 51-2 | FSM: unequal module type |
| 8094 _h | 51-3 | FSM: unequal module version |
| 8095 _h | 51-4 | FSM: error in SSIO communication |
| 8096 _h | 51-5 | FSM: error in brake activation |
| 8097 _h | 51-6 | FSM: unequal serial number |
| 8098 _h | 52-x | Group 52: FSM 2.0 STO |
| 8099 _h | 52-1 | FSM: discrepancy time expired |
| 809A _h | 52-2 | FSM: STO/STOB deactivated while power output stage enabled |
| 809B _h | 52-3 | FSM: Limitation error |
| 80A0 _h | 53-x | Group 53: FSM: Violation of safety conditions |
| 80A1 _h | 53-0 | USF0: safety condition violated |
| 80A2 _h | 53-1 | USF1: safety condition violated |
| 80A3 _h | 53-2 | USF2: safety condition violated |
| 80A4 _h | 53-3 | USF3: safety condition violated |
| 80A9 _h | 54-x | Group 54: FSM: Violation of safety conditions |
| 80AA _h | 54-0 | SBC: safety condition violated |

| CAN code | Error number | Description |
|-------------------|--------------|---|
| 80AC _h | 54-2 | SS2: safety condition violated |
| 80AD _h | 54-3 | SOS: safety condition violated |
| 80AE _h | 54-4 | SS1: safety condition violated |
| 80AF _h | 54-5 | STO: safety condition violated |
| 80B0 _h | 54-6 | SBC: brake not released for > 10 days |
| 80B1 _h | 54-7 | SOS: SOS requested for > 10 days |
| 80C0 _h | 55-x | Group 55: FSM: Actual value evaluation 1 |
| 80C1 _h | 55-0 | FSM: no actual speed / position value available or standstill for > 10 days |
| 80C2 _h | 55-1 | FSM: SINCOS encoder [X2B] - signal error |
| 80C3 _h | 55-2 | FSM: SINCOS encoder [X2B] - standstill > 10 days |
| 80C4 _h | 55-3 | FSM: Resolver [X2A] - signal error |
| 80C6 _h | 55-7 | FSM: other encoder [X2B] - Faulty angle information |
| 80C7 _h | 55-8 | FSM: impermissible acceleration detected |
| 80D0 _h | 56-x | Group 56: FSM: Actual value evaluation 2 |
| 80D1 _h | 56-8 | FSM: speed / angle difference encoder 1 - 2 |
| 80D2 _h | 56-9 | FSM: error cross comparison encoder evaluation |
| 80E0 _h | 57-x | Group 57: FSM: Inputs/Outputs |
| 80E1 _h | 57-0 | FSM: I/O - Self test error (internal/external) |
| 80E2 _h | 57-1 | FSM: digital inputs - signal level error |
| 80E3 _h | 57-2 | FSM: digital inputs - test pulse error |
| 80E7 _h | 57-6 | FSM: overtemperature |
| 80E8 _h | 58-x | Group 58: FSM: Communication / Parameterisation |
| 80E9 _h | 58-0 | FSM: plausibility check of parameters |
| 80EA _h | 58-1 | FSM: general error parameterisation |
| 80ED _h | 58-4 | FSM: buffer internal communication |
| 80EE _h | 58-5 | FSM: communication safety module - servo drive |
| 80EF _h | 58-6 | FSM: error in cross comparison for processors 1 - 2 |
| 80F0 _h | 59-x | Group 59: FSM: Internal Error |
| 80F1 _h | 59-1 | FSM: failsafe supply / safe pulse inhibitor |
| 80F2 _h | 59-2 | FSM: error external power supply |
| 80F3 _h | 59-3 | FSM: error internal power supply |
| 80F4 _h | 59-4 | FSM: error management: too many errors |
| 80F5 _h | 59-5 | FSM: error writing to permanent event memory |
| 80F6 _h | 59-6 | FSM: error on saving parameter set |
| 80F7 _h | 59-7 | FSM: flash checksum error |
| 80F8 _h | 59-8 | FSM: internal monitoring, processor 1 - 2 |

| CAN code | Error number | Description |
|-------------------|--------------|--|
| 80F9 _h | 59-9 | FSM: other unexpected error |
| 8100 _h | 12-x | Group 12: CAN communication |
| 8100 _h | 13-x | Group 13: Timeout CAN bus |
| 8120 _h | 12-1 | CAN: communication error, bus OFF |
| 8130 _h | 12-4 | CAN: Node Guarding |
| 8180 _h | 12-0 | CAN: duplicate node number |
| 8181 _h | 12-2 | CAN: communication error (sending) |
| 8182 _h | 12-3 | CAN: communication error (receiving) |
| 8183 _h | 12-9 | CAN: protocol error |
| 8184 _h | 13-0 | Timeout CAN bus |
| 8200 _h | 50-x | Group 50: CAN communication |
| 8210 _h | 12-5 | CAN: RPDO too short |
| 8480 _h | 35-x | Group 35: Linear motor |
| 8600 _h | 42-x | Group 42: Positioning |
| 8611 _h | 17-x | Group 17: Max. following error exceeded |
| 8611 _h | 27-x | Group 27: Following error monitoring |
| 8612 _h | 40-x | Group 40: SW limit switches |
| 8680 _h | 42-0 | Positioning: no follow-up position: stop |
| 8681 _h | 42-1 | Positioning: reversal of rotation not permissible: stop |
| 8682 _h | 42-2 | Positioning: reversal of rotation after stop not permissible |
| 8700 _h | 34-x | Group 34: Fieldbus |
| 8780 _h | 34-0 | No synchronisation via fieldbus |
| 8781 _h | 34-1 | Fieldbus synchronisation error |
| 8A00 _h | 11-x | Group 11: Homing run |
| 8A00 _h | 33-x | Group 33: Following error encoder emulation |
| 8A80 _h | 11-0 | Error when homing run is started |
| 8A81 _h | 11-1 | Error during homing run |
| 8A82 _h | 11-2 | Homing: no valid index pulse |
| 8A83 _h | 11-3 | Homing: timeout |
| 8A84 _h | 11-4 | Homing: incorrect / invalid limit switch |
| 8A85 _h | 11-5 | Homing: I ² t / following error |
| 8A86 _h | 11-6 | Homing: end of search distance reached |
| 8A87 _h | 33-0 | Following error encoder emulation |
| F000 _h | 80-x | Group 80: IRQ_0_3 |
| F080 _h | 80-0 | Time overflow current control IRQ |
| F081 _h | 80-1 | Time overflow speed control IRQ |

| CAN code | Error number | Description |
|-------------------|--------------|------------------------------------|
| F082 _h | 80-2 | Time overflow position control IRQ |
| F083 _h | 80-3 | Time overflow interpolator IRQ |
| F084 _h | 81-4 | Time overflow low-level IRQ |
| F085 _h | 81-5 | Time overflow MDC IRQ |
| FF00 _h | 28-x | Group 28: Operating hours meter |
| FF01 _h | 28-0 | Missing operating hours meter |
| FF02 _h | 28-1 | Operating hours meter: write error |
| FF03 _h | 28-2 | Operating hours meter corrected |
| FF04 _h | 28-3 | Operating hours meter converted |